







-
-  Changes the set room temperature
 -  Changes the operating program
 -  Takes you one step back in the menu
 - OK** Confirms your selections or settings
 - ?** Calls up additional information
 -  Calls up the extended menu
 -  Cursor keys
Scroll through the menu or adjust values

Extended menu

Press 



Note

The maximum number of displays is shown. Depending on the system equipment level, some displays will not appear.