

# Vokera

heating for life

COMBI SYSTEM REGULAR & FLOOR STANDING BOILERS \ WATER HEATERS \ WATER CYLINDERS \ SPARE PARTS \ AFTER SALES SERVICE \ TRAINING



ON TILE & INSET FLAT PLATE SOLAR THERMAL COLLECTORS \ EVACUATED TUBE SOLAR THERMAL COLLECTORS \ AIR TO WATER HEAT PUMPS



# warmth

Spares Stockists Nationwide	3
Technical Support	3
Training	3
Customer Services	3
Spare Parts	4-27
Tools	26

## Spares Stockists Nationwide

Spare parts for all Vokèra products are available through our nationwide network of approved spares stockists. For peace of mind, spares availability is guaranteed for 10 years after product withdrawal. Our large spares stockist network supports repairs and maintenance of Vokèra boilers.

Visit [www.vokera.co.uk](http://www.vokera.co.uk) to view a list of out approved spares stockists.

**Important:** Fitting any of the parts listed should only be undertaken by a compliant Gas Safe Registered engineer.

## Technical Support

Our fully trained Gas Safe Registered technical team provides technical advice to help select the correct spare part for any particular Vokèra boiler. Call **0844 391 0999** (option 4)

Alternatively you can view spare parts within each individual product installation manual at [www.vokera.co.uk](http://www.vokera.co.uk)

## Training

A major factor in the success of Vokèra is a passionate commitment to professional standards within the domestic heating industry. Our industry leading Technical Training programme embodies that commitment and provides the most comprehensive training syllabus for domestic heating professionals in the UK today. Vokèra installers enjoy full support for their training requirements and we are happy to adapt our resources to your

specific needs for individual or group training courses. Our nationwide network of training centres and external facilities means that you are never more than a 90 minute car journey away from a Vokèra training resource anywhere in England or Wales.

For further information or to book a Vokèra training course, please call **0844 391 0999** (option 5) or visit [www.vokera.co.uk](http://www.vokera.co.uk)

## Customer Services

80% of calls to Vokèra Customer Service are answered within just 20 seconds. That fact reflects the importance we place on keeping our customers happy.

If you ever have a problem or a question relating to a Vokèra product, please call us on **0844 391 0999** (option 2).

Customer care centres operate:  
08.15 - 17.00 Monday to Friday  
08.00 - 12.00 Saturday



SPARE PARTS

Part No.	Description	Price
01005043	Modulator Kit	42.95
01005067	LPG To NG Conversion Kit	5.65
01005080	Test Component	41.98
01005085	Frame	76.29
01005088	LPG To NG Conversion Kit	15.53
01005090	NG TO LPG Conversion Kit	15.53
01005127	3Way Valve Overhaul kit	7.93
01005133	Frame assembly	66.75
01005134	Obsolete	67.31
01005135	Obsolete	82.83
01005137	Venting Plugs Kit	7.76
01005138	Frame	102.57
01005177	Microswitch Kit Rep 8468 & 8447	20.34
01005178	Microswitch rep 0182/0809/0811	18.65
01005180	Conversion KitLPG to NG	8.48
01005181	Obsolete	13.41
01005182	Conversion Kit to NG	8.48
01005183	Obsolete	13.41
01005193	NG to LPG conversion kit	16.94
01005195	LPG to NG conversion kit	13.15
01005217	LPG Conversion kit	33.99
01005225	Conversion Kit LPG to NG	15.68
01005234	Glass Kit	6.15
01005242	Spark Electrode Kit	40.78
01005243	Frame assembly	84.76
01005245	Exchanger Inplace of 1841 & 2381	180.81
01005246	Main Heat Exchanger rep 2378 & 1914	197.76
01005259	Frame Assembly	74.55
01005272	Air Pressure Switch Rep 7070/8195/9232	46.79
01005284	Conversion kit to NG	15.68
01005285	NG to LPG conversion kit	14.11
01005286	LPG to NG conversion kit	19.34
01005291	Condensing Unit	390.90
01005292	Connections kit	24.41
01005293	Venturi press tube kit	17.23
01005294	Frame	115.31
01005297	NG to LPG Cconversion kit	39.30
01005303	NG to LPG Conversion kit	15.12
01005306	Knob supp & gear wheel kit	8.79
01005323	Casing	113.11
01005348	Obsolete	10.02
01005362	Silicone tube kit	14.06
01005365	Frame assembly	112.36
01005366	Condensing exchanger assembly	339.59
01005369	Condensing exchanger assembly	363.85
01005389	NG to LPG Con Kit (4.7 jet)	9.11
01005390	Ng to Lpg con kit (5.0 jet)	9.11
01005403	Frame	61.60
01005404	Use 10027599	0.00
01005405	Use 20030209 for Venturi and 10027538 for Pito pipe	19.30
01005407	NG to LPG conversion kit	17.69
01005409	NG to LPG conversion kit	17.41
01005411	Condensing unit	373.65
01005415	Frame	64.43
01005441	Frame assembly	100.00
01005442	Hinge assembly	4.69
01005443	Condensing exchanger assembly	461.48
01005445	Frame Assembly	74.27
01005446	NG to LPG conversion kit (3.6)	14.77
01005447	NG to LPG conversion kit (4.7)	14.01
01005448	NG to LPG conversion kit (5.0 jet) Replaced 01005390	14.01
01005458	USE 10028537	77.88
01005464	LPG to NG conversion kit	7.22
01005465	LPG to NG Conversion kit (6.7)	8.60
01005466	LPG to NG Conversion kit (7.0 Jet)	8.60
01005468	Wiring box	14.69
01005469	Clips for anti frost resistors	22.33
01005481	Casing	62.31
01005482	Casing	62.31
01005497	Casing	67.81

SPARE PARTS

Part No.	Description	Price
01005500	NG to LPG conversion kit	9.49
0112	Obsolete	42.62
0113	Screw	0.35
0114	Obsolete	0.00
0117	Obsolete	1.06
0119	Obsolete	1.80
0139	3 Way Valve Tail Plate	18.74
0159	3 Way Valve Head Shaft	26.91
0182	Use 01005178	11.55
0184	Extension Shaft	26.91
020	Silicone Grease	12.82
021	Obsolete	9.33
0213	Obsolete	0.00
0215	Obsolete	0.00
0216	Front Seal	3.93
0218	Retaining Ring	4.68
0219	Shuttle	15.41
0220	Obsolete	0.33
0221	Washer	0.75
0225	Obsolete	46.11
0226	Diaphragm (6 Screw)	5.83
0292	Obsolete	0.00
029370	Use 029620	0.00
029373	Casing (Right Side)	54.06
029374	Casing (Left Side)	54.06
029375	Casing (Front)	51.83
029376	Fixing Plate	39.57
0296	Obsolete	0.00
029620	Casing (Top)	53.28
0298	Obsolete	0.43
0301	Obsolete	2.67
0309	Front Seal	10.76
03165	Thermal Store	357.86
0338	Obsolete	0.00
0340	Obsolete	0.00
0341	Fibre Washer	1.65
0349	O'Ring	0.30
0352	Obsolete	0.00
0353	Obsolete	0.40
0357	Obsolete	0.36
0358	Obsolete	0.36
0360	Obsolete	0.00
0361	Obsolete	8.97
0363	Obsolete	0.00
0364	Obsolete	2.39
0365	Obsolete	1.27
0366	Obsolete	1.03
0367	Obsolete	7.36
0371	Washer	1.19
0373	Obsolete	0.09
0378	Obsolete	0.00
0379	Obsolete	1.41
0380	Obsolete	2.07
0381	Venturi	2.23
0382	Obsolete	0.00
0394	NG Spring	1.82
0395	Obsolete	0.25
0401	Obsolete	87.83
0402	Obsolete	88.15
0407	Obsolete	8.97
04213	Use 04227 Insulation panel	12.95
04223	Use 04227	0.00
04227	Insulation Cover	13.01
0439	Auto Air Vent	9.42
0442	Air Box Clip	4.16
0443	Obsolete	45.17
0444	Obsolete	45.17
0445	Obsolete	45.17
0533	Obsolete	137.76
0536	Nylon Plate	8.61

## SPARE PARTS

Part No.	Description	Price
05420	Obsolete	15.36
05422	Obsolete	5.19
0549	Obsolete	8.97
0550	Obsolete	0.60
0552	Obsolete	1.59
0554	O'Ring	0.35
0555	Spring	0.90
0556	By-pass Bearer Plate	3.48
0557	Diaphragm	4.81
05589	Bar	15.75
0563	Obsolete	35.90
05660	Bracket	11.56
05800	Obsolete	11.56
05801	Elbow (102921)	16.24
05802	Elbow	14.96
05803	Tube	16.71
05808	Clip	6.75
0587	N.G Jets 1.35	0.40
0588	Obsolete	0.60
0594	N.Gas to LPG Conversion Kit	10.34
0598	Obsolete	104.57
0600	Obsolete	0.53
0602	Obsolete	55.44
0604	.77 jet	0.65
0615	Obsolete	91.29
0618	Obsolete	3.76
0620	Obsolete	8.97
0623	Obsolete	5.00
0628	Microswitch	14.14
0637	Obsolete	1.25
0642	Obsolete	15.97
0652	Obsolete	0.26
0658	Microswitch	14.64
0659	Obsolete	0.33
0661	Obsolete	29.93
066314	Obsolete	2.60
0666	Obsolete	3.78
0667	O'Ring	2.49
0680	Obsolete	117.66
0681	Obsolete	31.94
0704	O'Ring	1.09
0706	O'Ring	1.18
0709	Spring	0.70
0714	Diaphragm	3.96
0716	O'Ring	0.40
0717	Plate	3.97
0736	Obsolete	5.02
0737	Obsolete	0.00
0749	Obsolete	91.61
0750	Use 7625	0.00
077000	Obsolete	1.17
077085	Use 1859	0.00
077086	Use 1860	0.00
077939	Use 10027352	4.82
078125	Control Panel	26.36
078127	Wiring Harness	141.26
078128	Cover	30.68
078129	Control Panel Flap	15.60
078130	Linea max wiring (inc h/l stat) Use 078127	209.30
078139	Pressure Gauge	10.42
078140	Use 106326	471.33
078617	Thermostat - Linea Max/Meteor	11.76
0795	Washer	0.65
0803	Obsolete	8.97
0809	Use 01005178	6.99
0811	Use 01005178	7.48
0828	Single Microswitch	10.83
0851	Nut	3.43
0852	By-Pass Bobbin	2.57

## SPARE PARTS

Part No.	Description	Price
0855	Front Seal	5.54
0856	Front Seal Bush	6.18
0857	Spring	3.77
0858	Spindle Set	14.45
0862	Tail Plate	23.73
0863	3 Port Valve	14.39
0866	Obsolete	0.30
08665	Use 100618	0.00
0867	Front Seal	3.81
0869	Bearer Plate	5.43
0870	Diaphragm	4.41
0873	Non Return Nylon Body	28.47
0874	Obsolete	3.51
0875	Obsolete	4.86
0876	Obsolete	83.61
0877	Obsolete	1.47
0878	Obsolete	34.71
088031	Use 10021792	0.00
088042	Obsolete	47.22
088106	Pipe	42.01
088107	Pipe	26.70
088108	Pipe	31.11
088110	Pipe	23.92
088111	Pipe	21.69
088112	Pipe	35.05
088113	Gas Pipe	20.07
088114	Gas Pipe	20.33
088115	Pipe	28.95
088116	Pipe	21.96
088117	Pipe	15.32
088118	Pipe	20.28
088119	Brass Connection	8.70
088120	Use 1488	18.46
088122	Manifold	282.51
088124	Use 1786	10.79
088125	Valve	10.43
088126	Use 1788	11.99
088127	Use 1789	11.06
088128	Use 1790	7.06
088129	Use 1791	10.69
088131	Use 1793	3.23
088132	Filling Loop Pipe (Straight Tube)	16.91
088133	Use 1821	0.18
088134	Use 1822	0.23
088135	Valve	12.52
088136	Nut	0.75
088137	Use 1824	1.22
088140	Filling loop (2 right angles)	27.39
088153	Obsolete	12.46
088155	Heat Exchanger	138.82
088181	Expansion Vessel 10 Litre	84.76
088383	Flow Restrictor 18 litre	7.98
08948	Thermal Store Complete	392.78
0903	Obsolete	5.83
0934	Use 0594	6.99
0935	Obsolete	18.83
0940	Obsolete	124.31
0950	Ignition Box	141.26
0963	Use 01005272	32.13
0975	Pressure Switch	45.81
0978	Obsolete	49.70
099862	Use 10025074	0.00
099864	Use 1837	0.00
0CR106339	PIPE	0.00
10020041	11L Flow governor (Beige)	3.83
10020054	Obsolete	27.71
10020076	Expansion Vessel Pipe	10.52
10020104	Burner (replaces 5295)	77.09
10020216	Cover Assembly	48.91
10020217	Cover Assembly	44.91

SPARE PARTS

Part No.	Description	Price
10020223	Use 0225	16.62
10020265	NG Injector	4.01
10020305	Obsolete	11.39
10020308	Obsolete	0.69
10020330	Use 10022349	13.42
10020335	Manifold Top Rep 2904	7.91
10020430	Air box cover rep 2061	54.53
10020437	Use 10021792	0.00
10020438	Pump	152.55
10020439	Heating manifold	62.15
10020477	Use 10024558	26.48
10020478	Use 10024528	0.00
10020493	Main Printed Circuit Board	152.55
10020511	Burner Nat Gas	118.82
10020512	Obsolete	118.82
10020513	Main Heat Exchanger	163.86
10020514	Combustion Chamber Assembly	19.40
10020517	Front Insulation Panel for Combustion Chamber	7.19
10020518	Rear Insulation Panel for Combustion Chamber	7.47
10020519	Flow Pipe	10.92
10020520	Obsolete	62.58
10020521	Obsolete	14.64
10020522	Use 10024731	0.00
10020523	White Bracket	8.46
10020524	Lower Connection Plate	7.21
10020525	Obsolete	25.11
10020529	M3 to Heat thermistor, High limit stat, Burner stat & Analogue PD switch Wiring	39.59
10020530	M5 to DHW thermistor, Water pressure switch & DHW flow switch Wiring	19.73
10020597	Use 01005085 (Complete Frame)	14.10
10020599	Use 01005085 (Complete Frame)	14.10
10020601	Obsolete	56.25
10020603	Obsolete	13.47
10020604	Obsolete	6.34
10020605	Obsolete	6.34
10020607	PCB Cover	16.46
10020608	Cover Panel	2.99
10020609	Obsolete	2.87
10020610	LED Lens Tube	4.13
10020611	Pin	3.40
10020612	Pipe	17.90
10020613	Room sealed Chamber	77.62
10020615	M1 to High limit stat & Gas valve	37.86
10020616	M6 to Fan & PD switch	27.73
10020617	M4 to DHW thermistor, Heat thermistor, DHW Flow switch, Pressure switch & Modulator	52.12
10020621	Use 10022658	11.90
10020622	Pressure Gauge	17.26
10020624	Test Plate	1.31
10020625	Fumes testing connection screw	2.13
10020626	Stop Clip (individual)	0.55
10020627	Fumes Testing Connection Pipe	3.55
10020631	Obsolete	35.97
10020645	Obsolete	4.44
10020647	Use 10020893	2.22
10020648	Obsolete	16.65
10020649	Obsolete	5.26
10020661	Obsolete	14.35
10020664	Obsolete	23.33
10020666	Obsolete	8.97
10020667	Gas Pipe	11.20
10020668	Obsolete	3.57
10020669	On/Off Shaft	3.57
10020670	Temperature Shaft	3.57
10020674	Knob	4.01
10020676	LED Light Guide	4.49
10020679	Case - Aquanova	49.30
10020687	Use 10028996	0.00
10020688	Wiring Harness	90.81

SPARE PARTS

Part No.	Description	Price
10020707	Distribution Manifold	273.30
10020714	Pipe	13.47
10020754	Obsolete	3.87
10020781	Obsolete	16.25
10020793	Fan Assembly (Includes Venturi)	76.04
10020799	Obsolete	58.22
10020838	Use 20040675	62.80
10020839	Expansion Vessel	99.80
10020840	Expansion Vessel	79.11
10020857	Use 0225	16.62
10020871	Non-Return/Double-Check Valve	18.23
10020885	Obsolete	8.97
10020886	Obsolete	8.97
10020887	Obsolete	19.72
10020889	Air Pressure Switch	34.53
10020890	Pressure Switch	32.28
10020891	Obsolete	23.76
10020893	Obsolete	7.29
10020894	Obsolete	29.32
10020896	Option hanging bracket	5.55
10020897	Gas Cock	20.59
10020898	Safety Valve Outlet Tail	8.73
10020951	Obsolete	8.73
10020963	Use 10023603	0.00
10020966	Front Flap	15.06
10020967	Lower control panel right hand	6.57
10020968	Lower control panel left hand	6.57
10020973	Casing	53.85
10021005	Connection	18.23
10021006	Filling valve	8.43
10021021	Use 10025074	88.59
10021041	Flow Pipe	15.84
10021065	M3 to Heat thermistor, High limit stat, Burner stat & Analogue PD switch Wiring	40.59
10021080	Obsolete	2.50
10021108	M3 to Heat thermistor, High limit stat, Burner stat & Analogue PD switch Wiring	47.29
10021115	Obsolete	13.86
10021117	M9 to M2 ribbon cable from the main PCB to display PCB	6.93
10021120	Inst. Panel Back Pan	22.40
10021127	Instrument Panel	34.09
10021131	Upper Proof	11.62
10021231	Main Heat Exchanger	129.96
10021232	Main Heat Exchanger	152.55
10021233	Wiring Tray	9.35
10021235	Thermostat	6.71
10021236	M3 to Heat thermistor, High limit stat & PD switch	28.61
10021240	Flow Pipe	20.59
10021241	Obsolete	20.29
10021251	Manifold Extension	3.97
10021252	Air box bottom	57.99
10021253	Gas Valve	116.95
10021254	Gas Valve Outlet Pipe	10.31
10021255	Spark Electrode Inc Lead	12.66
10021256	Obsolete	13.47
10021257	Flow Pipe	14.26
10021258	Return Pipe	13.47
10021259	Flow Pipe	15.84
10021260	Mynute 10e Instrument Panel	35.15
10021262	Use 10029470	0.00
10021263	Selection Switch Shaft	1.79
10021264	T/Stat & Mode Knob	1.89
10021265	PCB Cover	13.47
10021266	Obsolete	4.44
10021267	Obsolete	2.87
10021268	J3 to Gas valve & water pressure switch and J4 to the Pump Wiring	38.69
10021269	Wiring J6 to Fan PD switch & High limit stat and J7 to Heat thermistor (top half)	50.13
10021270	Wiring J6 to Fan PD switch & High limit stat and J7 to Heat thermistor (bottom half)	28.61
10021271	Wiring Socket Mynute 10/14/20E	28.61

SPARE PARTS

Part No.	Description	Price
10021272	Ignition Transformer with Wires	12.37
10021273	Use 1783 and cut down	3.87
10021287	Mynute 14E Instrument Panel	35.15
10021288	Air Box bottom	57.99
10021289	Obsolete	12.37
10021290	Flow Pipe	13.79
10021291	Mynute 20E Instrument Panel	35.15
10021293	Distribution Manifold	271.18
10021294	Distribution Manifold	278.00
10021367	Heat Exchanger	208.01
10021398	Use 10025985	0.00
10021407	Wiring harness	20.16
10021419	Main heat exchanger	201.39
10021420	Flue Gas Flange	1.61
10021519	Obsolete	45.20
10021558	Glass	10.99
10021568	Use 10024779	19.40
10021570	Obsolete	32.15
10021702	33mm Flue Restrictor Ring (Mynute 1	1.62
10021726	Venturi for Fan	11.09
10021730	44mm Flue Restrictor Ring	1.62
10021792	Pump Rep 10020437	167.16
10021817	Spark Electrode Cable	23.33
10021821	Heating Distribution Manifold	70.58
10021847	Use 10024528	0.00
10021848	Use 10028891	0.00
10021849	PCB Cover Rep 1855	15.92
10021899	Connection	22.40
10021901	Non return valve	14.58
10021906	Pipe	16.63
10021947	M14 to Ignition PCB & Gas valve Wiring	38.13
10021949	Use 10027540	25.17
10021951	Instrument Panel	38.18
10021972	Fan Connection	18.26
10021973	Fumes testing conn pipe	3.47
10021984	Use 10029470	0.00
10021991	Use 10022659	0.00
10022000	Pipe - Replaces 2218	17.88
10022002	Flexible Pipe	16.46
10022015	Instrument Panel Replaces 1919	38.00
10022027	Use 10025891	0.00
10022029	Obsolete	37.25
10022112	M4 to Ignition PCB & Mod coil	12.86
10022125	Pipe	14.95
10022174	Use 10028890	0.00
10022229	Use 20078519	24.57
10022278	Obsolete	228.55
10022279	Obsolete	260.89
10022282	Obsolete	285.78
10022333	Eclipse 2 Wiring Harness	150.80
10022348	Use 10022349	28.22
10022349	DHW Actuator replaces 10020330	27.02
10022352	Use 10024731	135.00
10022355	Obsolete	171.89
10022388	Air box bottom	31.89
10022424	Shaft	1.12
10022441	Gas Valve	171.89
10022442	Gas Pipe	10.80
10022443	Obsolete	9.43
10022444	Obsolete	6.10
10022445	Obsolete	17.57
10022450	Air Conveyor	146.93
10022451	Gas Diaphragm	1.94
10022453	Main Burner Injector LPG	5.49
10022483	M1 to motorised valve wiring harness	14.43
10022491	Use 10028996	142.58
10022499	Connection (replaces 2260)	3.59
10022518	Venting plug	11.22
10022530	Pipe	2.34
10022533	Main Printed Circuit Board	204.57

SPARE PARTS

Part No.	Description	Price
10022556	Pressure switch condensing	19.40
10022570	Cap	4.69
10022614	Fumes test conn pipe	3.85
10022620	Side Insulation Panel for Combustion Chamber	7.07
10022621	Use 10022620	6.64
10022622	Fan flue connection	5.05
10022626	Pipe	15.51
10022658	Connection	14.44
10022659	Ignition Transformer rep 10021991	18.04
10022666	Actuator cable	15.12
10022667	Combustion cable	26.86
10022668	Gas valve cable	16.71
10022671	Bracket	2.50
10022672	Room Sealed Chamber	56.47
10022685	Eclipse 226 ESC PCB NG & LPG	365.94
10022686	Eclipse 226 ESS PCB NG & LPG	365.94
10022687	Eclipse 216 ESS PCB NG & LPG	365.94
10022688	Use 10022685	72.23
10022689	Use 10022686	0.00
10022690	Use 10022687	0.00
10022714	Flue draught diverter	34.32
10022715	Combustion chamber	20.79
10022718	Fan	86.77
10022726	Washer	2.45
10022727	NG burner	156.84
10022826	LED light guide	3.29
10022853	Fan (replaces 8891&1018)	197.76
10022859	Obsolete	16.46
10022860	Obsolete	0.00
10022867	Obsolete	5.49
10022868	Obsolete	4.39
10022980	NG burner	127.56
10022981	Hydraulic control cable	20.71
10023011	Cover	14.20
10023044	Bush (replaces 1863)	1.77
10023048	Fan to Flue Connector	9.89
10023051	Obsolete	31.58
10023065	Use 10020898	0.00
10023066	Terminal Block and wires	25.17
10023067	M5 to Water pressure switch wiring	13.93
10023073	Valve	13.08
10023095	Air Box Bottom	48.04
10023136	Power wiring harness	7.13
10023168	NG burner	88.95
10023169	Burner	75.73
10023181	Fan/Flue Connector (includes Venturis)	12.47
10023182	Flue elbow	12.05
10023183	Fan/Flue Connector (Includes Venturi's)	39.22
10023185	Venturi	1.31
10023195	Use 1848	4.24
10023198	Pipe	20.34
10023202	Pipe	13.87
10023203	Pipe	22.59
10023208	Pipe	24.13
10023209	Pipe	13.06
10023210	Pipe	15.18
10023211	Pipe	13.59
10023235	Vent Plug	3.48
10023238	Cover assembly	26.95
10023276	Obsolete	4.70
10023277	Obsolete	0.00
10023279	Use 10027792 (log book incl)	0.00
10023280	Flue Gas Flange	0.00
10023281	Instrument panel	48.44
10023297	Display PCB	118.23
10023299	Input Printed Circuit Board	81.18
10023347	Instrument Panel	38.27
10023431	Thermo-pressure gauge	27.44
10023432	Use 10026050	0.00
10023451	Gas Injector (Worgas)	3.66

SPARE PARTS

Part No.	Description	Price
10023476	Obsolete	20.06
10023477	Obsolete	17.10
10023478	Use 2033	0.00
10023479	Main Printed Circuit Board	365.94
10023482	Domestic Heat Exchanger	78.91
10023483	Obsolete	4.92
10023486	Roomsealed Chamber	78.91
10023493	Obsolete	12.83
10023495	Siphon	51.62
10023530	Use 10026272	0.00
10023531	Siphon Plug	6.28
10023532	Locking Pin	11.76
10023533	O Ring	1.10
10023537	Printed Circuit Board - Green	192.99
10023549	Main Printed Circuit Board	419.56
10023566	Heating Flow Cock/Service Valve	26.88
10023567	C-Water inlet valve/Stop Cock - Screws into non return valve	26.50
10023568	Supply inlet valve	18.68
10023569	Non-Return/Double-Check Valve	18.40
10023570	Flexible Pipe/Filling Loop	19.93
10023571	Obsolete	4.47
10023573	Obsolete	13.34
10023574	Obsolete	27.21
10023575	Obsolete	32.31
10023576	Pipe	31.69
10023577	Pipe	31.37
10023578	Obsolete	33.92
10023579	Pipe	27.21
10023580	Connection Pipe	15.30
10023582	Membrane Keypad	47.05
10023583	Obsolete	3.14
10023584	Obsolete	12.94
10023585	Wiring Harness	172.53
10023586	Flat Cable (Hydra)	64.17
10023587	Wiring M6 to DHW Thermistor (NTC3)	8.70
10023589	Obsolete	145.77
10023603	Flexible Expansion Pipe	16.79
10023643	S.Valve outlet tail repl 1792	14.91
10023651	Use 20005146	0.00
10023661	Main heat exchanger Rep 20005151	220.36
10023681	Cover	4.82
10023697	Obsolete	20.36
10023699	Washer	0.45
10023763	Display board	61.75
10023764	Use 10024393	156.84
10023772	Obsolete	16.86
10023774	Obsolete	16.86
10023798	Burner	60.39
10023799	Burner	43.44
10023805	Metal Air Box Hole Cap	3.14
10023810	Door Panel	10.63
10023812	Obsolete	18.04
10023816	LED Light Guide	2.52
10023817	Use 10030336	3.29
10023818	Use 10030335	3.29
10023822	Case	78.42
10023823	Compact 28 Case	86.27
10023834	Burner	118.27
10023836	Use 20020377	2.26
10023838	CN8 to Primary NTC,Air Press switch,High limit stat & CN4 to Fan	45.58
10023840	CN1 to M3 external connections block	39.22
10023878	Main Heat exchanger	254.03
10023891	Membrane keypad	56.50
10023892	LED Light guide	2.24
10023901	Burner	69.79
10023902	Main burner injector manifold	52.47
10023904	Air box bottom	71.62
10023907	Fan Assembly Includes Venturi	117.62

SPARE PARTS

Part No.	Description	Price
10023908	Air Pressure Switch	39.99
10023909	Rear Insulation Panel for Combustion Chamber	5.02
10023910	Front Insulation Panel for Combustion Chamber	6.58
10023928	Cover Assembly	33.72
10023931	Roomsealed Chamber	73.71
10023933	Use 20001126 - Will need to change all fascia components to fit new version	0.00
10023935	Clock bezel for 10028496 & 10023938	3.77
10023936	Use 10030336	0.00
10023937	Control Knob - Will need to change all fascia components to fit new version	2.21
10023938	Use 10028496	0.00
10023939	CN5 to Gas valve, CN2 to Pump & CN9 to Water pressure switch,Modulator,DHW thermistor & DHW Flow switch	45.49
10023940	M6 (Conections block) to Clock	9.07
10023942	Use 10027793 (log book incl)	0.00
10023945	Roomsealed Chamber	123.12
10023946	Heat exchanger	344.44
10023947	Pipe	19.61
10023948	Flexiible Pipe	18.04
10023949	Pipe	29.36
10023950	Pipe	14.11
10023996	Gas Pipe	13.18
10023997	Obsolete	10.20
10024019	Press Gauge (Old Type) Sits Behind Control Panel	12.78
10024026	Clamp	4.43
10024035	Fan	143.12
10024037	Use 20020309	2.26
10024042	46mm Restrictor Ring	2.26
10024043	47mm Restrictor Ring	2.26
10024044	49mm Restrictor Ring	2.26
10024067	CN8 to Heat thermistor, Pressure Differential switch, DHW Flow switch & CN4 to the Fan	47.84
10024112	Siphon	36.73
10024120	M3 to Heat thermistor, High limit stat, Burner stat & PD switch (Also comes M1 to condense sensor & M12 to fan)	45.77
10024121	Use 20006403	0.00
10024125	Hood Assembly	32.17
10024126	Clamp	14.95
10024129	Short Pipe from Condense Unit	21.11
10024130	Pipe	15.41
10024131	Pipe	14.11
10024132	Use 20068881	19.52
10024133	Siphon plug	3.89
10024136	Retarder	54.00
10024137	Fan flue connection	30.89
10024140	Use 10025212	34.71
10024141	O ring	13.35
10024142	O ring	0.55
10024143	O ring	9.23
10024157	Wiring harness	24.48
10024166	Air box side	20.15
10024173	Use 10024976	16.41
10024191	Pressure tube	1.23
10024230	Fan	247.74
10024295	Use 20015932	32.32
10024301	Heat exchanger	188.16
10024310	Flue Hood assembly	17.38
10024311	Short Pipe from Condense Unit	20.30
10024312	Pipe	16.18
10024313	Pipe	13.35
10024314	Wiring harness	45.77
10024323	Obsolete	5.88
10024326	Use 10024731	182.69
10024336	Clip	20.30
10024342	M5 to DHW thermistor, Water pressure switch & DHW flow switch	16.71
10024364	Plate (replaces S10013)	7.15
10024384	Use 1817	5.71
10024390	Main Printed Circuit Board	239.40
10024392	X1,X2,X3,X4 Near Full Loom	254.54



SPARE PARTS

Part No.	Description	Price
10024393	X1,X2 & X3 Near full loom	130.39
10024440	Use 20068882 Plastic Pipe	20.30
10024449	Use 20081537	0.00
10024462	9L Flow governor (Orange)	5.47
10024463	NG Burner	105.00
10024464	Obsolete	90.00
10024466	M4 to Ignition PCB & Gas valve Wiring	13.53
10024467	Use 10027794	0.00
10024468	Linea 726/730/735 user man	0.00
10024473	Hood Assembly	28.30
10024498	Instrument Panel	17.55
10024508	Door panel rep 10024530	13.35
10024518	Pipe	21.89
10024519	Pipe	15.17
10024520	Pipe	15.69
10024521	Use 20068884	21.11
10024522	Wiring harness	45.77
10024524	Ng burner	101.57
10024526	Fan	118.66
10024528	Main Printed Circuit Board (Rep 10021847) & 10020907	126.98
10024530	Use 10024508	11.27
10024554	Use 20028963	0.00
10024558	Control Printed circuit board - rep 10020477	66.83
10024573	Obsolete	150.43
10024577	Fan	152.55
10024578	Main heat exchanger	181.63
10024579	Main heat exchanger	220.36
10024580	Main heat exchanger	216.04
10024627	Domestic Heat Exchanger	84.76
10024640	Use 10030114	0.00
10024641	By-pass casing	12.17
10024642	Bypass body	9.53
10024643	Cover for by-pass assembly	8.90
10024645	Automatic by-pass plug	3.76
10024646	Discharge Valve with O ring (10025064) & Washer (10025066)	6.28
10024647	Connection	3.10
10024662	Expansion vessel	119.29
10024668	Pipe	24.22
10024669	Roomsealed chamber	56.50
10024672	Pipe	22.94
10024673	Pipe	37.00
10024676	Front cover	21.02
10024680	LED light guide	14.52
10024681	Gear wheel	1.66
10024682	Gear wheel	1.73
10024686	Hole cover	1.37
10024687	Hole cover	2.21
10024688	Obsolete	2.21
10024689	Wiring harness	40.87
10024692	Casing kit for Rain boiler	119.29
10024710	Limit thermostat	9.59
10024718	Spreader bar	6.65
10024731	Printed circuit board	225.69
10024740	Hydraulic control cable	14.65
10024742	Burner injector manifold	44.61
10024751	Combustion chamber	36.60
10024752	Burner (NG)	81.36
10024756	Instrument panel	33.04
10024757	Front flap	14.89
10024759	Use 10027801	0.00
10024779	Cover for Air Box rep 10021568	19.40
10024794	Combustion Chamber Front (Metal)	7.68
10024799	Pipe	15.34
10024800	Pipe	15.34
10024801	Pipe	14.27
10024802	Pipe	21.61
10024957	Use 10027571	0.00
10024958	Locking Pin	0.80
10024976	Rear cover	10.25

SPARE PARTS

Part No.	Description	Price
10024982	Pipe	7.04
10024983	Pipe	8.53
10024985	Nipple	9.39
10024986	Locking Pin	0.80
10024987	Flow governor (Blue)	5.09
10024988	O ring	0.65
10025055	Use 20044364	17.96
10025056	Non return valve	4.16
10025057	Pipe	8.60
10025059	Connection	9.39
10025061	Use 10027351	9.07
10025062	Locking Pin	0.80
10025063	Locking Pin	0.80
10025064	O ring	4.31
10025065	O ring	1.51
10025066	Washer	2.67
10025067	O ring	2.11
10025068	Silicone Tube	2.11
10025074	Use 20035533 (R106332) (R102866)	126.24
10025080	Flow governor (Red)	5.29
10025188	Flexible pipe for Expansion vessel	12.56
10025212	Condensing level detector	33.54
10025270	NG Burner	47.72
10025271	Main burner injector manifold	37.32
10025304	Actuator/Motorised valve	51.40
10025305	3 way valve cartridge	54.31
10025312	Electric connections kit	99.24
10025340	Printed circuit board - Green	189.14
10025348	Pressure gauge	7.07
10025368	Wiring harness	62.88
10025370	CN4 to fan & CN8 to NTC, Limit stat & flue press switch	38.18
10025449	Curved Locking Pin	1.94
10025450	Fixing fork wrench	12.92
10025461	Injector 4.8	8.81
10025468	Fan Baffle Compact 25HE	8.61
10025485	Auto air vent bottle (Pump)	15.12
10025647	Fan Baffle	8.61
10025726	Use 20001140	0.00
10025728	Sabre 24 casing	102.99
10025731	Fixing flange	105.93
10025733	Water supply stop cock	18.93
10025739	Sabre 28 casing	102.99
10025833	Obsolete	9.65
10025839	Pipe	15.29
10025840	Pipe	10.21
10025842	Front Panel	16.80
10025891	Spark / ignition electrode with lead	15.34
10025911	Main Printed Circuit Board	234.65
10025934	Hood assembly	22.63
10025935	Combustion chamber	12.64
10025938	Fan	142.39
10025941	Combustion - Fan cable	52.65
10025961	Obsolete	15.12
10025962	Obsolete	17.64
10025963	Obsolete	7.40
10025985	Spark / ignition electrode with lead Rep 10021398	13.73
10026008	Fan Baffle Compact 29HE	8.61
10026031	Ignition transformer TR6 with wires	9.62
10026041	Flow governor (Green)	4.84
10026042	Flow governor (Green)	4.84
10026043	Flow governor (White)	5.09
10026044	Flow governor (Yellow)	3.94
10026045	Flow governor (Beige)	3.94
10026046	Flow governor (Pink)	4.84
10026050	Thermo-Pressure gauge	30.64
10026071	Obsolete	34.92
10026097	Plug	0.00
10026098	CN5 to Gas Valve, CN9 to water pressure switch & modulator & CN2 to Pump Wiring	26.07
10026102	Burner	36.08

SPARE PARTS

Part No.	Description	Price
10026116	Cover	31.34
10026164	Case	77.20
10026179	Casing - Compact 29HE / Procombi 100HE	77.20
10026193	Pipe	13.18
10026194	Use 20092620	4.33
10026203	Casing - Sabre 25 HE	66.57
10026228	Pipe	15.81
10026230	Roomsealed chamber cover	34.92
10026231	Roomsealed chamber side	26.17
10026232	Test Point Cap	2.15
10026236	Transformer with wires that connect onto CN01	73.41
10026237	Use 20002969	39.84
10026238	Use 10029365	133.50
10026239	Cover assembly	25.90
10026240	Use 20007052	0.00
10026241	Casing	104.21
10026247	Pressure gauge	19.03
10026264	Pipe	15.29
10026265	Obsolete	14.09
10026266	Obsolete	38.44
10026267	Pipe (Rep 10027317)	22.94
10026268	Obsolete	0.00
10026269	Clip	0.80
10026272	Flexible Pipe	6.76
10026273	Use 20081926	0.00
10026275	Use 10029306	0.00
10026309	Use 10028420	0.00
10026310	Use 20007053	0.00
10026311	Use 10028421	12.35
10026316	Sensing electrode	10.02
10026317	Use 10028204	17.05
10026318	Gas pipe	13.02
10026322	Washer	17.64
10026323	Washer	10.57
10026324	O ring	2.30
10026325	O ring	2.05
10026328	Glass assembly	6.76
10026330	Wiring J15 & CN3 to M10 connector (external sensor/U.H.T)	32.54
10026331	J9 to Motorised Valve (With the second pump connection for underfloor htg etc)	14.36
10026332	CN02 to Fan & CN1 to Condense sensor,Flow thermistor & return thermistor (now with J12 & condense sensor)	38.82
10026333	J3 Mains terminal block & wires	25.46
10026335	Obsolete	25.46
10026336	J10 to Gas valve cable	19.51
10026337	CN01 to Fan transformer	20.37
10026338	J8 to Pump Wiring Harness	13.20
10026339	Use 10028363	0.00
10026341	Ribbon Cable	14.06
10026342	Cable Connector	6.32
10026345	Washer	5.58
10026346	Silicone pipe	0.50
10026355	Combustion chamber cover	6.08
10026359	Venturi	10.63
10026366	Washer	4.41
10026372	Hood Assembly	12.92
10026384	Cover	27.29
10026404	Printed Circuit Board (Small)	0.00
10026405	Obsolete	28.00
10026406	Combustion chamber	13.43
10026407	Fan	143.83
10026408	Combustion - Fan cable	52.65
10026409	Use 10027795 (log book incl)	0.00
10026412	Obsolete	15.38
10026413	Obsolete	18.23
10026422	Pipe	13.43
10026423	Pipe	13.43
10026424	Pipe	12.40
10026429	Open therm ribbon Cable	36.59
10026475	Use 10027599	0.00
10026491	Use 10028202 (expl diag incl)	0.00
10026494	O ring	0.60
10026506	Heating manifold	67.19

SPARE PARTS

Part No.	Description	Price
10026507	Valve	59.63
10026508	Htg manifold & cartridge (3 P V kit)	62.83
10026545	Pipe	4.23
10026547	Linea HE ht exch (Special)	116.58
10026548	Use 10028537	0.00
10026552	Pipe	14.00
10026558	TSC1 (ignition transformer) to Spark electrode Wiring	8.79
10026671	Fixing Flange	3.21
10026686	Connection band CN4 to J1 on display PCB	6.60
10026698	Use 10028203	17.64
10026701	Obsolete	44.76
10026703	Gas Pipe	25.03
10026721	Thermostat	12.64
10026771	Use 10026098	0.00
10026791	Clamp	1.66
10026796	Fan Gasket	5.85
10026866	Casing	129.12
10026933	Block with combustion analysis check	7.50
10026982	Limit stat	7.88
10026983	Use 10027360	3.00
10027015	Use 20000773	23.53
10027040	Flexible pipe	4.67
10027051	Fan	234.93
10027089	Tryton	8.79
10027132	Use 10028142	0.00
10027135	Pressure gauge	17.64
10027146	Pipe	23.74
10027158	CN2 to W Pressure sensor, DHW Flow switch, DHW temperature wiring	26.43
10027159	LPG Injector (3.6)	4.91
10027161	LPG to NG jet (6.7)	6.49
10027162	NG jet (7.0)	6.49
10027175	Air box bottom	101.33
10027187	Use 20039202	145.34
10027190	Use 10028405	0.00
10027191	Pipe	6.15
10027192	Flexible pipe	5.58
10027193	Washer	0.90
10027196	Use 10028206	17.91
10027200	Driver PCB	42.57
10027258	Pump	129.96
10027316	Fan	140.15
10027317	Use 10026267	22.94
10027318	Use 20020179	0.00
10027320	Pipe	20.28
10027321	Use 10029458	0.00
10027335	Pressure reducing valve	48.62
10027343	3 way htng man & cartridge	59.91
10027351	Thermistor/NTC Sensor	6.33
10027352	Thermistor/NTC Sensor (20004978)	10.90
10027360	J12 Link wire between heat exchanger thermostat & flow overheat stat	2.95
10027370	Use 20002906	0.00
10027408	Mixer	43.00
10027410	Insulation kit	2.33
10027502	Compact HE 25/29 inst man	0.00
10027533	Air Box Bottom	47.36
10027535	Condense Pressure switch	21.18
10027536	NG burner	88.31
10027537	Gas pipe	13.41
10027538	Pitot pipe from venturi kit 01005405	2.26
10027540	Condense Unit Washer	7.23
10027541	Pipe	34.58
10027542	Pipe	21.99
10027543	Use 20066456	20.93
10027544	Pipe	10.38
10027545	Flexible pipe	7.23
10027546	Siphon	52.26
10027547	Use 20001102	67.03
10027549	Use 20001101	20.37
10027553	88mm Restrictor ring (100-88)	0.80

SPARE PARTS

Part No.	Description	Price
10027554	40mm Restrictor ring (80-40)	0.80
10027555	45mm Restrictor ring (80-45)	0.80
10027558	Wiring harness	65.13
10027559	CN4 to Fan & CN8 to Heat Thermistor, PD switch & high limit stat wiring	42.08
10027562	Air box bottom	45.16
10027564	Use 5317	101.61
10027566	Pipe	30.57
10027567	Pipe	20.93
10027568	Use 20066460	21.99
10027569	82,5mm Restrictor ring (100-84)	0.80
10027571	Pump	152.55
10027578	Cover	22.85
10027580	Sabre HE combi user guide	0.00
10027581	Use 10028019	0.00
10027599	Cover assembly	16.36
10027620	Spark/Ignition electrode	16.95
10027685	Connections cover	31.44
10027709	Pipe	28.22
10027712	Use 20001141	14.46
10027713	Wiring harness	33.63
10027739	Gas pipe	26.80
10027742	Obsolete	34.41
10027757	Locking Pin	0.60
10027758	Hydraulic control cable	35.69
10027768	Heating manifold & Cartridge	51.07
10027806	3/4" gas cock	24.01
10027807	Obsolete	24.71
10027841	Pipe	9.17
10027845	Flange Ø 42	0.75
10027864	Spark/ignition electrode	24.20
10027896	Pipe	11.04
10027898	M12 to Fan & M3 to Heat thermistor, high limit stat and Air pressure switch	41.71
10027913	CN4 to Fan & CN8 to Heat Thermistor, PD switch & high limit stat wiring	19.16
10027949	Front Panel	139.82
10027952	Wiring harness	10.21
10027953	Wiring harness	13.18
10027975	Pipe	35.75
10027990	Pipe	28.06
10028002	White Caps	1.08
10028011	Air Box Bottom	50.25
10028013	NG Burner	82.32
10028014	Gas pipe	20.46
10028015	Use 20066463	20.46
10028016	Casing Sabre 35 HE	121.29
10028025	Case - Compact 35HE	110.20
10028045	Compact HE inst man (25,29,35)	0.00
10028141	Water Pressure switch	14.27
10028142	Pressure Transducer Rep 10027132	16.15
10028155	Pipe	25.14
10028203	Gas pipe	11.73
10028204	Pipe	90.05
10028206	Gas Pipe Replaced 10027196	18.85
10028263	Use 20019769	85.47
10028264	Use 20020179	79.30
10028341	Room sealed chamber	39.55
10028345	Cover for air box	39.00
10028363	Wiring harness/condense sensor Rep 10026339	15.56
10028393	Obsolete	122.77
10028405	Siphon	43.84
10028415	Heating manifold	61.85
10028420	Air gas conveyor	40.33
10028421	Flue drain connection Replaced 10026311	7.80
10028422	Flame detection electrode	17.22
10028423	Gas pipe	11.80
10028424	Use 10030381	18.53
10028425	Tryton	11.04
10028426	Washer	6.98
10028427	Use 10028904	11.80
10028428	Pipe	14.27
10028429	Use 10029515	69.07

SPARE PARTS

Part No.	Description	Price
10028430	Air bleeding connection Pipe	9.17
10028431	Cock	7.54
10028432	Casing	126.07
10028447	Air box bottom	51.71
10028448	Casing	126.07
10028451	Casing - Unica32HE & 36HE	126.07
10028454	PCB	99.52
10028456	Fan	251.99
10028467	Electrode	9.16
10028474	Use 20001103	0.00
10028475	Knob	3.23
10028476	Knob	3.23
10028477	Timer carrier	4.80
10028479	Room sealed chamber	56.50
10028482	Spark Electrode Cable	12.80
10028492	Pipe	19.89
10028493	Pipe	11.56
10028494	Pipe	22.85
10028495	Pipe	16.92
10028496	Mechanical Timer (Rep 10023938)	65.07
10028503	Blanking plate	1.06
10028506	Pipe	23.36
10028515	Use 20019766	9.93
10028516	Use 20019766	9.93
10028517	Pipe	6.93
10028531	CN3 to Motorised Valve, CN2 to Pump, CN5 to Gas Valve & Solenoids & CN9 to Pres Switch, Condense Pres Switch, Modulator, DHW Thermistor & DHW FloSwitch	65.32
10028533	Tube	6.89
10028535	Expansion vessel	67.19
10028536	Use 20008306	0.00
10028537	Burner (Rep 01005458 and 10026548)	129.03
10028538	Use 20039202	134.40
10028539	Condensing pipe	8.86
10028540	Condensing pipe	4.32
10028551	Instrument panel	25.55
10028553	Use 10030136	17.76
10028554	Cover assembly	20.73
10028557	LED light guide	3.23
10028558	Use 20008307	0.00
10028559	Knob assembly	4.58
10028593	X2 to M4 to open therm plus connection & external sensor Wiring	17.76
10028594	CN5 to Pump Wiring harness	14.77
10028595	X4 to Fan Signal Control, FA2 to Condense Sensor & Sense Electrode	43.00
10028596	Wiring CN1 to M5 room thermostat & M3 terminal block	36.86
10028597	Earth connection	2.03
10028598	Wiring X16 to Water pressure switch	6.98
10028599	Wiring CN3 to Gas valve & solenoids	17.76
10028600	Wiring CN1 to Fan power supply, CN2 to ign transformer	32.79
10028601	X9 to M3a Terminal Strip, Return NTC & Flow	43.24
10028603	Pipe	10.46
10028617	Pipe	18.85
10028618	Use 10028906	27.43
10028620	Gas pipe	12.08
10028623	Use 20007053	0.00
10028625	Use 10028905	28.47
10028626	Wiring harness	32.54
10028628	Gas pipe	12.08
10028629	Gas pipe	12.40
10028631	Pipe	25.82
10028632	Instrument panel	28.21
10028633	Wiring CN5 to Pump & 3 way motor	29.06
10028634	Wiring X16 to Water pressure switch, DHW flow switch & DHW temp thermistor	19.36
10028642	Burner	113.63
10028643	Pipe	24.20
10028747	Pipe	30.32
10028809	Frame assembly	171.84
10028811	Expansion vessel	68.15
10028812	Distributor	75.95
10028813	Gas pipe	12.51
10028814	Gas pipe	10.31
10028815	Gas pipe	13.47

SPARE PARTS

Part No.	Description	Price
10028816	Pump 15-60	156.06
10028817	Pipe	33.27
10028818	Pipe	14.24
10028819	Pipe	8.72
10028820	Pipe	14.20
10028824	Wiring	21.08
10028825	Wiring CN2 To DHW NTC, DHW Flowswitch, Water pressure sensor	23.64
10028826	Wiring CN1 TO NTC1, NTC2, Condence sensor, J12 to overheat stats, CN02 to fan	32.63
10028827	Wiring Mains terminal block to J3 & wires	27.97
10028828	Wiring CN2 To DHW NTC, DHW Flowswitch, Water pressure sensor	19.45
10028829	Wiring J10 To Gas Valve	17.70
10028831	Wiring	8.66
10028834	Frost protection resistors	86.25
10028839	Door panel	16.02
10028865	Combustion cable	44.47
10028868	Gas pipe	12.71
10028869	Gas pipe	9.35
10028880	REC07 inteface PCB	29.52
10028890	Flame control ignition module (Rep 10022174)	100.67
10028891	Ignition module (Rep 10021848)	84.24
10028894	Quick primer pressure gauge	14.03
10028899	Buner NG	68.88
10028902	Case clips	3.79
10028903	Case clips	3.79
10028904	Pipe	18.92
10028905	Pipe	24.92
10028906	Pipe	24.48
10028996	Use 20028963	169.29
10029007	Pipe	14.43
10029032	Wiring M2 to External Pump	7.46
10029105	Water gauge carrier	6.57
10029209	Injector (5.7)	3.39
10029212	Use 20007052	0.00
10029279	Expansion vessel	88.45
10029296	Pipe	37.20
10029305	Gas pipe	12.03
10029306	Auto air vent (Brass)	16.18
10029365	Display Panel - Replaced 10026238	144.84
10029415	Instrument panel	29.82
10029417	Door panel	11.62
10029420	Printed circuit board	71.77
10029421	Pressure gauge (New Type) - Hole Completely Cut Out	21.72
10029422	Actuator cable	11.62
10029423	Pump cable	13.65
10029424	Wiring harness	31.08
10029425	Gas valve cable	23.75
10029426	Combustion cable	44.47
10029427	Control cable	20.21
10029429	Combustion cable	44.97
10029442	Pipe	35.89
10029443	Pipe	36.39
10029457	Use 20019769	78.92
10029458	Use 20020179	78.78
10029470	Main Printed circuit board	122.41
10029515	Use 20020182	63.18
10029526	Connection	8.60
10029574	Blanking plate	1.76
10029585	Badge	3.38
10029590	Pipe	12.23
10029591	Pipe	11.53
10029592	Pipe	8.63
10029607	Gas pipe	9.86
10029715	Use 20081926	0.00
10029717	Main Printed Circuit Board	153.13
10029757	Heating Cock 28mm	30.94
10029823	Glass flange assembly	7.50
10029850	Pipe	58.85
10029961	Pipe	18.97

SPARE PARTS

Part No.	Description	Price
10029963	Gas pipe	9.48
10029965	Safety valve P & T	50.73
10029967	Fixing flange	9.29
10029968	Nipple	10.78
10029969	Boiler outlet tube	31.51
10029975	Pipe	26.38
10030114	Connection	8.80
10030117	NG burner	66.61
10030123	Pipe	17.90
10030124	Knob	2.80
10030125	Knob assembly	2.80
10030126	Door panel	15.79
10030136	Door flap	3.60
10030214	Support	2.94
10030255	Door panel	9.19
10030311	Hanging bracket	8.33
10030335	Temperature control knob	1.98
10030336	Selector Knob - Will need to change all fascia components to fit new version	1.79
10030381	Gas pipe rep 10028424	36.16
10030433	Dual Printed circuit board - Red	192.99
10030440	Pipe	20.00
10030505	Dual Printed circuit board - Red	255.12
10030506	Test point plugs	3.06
1006	Bolt head Screw	1.38
100618	Auto vent valve Rep 08665	13.24
1007040	Flexible pipe	4.12
100940	Closing pin	1.16
1011	Obsolete	22.95
1012	Obsolete	10.83
1013	Obsolete	28.15
1014	Use 1191	0.00
1016	Insulation Panel	2.71
1018	Use 10022853	118.87
1019	Burner Gasket	26.80
1022	Washer Ring	0.25
102402	Use 1859	0.00
102403	Use 1860	0.00
1028	Obsolete	166.33
1029	Obsolete	166.33
102921	Linea Max HE Flue Tee	22.61
102965	System return pipe	20.73
103277	Closing pin	0.80
1033	Cover for condensing assembly	163.86
1035	Front Panel for Air Box	38.81
103539	Key	0.80
1037	Obsolete	11.29
1041	Obsolete	6.17
104199	Use 078617	9.58
1042	Obsolete	564.82
104268	Non Return Valve	19.67
1044	Electrode	15.84
1045	Pump Cable	15.60
104654	Outside probe	26.15
1048	Transformer	59.20
1050	Use 10020438	0.00
105852	Solar Grey(Cylinder) Probe SPF 1000	107.63
105898	Main wiring	47.36
105899	Master wiring	62.45
105900	Slave wiring	130.13
105901	Ignition cable	78.07
105902	Bend	28.17
105903	Burner head silicone gasket	10.41
105904	Use 20102262	12.84
105906	Green on off switch (oblong)	10.41
105907	Round green on off switch	13.02
105908	Gasket/screw kit for venturi	34.44
105910	Flue gas analysis test point with plug (Rep B81515)	62.45
105911	Bulkhead connector for the condensate	14.70
105912	Cock	20.02
105913	Premix Burner	226.01

SPARE PARTS

Part No.	Description	Price
105914	Ignition/detection electrode	69.96
105915	FE flange for exchanger pipe	15.61
105916	Silicone gasket for ignition plu	10.41
105917	Viton gasket	40.90
105918	Use 20049127	902.92
105919	Condensate drain trap quick fit	53.81
105920	Pijnenburg master board	520.50
105921	Use 107934	0.00
105922	Use 7236	15.61
105924	Temperature probe	39.83
105926	Thermostat	10.41
105930	Air vent valve	13.02
105931	Fan	399.75
105932	Venturi	158.85
105965	Upper Front Panel	91.21
105966	Front Panel	344.40
105967	Front panel	172.20
105968	Right Panel	119.47
105969	Left panel	86.10
105970	Gas Pipe	72.65
105971	Gas Inlet Pipe Condexa Pro	65.54
105973	Instrument Panel	52.13
105974	Panel & Cover Slave	57.31
105975	Top Rear	104.94
106250	Gas valve	297.79
106252	Pressure diff switch	165.00
106254	Serial cables	30.51
106277	Detector	65.36
106323	Use 10022556	25.40
106324	Condense drain pipe	41.13
106325	Use 10027546	64.87
106326	Control Panel Complete	471.33
106327	Management board	301.52
106328	Complete wiring	188.21
106330	Use 10023568 (Small V) & 10023566 (large V)	0.00
106331	Use 10025188	29.67
106333	Use 2573	122.99
106334	Instrument panel cover	20.81
106335	Wiring	9.09
106336	Condensate drain pipe	14.77
106337	Pipe	136.65
106338	Safety valve	68.24
106339	Pipe	18.94
106368	Pipe	26.91
106513	Collector & tank probe	36.49
106791	Master board (Incorrect Board use R107584)	434.65
106792	Master Box	55.69
106847	Instrument Panel	122.69
106849	Digital display frame assembly	50.85
107180	Condexa pro lpg con kit 2 washers 6.5 and 6.75	16.15
107393	Ignition/detection electrode	79.65
107428	Use 105919	53.81
107529	Use 10023566 (L) & 10023568 (S)	0.00
107584	Master board Replaced R106791	434.65
107934	Pijnenburgh slave board	475.63
1095	Wiring M3 to thermistor, High limit stat & Air pressure switch	40.32
11300	Screw	3.23
11304	Obsolete	8.74
11305	Use 1890	2.48
11322	Obsolete	5.05
1133	Obsolete	77.62
1140	Use 7315	2.73
1141	Fan Flue Connection	10.47
1191	Siphon	17.90
1192	Siphon pipe	7.93
1193	Front Insulation Panel	20.51
1194	NTC Sensor	10.85
1195	Main burner support	15.74
1196	Main Burner	178.93
131ZEB3A	Obsolete	12.95

SPARE PARTS

Part No.	Description	Price
1321	Flow governor (Green)	2.95
1322	Flow governor	2.28
1329	Expansion vessel	45.19
1439	Pressure Switch	103.51
1440	Bracket	14.74
1453	Baffle	45.42
1457	Silicone tube (1 Metre)	1.66
1466	Flow governor (Blank)	1.42
1488	Flow Switch / Actuator	27.62
1489	Water filter	2.26
1490	Use 1488	0.00
1493	Input P.C.B.	35.50
1494	Obsolete	178.92
1495	Obsolete	178.92
1498	Front Flap (New Linea)	16.37
1531	Use 10020216	0.00
1547	3 Core Fly Lead	6.56
1548	Cover for Air Box	33.26
1549	Air Chamber Side Panel Rep 1878/48928	20.59
1552	Valve For DHW Bypass	6.32
1592	3/4" Heat water cock	12.81
1604	Flow governor (White)	3.39
1606	Obsolete	58.21
1607	Obsolete	58.21
1631	Use 8460	20.85
1639	Obsolete	66.54
1642	Obsolete	2.71
1704	Obsolete	0.81
1730	Obsolete	286.85
1731	Obsolete	286.85
1732	Obsolete	286.85
1733	Obsolete	286.85
1734	Heating By-pass Valve	6.32
1749	Water Stop Cock	20.38
1777	Obsolete	13.58
1778	Obsolete	13.58
1779	Use 10022125	12.45
1780	Internal clock wire	15.13
1781	Obsolete	3.76
1783	Hanging bracket	4.41
1784	Obsolete	4.00
1785	Obsolete	4.22
1786	C-Water inlet valve/Stop Cock - Stands alone	19.49
1787	Gas Cock	13.24
1788	Heating Flow Cock/Service Valve	20.96
1789	Heating Cock 22mm (Washers are 5237)	19.49
1790	Connection Rep 088128	12.53
1791	Double Non Return Valve	16.46
1792	Use 10023643	9.63
1793	Brass Nut Rep 088131	5.86
1794	Flexible Pipe/Filling Loop	23.29
1806	Safety Valve (Push Fit)	13.86
1806G	Obsolete	3.39
1807	Use 20007057	4.81
1816	Obsolete	388.11
1817	Hanging bracket - Replaced 10024384	6.83
1820	Clip	0.75
1821	Olive (Small)	0.40
1822	Olive (Large)	0.50
1823	Nut (Small)	1.21
1824	Nut (Large)	1.21
1828	Obsolete	0.00
1829	Expansion Vessel Plate	2.78
1830	8 Litre Expansion Vessel (Inc pipe)	84.76
1831	Use 2127	0.29
1832	Use 1913	0.00
1835	Electrode Seal	0.90

SPARE PARTS

Part No.	Description	Price
1836	Use 10025074	86.09
1837	Ignition Box	129.96
1838	Spark Electrode with lead	16.08
1839	Gas Pipe (requires 1840 too)	11.12
1840	Pipe (requires 1839 too)	14.67
1841	Use 01005245	0.00
1842	Hood Assembly	19.29
1843	Air Baffle (Left)	2.77
1844	Air Baffle (Right)	1.02
1845	M15 to Pump Wiring	6.58
1846	Pipe	22.51
1847	Pipe	11.64
1848	Pump Pipe replaced 10023195	15.45
1849	Obsolete	0.00
1850	Expansion Vessel Pipe	7.91
1851	Use 10021951	38.00
1852	Door Panel	11.12
1853	Use 10024528	0.00
1854	Use 10024558	34.84
1855	Use 10021849	17.70
1856	Obsolete	0.00
1857	Pressure Gauge	14.52
1858	Green to Red LED	6.80
1859	temp control knob htg&dhw	3.14
1860	dhw/htg Mode selector switch	3.14
1861	Cap	0.80
1862	Spring	1.74
1863	Use 10023044	0.33
1864	Clip	4.70
1865	Adhesive Film	1.83
1866	Adhesive Film	1.58
1867	Pin/Screw for Control Panel	1.47
1868	Obsolete	0.25
1869	O'Ring	0.25
1870	M12 to Fan Wiring	21.22
1871	Wiring M3 to Primary thermistor, High limit stat & AP Swith	30.71
1872	Wiring M5 to DHW thermistor, Boiler flow switch & DHW Flow switch	39.65
1873	Wiring M11 to Motorised valve	9.23
1874	Wiring to CVI - M4 & M14 to Gas valve, Mod coil & ign box	28.22
1878	Use 1549	0.00
1879	Use 1531	0.00
1880	Case	106.07
1881	Locating Clip R/H	1.66
1882	Locating Clip L/H	1.66
1888	Water supply stop cock	16.46
1890	Clip	0.60
1895	Terminal Board	3.80
1901	Obsolete	0.57
1910	Obsolete	3.00
1912	Use 2073	0.00
1913	Guard Replaced 1832	6.48
1914	Use 01005246	141.75
1915	Obsolete	0.00
1916	Obsolete	0.00
1917	Use 10023202	13.14
1918	Obsolete	27.83
1919	Use 10022015	0.00
1920	Use 10020217	23.76
1922	Case	109.40
1931	Use 1838	0.00
1947	1AM Fuse (Individual)	1.10
1955	Expansion Vessel	61.76
1956	Flow governor (Pink)	3.92
1957	Domestic Heat Exchanger	118.24
1959	Combustion Chamber	63.23
1960	Obsolete	0.00
1964	Electrode	16.44
1966	Gas Pipe	15.00
1967	Obsolete	163.86
1968	Hood Assembly	39.70

SPARE PARTS

Part No.	Description	Price
1969	Obsolete	41.09
1970	Obsolete	14.19
1971	Air Baffle	2.38
1972	Obsolete	2.38
1973	Front Panel	9.47
1974	Back Combustion Panel (Linea P	9.47
1975	Pipe	24.83
1978	Obsolete	5.54
1979	Obsolete	6.28
1980	Clock Wire	7.00
1987	Distribution Manifold	310.49
1988	Heat Exchanger Jacket	5.17
1996	Control Panel Flap	13.49
1B700005	Washer	12.02
20000118	Drain plug	10.12
20000120	Flange for fan	16.75
20000121	Rear instrument panel	11.16
20000122	Casing	80.22
20000123	Conveyor	41.91
20000124	Instrument panel	17.90
20000125	Gas pipe	11.42
20000126	Use 20020255	50.87
20000127	Pipe	25.82
20000128	Pipe	34.17
20000129	Air bleeding connection Pipe	6.93
20000130	Spring clip	1.98
20000131	O ring	0.85
20000132	Flexible pipe	5.55
20000133	Flexible pipe	5.64
20000134	Pump cable	6.74
20000135	Combustion cable	16.28
20000136	Power wiring harness	21.66
20000137	Gas valve cable	13.00
20000138	Wiring harness	7.89
20000140	Air box side	20.83
20000141	Condensing exchanger assembly	438.21
20000142	Top flue outlet blanking cap	4.73
20000143	Drain plug	20.40
20000148	Burner	99.77
20000168	Instrument panel	17.90
20000498	Use 20007052	0.00
20000533	Cock	4.33
20000539	Clip	0.35
20000713	Detector Replaced 20075973	4.70
20000761	Cover	13.71
20000762	Wiring X2 to M4 (OT & external sensor)	9.11
20000763	Pump cable	17.84
20000764	Low tension cable	11.93
20000765	Combustion cable	25.19
20000767	Gas valve cable	12.78
20000768	Power wiring harness	21.54
20000769	Pipe	9.74
20000773	Instrument panel	14.64
20000774	Door Panel	3.44
20001003	Protection	29.44
20001101	Instrument panel cover Rep 10027549	9.35
20001102	Instrument panel	17.47
20001103	Instrument panel	11.74
20001116	Use 20008307	0.00
20001126	Instrument panel - If rep 10023933 - change fascia components as well	44.67
20001140	Instrument panel	42.04
20001141	Instrument panel	39.15
20001560	Ignition cable	19.04
20001563	Use 20002969	33.32
20001564	High limit stat (With Clip)	16.82
20001617	Combustion fan cable	34.71
20001681	CN1 to Fan Power Supply, CN2 to Ignition Transformer	23.09
20001873	Use 20002906	0.00
20002045	Ignition Cable	10.17
20002906	Pump rep 2225 & 20001873	155.16

SPARE PARTS

Part No.	Description	Price
20002969	Ignition transformer with wires Rep 10026237 & 20001563	33.32
20002995	Fan	202.27
20003181	Water pressure switch	8.01
20003819	Use 20081926	13.29
20004365	Use 20081926	20.62
20004832	Use 10027352	19.37
20004978	Use 10027352	10.90
20005146	Use 20052572	249.89
20005150	Use 10021419	0.00
20005151	Use 10023661	0.00
20005544	Heat exchanger	287.62
20005546	Spring pipe	3.56
20005549	Cap smoke analysis	7.17
20005550	Plug	0.90
20005551	N.G. burner	23.27
20005552	Washer	1.13
20005553	Gas pipe	19.41
20005554	Gas pipe	10.72
20005556	Pipe	11.46
20005557	Pipe	11.92
20005558	Pipe	16.10
20005559	Pipe	13.01
20005560	Front insulation panel	6.23
20005561	Back insulatin panel	6.39
20005562	Insulation panel	9.16
20005566	O ring	1.82
20005568	Heating distrib.	6.56
20005569	Printed circuit board MP08	92.82
20005571	Low tension cable	19.03
20005572	Wiring Harness CN2 to M3 mains connection, pump & gas valve	27.51
20005574	Cover	5.43
20005575	Knob	1.62
20005579	Knob	1.35
20005580	Quick primer pressure gauge	9.88
20005582	Pump	131.83
20005584	NG Burner Injector Manifold	13.69
20005585	High limit stat	2.50
20005586	Plastic Hole cover	1.28
20005591	Frame	22.46
20005594	Combustion chamber cover	28.48
20005595	Kit cable grommet	5.34
20005596	Flue draught diverter	7.21
20006403	Condensing level detector cable Replaced 10024121	11.21
20006411	Fan baffle	7.08
20006423	Casing	82.32
20007047	Heat Exchanger Jacket	1.62
20007050	Flue sensor	11.19
20007052	Main Printed circuit board	305.58
20007053	Conveyor	43.97
20007057	Heat exchanger jacket (Rep 1807)	2.67
20007692	Cover	53.93
20007783	Heating by-pass valve	1.79
20008306	Conveyor Replaced 10028536	33.32
20008307	Main Printed circuit board	167.52
20008788	Sonda Di Temperatura	29.06
20010331	Condensing Pipe	4.16
20010682	Pump 32-80	324.45
20011042	Clip	0.70
20011043	Connection	5.64
20011048	Fumes connection	10.51
20011082	Instrument panel	16.55
20011392	Casing cover	43.17
20011393	Case assembly	123.47
20011402	Pump	152.45
20011403	Gas cock	28.30
20011411	Frame Assembly	64.70
20011419	Use 20052578	233.92
20011420	Pipe	23.34
20011421	Pipe	13.85
20011422	Pipe	10.77

SPARE PARTS

Part No.	Description	Price
20011423	Pipe	15.29
20011424	Printed circuit board	100.78
20011443	Printed circuit board kit	34.67
20011449	CN8 - J1 Display Wiring Harness	3.27
20012544	Low tension cable	7.29
20012937	Flexible Pipe	6.56
20012949	Frame Assembly	55.30
20013055	Knob	1.65
20013140	Pipe	9.28
20013349	Combustion cable	21.83
20013350	Low tension cable	9.71
20013352	LED light guide	0.65
20013353	Pipe	21.91
20013354	Ignition transformer	11.66
20013968	DHW Actuator	17.98
20014025	Control Knob	1.65
20014074	Connection	5.97
20014873	Pipe	13.48
20014882	Water gauge carrier	1.53
20014884	Light guide	1.23
20014885	Pressure gauge	15.89
20014887	Heating Control Knob	1.47
20014888	Hot Water Control Knob	4.28
20014891	Instrumental panel	13.61
20014920	Frame	37.25
20015932	Mixer Replaced 10024295	32.32
20016279	CN2 to Water Pressure Switch, Flow meter & DHW NTC	13.35
20016280	Ignition Flame Wiring Harness	23.31
20016282	J13 to flame sensor, CN1 to flow/return NTC's, J12 to flow overheat stat, J24 to fan (LV) & J7 to condense/flame sensor	32.30
20016283	Printed Circuit Board	250.03
20016328	Burner Assembly	105.09
20017585	Metal Combustion Chamber Cover	9.15
20017591	Pipe	30.98
20017592	Pipe	33.15
20017594	Actuator/Motorised valve	47.04
20017596	CN4 to Motorised Valve	29.16
20017597	Use 20043594	38.43
20017598	Square Locking Pin	1.13
20017599	Valve with cartridge	67.63
20017785	Hanging bracket	6.83
20017899	Detector	8.64
20018986	Casing	72.11
20019250	Casing - Unica 32HE & 36HE	126.36
20019763	Pipe	10.22
20019764	Pipe	21.32
20019765	Pipe	16.95
20019766	Air bleeding connection Pipe (Rep 10028516 & 10028515)	9.93
20019767	Locking Pin	0.35
20019768	Auto air vent (Black)	4.73
20019769	Flow Pipe assembly (Rep 10029457)	60.52
20019888	Air Separator	14.36
20020178	Air bleeding connection Pipe	4.45
20020179	Flow Pipe Assembly Rep 10029458 & 10027318	61.18
20020181	Air bleeding connection Pipe	5.18
20020182	Flow Pipe Assembly (Rep 10029515)	60.43
20020192	Pipe	15.26
20020252	Pipe	17.76
20020254	Pipe	9.69
20020255	Flow Pipe Assembly replaced 20000126	55.05
20020300	Frame assembly	81.41
20020309	45mm restrictor ring rep 10024037	2.26
20020310	Flue flange Ø 47	2.80
20020311	Flue flange Ø 43	2.80
20020377	42mm restrictor ring	2.26
20020899	Pipe	43.22
20020900	Pipe	73.46
20021032	Combustion cable	27.34
20021496	3 way htg manifold & cartridge	64.00
20021497	3 Way Manifold & Cartridge	55.94
20021548	Pressure connection	1.00

SPARE PARTS

Part No.	Description	Price
20021597	Fan support kit	4.06
20022564	Wiring harness	22.81
20023928	Fixing flange	1.11
20024086	Spring Clip	3.78
20024202	Pump Cable	23.56
20024205	Printed Circuit Board	29.66
20024419	Use 20029826	59.34
20024559	Pressure Transducer	25.85
20024591	Condensing Exchanger Assembly	356.82
20024600	Gas Pipe	14.31
20024841	3-Way Valve Motor	27.12
20024869	O Ring	0.60
20025687	Segnal amplifier	1.82
20025733	Siphon	8.95
20025734	CN9 to DHW flow switch, DHW NTC & Water pressure switch	10.77
20025735	Use 20069541	124.31
20025736	CN1 to Ign Transformer, CN3 to Fan, CN10 to Fan & CN11 to Flow/Return NTC's, Flue NTC & High Limit Stat	52.89
20025737	Ignition electrode with Lead	16.28
20025738	Electrode	11.24
20025740	Seal for Ignition electrode	0.85
20025743	Pipe	5.71
20025744	Flow Pipe Assembly	37.97
20025745	Pipe	23.01
20025746	Air bleeding connection Pipe	7.68
20025747	Washer	0.25
20025752	Use 20039202	89.54
20025753	Washer	3.00
20025755	Copper Pipe from Safety Valve	8.60
20025756	Copper Tail 15mm	5.39
20025757	Copper Tail 22mm	6.32
20025758	Copper Pipe (L Shape)	7.07
20025760	Suction pipe	4.70
20025761	Mixer	16.82
20025762	Use 20039953	4.02
20025763	Pipe	25.31
20025764	Pipe	17.84
20025765	Use 20039923	252.92
20025880	Pump	250.03
20025881	Pipe	25.08
20025883	J9 to divertor actuator & M2 (secondary pump)	18.65
20025884	Pump Cable	12.72
20026048	Compact 25 A Instrument Panel	11.58
20026049	Outlet nut	4.36
20026051	Diaphragm	3.82
20026055	Control Panel Cover	18.23
20026056	Flue collector	5.93
20026058	Test Point Cap	2.64
20026059	Washer	2.64
20026060	Conveyor	50.39
20026061	Complete Burner Assembly	153.16
20026073	Casing	63.66
20026079	Burner assembly	190.70
20026080	Compact 29 A Instrument Panel	10.61
20026081	Use 20039924 Exchanger Assembly	269.06
20026082	Diaphragm	3.60
20026083	Mixer	16.10
20026585	Control panel	124.30
20026586	Use 20039202	115.27
20026587	Wiring J3 to M3 230v mains connector & M6 connector block (TA link)	14.16
20026589	Casing	96.54
20026724	Fan kit	45.38
20026728	Fixing flange	2.38
20028324	N.G. burner	27.47
20028325	Collector	18.60
20028661	CN4 to divertor actuator	12.92
20028731	Safety Valve	12.24
20028732	Pipe	40.97
20028733	Pipe	38.26

SPARE PARTS

Part No.	Description	Price
20028734	Pipe	96.72
20028736	Pipe	10.98
20028737	washer	2.38
20028738	Pipe	26.40
20028739	Conveyor	56.32
20028740	Pressure Switch	55.72
20028741	Mixer	53.82
20028742	Washer	2.71
20028744	O Ring	1.41
20028745	Stub Pipe	31.24
20028746	washer	6.78
20028747	Stub Pipe	79.12
20028748	Cover	54.79
20028749	Pipe	16.87
20028750	Pipe	43.83
20028752	Pipe	151.42
20028759	Suction Pipe	68.06
20028760	Flexible Pipe	4.75
20028761	Flexible Pipe	3.87
20028762	NG Injector	6.49
20028763	Burner Assembly	91.12
20028765	Condensing Exchanger Assembly	398.22
20028769	Cover	46.34
20028904	Nipple	37.00
20028963	PCB Replaces 10028996 & 10024554	169.29
20029043	LPG to NG Conversion kit	9.32
20029052	LPG to NG Conversion kit	6.78
20029055	NG to LPG conversion kit (4.3 jet)	18.23
20029826	Expansion vessel Rep 20024419	79.59
20029985	DHW Actuator	21.20
20030209	Venturi kit (Repl 01005405)	19.07
20030334	Airbox	46.46
20031414	LPG to NG Conversion Kit	19.37
20031415	LPG Conversion Kit	23.10
20031497	Mixer (Red)	76.74
20031569	Use 20030209	0.00
20032150	LPG to NG Conversion Kit	11.30
20032155	NG TO LPG Conversion Kit	11.30
20032553	Degasser kit	22.04
20033722	Tank Condensation Collecting	13.01
20034037	3 way htg manifold with cartridge (10026508) & motorised valve (20024841) Complete	62.83
20034320	Expansion Vessel	71.83
20035019	Air Vent bottle	18.48
20035390	Pipe	23.77
20035391	Gas pipe	21.65
20035392	Cover assembly	5.89
20035393	Pipe	11.53
20035394	Cock	13.90
20035397	Case Assembly	72.04
20035404	CN9 to DHW Flow Switch, DHW NTC & Water Pressure Switch	21.62
20035405	CN2 to M3 Mains Connection, Clock Harness, Pump & Gas Valve (With Tyco lead)	48.02
20035501	Instrumental panel	11.53
20035502	CN9 to Water pressure switch	16.15
20035533	Gas valve - Relaced 10020574 & 10021021	126.24
20035608	Control panel	11.53
20035609	Pipe	11.28
20035613	Case Assembly	90.73
20035648	Filing Cock Knob	1.83
20035649	Filling cock	5.01
20036112	Pump	144.81
20036120	Pipe	8.31
20036537	Tryton Retarder	2.37
20036547	Use 20079944	159.46
20036548	Flow Switch	65.31
20036549	Use 20104238	557.13
20036551	Inlet Water Pipe	188.28
20036552	Outlet Water Pipe	103.74
20036553	Compressor	370.76



SPARE PARTS

Part No.	Description	Price
20036554	Compressor Protection Module	5.76
20036555	Condenser	453.39
20036556	Inverter Module	445.68
20036564	Front Panel	76.83
20036581	Inverter Module	468.74
20036582	Outlet Water Pipe	99.89
20036583	Condenser	864.50
20036585	Straightener	30.72
20036586	Liquid Assy	153.70
20036587	Condenser	1171.86
20036588	Front Panel	109.50
20036607	Motor	132.56
20036608	Condenser	1575.29
20036609	Compressor	1440.83
20036610	Accumulator	13.43
20036611	Magnetizing Coil Valve	26.53
20036612	4 Way Valve	119.12
20036613	Logical PCB	438.01
20036614	Liquid Assy	172.90
20036630	Thermostat	303.54
20036700	External probe	49.96
20036990	Mixer Spacer	0.60
20038366	CN2 to Water Pressure Switch, Flow meter & DHW NTC	25.67
20038597	Combustion Chamber Cover	28.40
20039151	Pipe	18.60
20039152	Pipe	17.17
20039153	Pipe	8.95
20039202	Gas valve Rep 10028538 & 10027187 & 20025752	134.40
20039204	Gas Diaphragm	7.55
20039359	Glass kit	52.29
20039402	M6 to CN6 & CN5	22.61
20039923	Exchanger Assembly rep 20025765	252.92
20039924	Exchanger Assembly rep 20026081	269.06
20039926	Pump Kit	156.06
20039953	Flow Connection for Compact A	4.02
20039954	Return Connection for Comact A	4.02
20040102	Flue drain connection	8.18
20040474	Gas Pipe	11.92
20040675	Gas Valve Solenoid (Fits 10025074 & 20035533)	62.80
20040979	Cock	27.12
20040980	CN2 - Mains terminal block, Pump, Water pressure switch & Gas valve Wiring Harness	95.73
20040981	CN4 - M3A Wiring Harness	22.81
20040982	CN1 - Ign transformer + FA1 Wiring Harness	22.81
20040983	CN10 - Fan Wiring Harness	18.23
20040984	CN9 - Water Pressure Switch + Cylinder Stat	22.81
20040985	Instrument panel	21.47
20040986	Pipe	14.69
20040987	CN3 - Fan Wiring Harness	31.91
20040988	CN11 - High limit, Flow NTC, Return NTC, Flue stat, UFH stat & FA2 - Flame sensor Wiring Harness	68.41
20040989	CN6 - M6 Wiring Harness	31.91
20040990	Pump	177.42
20040999	Frame assembly	192.11
20041000	Case Assembly	132.22
20041049	Case	86.33
20041051	Fixing Door	5.01
20041053	Instrument Plate	11.39
20041058	Diaphragm	1.00
20041473	Diaphragm	0.95
20042113	Knob	1.62
20042114	Knob	1.62
20042115	Pressure gauge	12.92
20042121	Use 20060938	36.06
20043496	By-pass valve	1.83
20043523	Ionisation Electrode	11.30
20043524	Burner assembly 25 kW (Ceramat)	146.91
20043594	3 way valve cartridge Rep 20017597	36.60
20043820	Use 20044364	17.96
20044364	Safety valve Rep 10025055 & 20034917 & 20043820	17.96
20044890	Lateral insulation panel	10.76
20044892	Burner 25 kw (Ceramat)	92.83

SPARE PARTS

Part No.	Description	Price
20044894	Burner Gasket	9.69
20044895	Exchanger cover	26.91
20044896	Burner	75.34
20045328	Use 20020179	61.18
20045568	LPG to NG conversion Kit	17.22
20045569	NG to LPG conversion kit (3.9)	19.78
20046189	Water Pressure Switch Replaced 2214	23.76
20046265	Washer	10.98
20046266	Cover	23.68
20046269	Burner (New type Worgas)	104.40
20046270	Protection	10.01
20046560	Pressure switch same as 2726?	14.00
20046835	Flange and Insulation	23.68
20046836	Tryton with 3 Screws	17.38
20046837	Flange and Insulation	25.83
20046839	Tryton and Screws	13.50
20047573	Flue gas flange	32.29
20047802	Washer	1.40
20047807	Burner Flange	14.15
20047811	Ring Closing	3.98
20047812	Insulation	16.15
20047819	Washer	1.00
20047820	Sealant	14.53
20048263	Heat Exchanger shell	62.15
20048269	Heat Exchanger shell	52.09
20048271	Container Exchanger	55.97
20048272	Exchanger shell	77.49
20048322	Case Assembly	63.66
20048779	3 way valve	287.70
20049127	Exchanger	902.92
20049604	NTC Sensor	50.42
20049606	Plug/Hole Cover	2.74
20049608	Wiring Harness	22.97
20049617	Quick primer pressure gauge	14.00
20049618	Frame Assembly	34.44
20051029	Heat Exchanger Bracket Kit	4.31
20051418	Heat Exchanger Support Bracket	8.66
20052572	Main heat exchanger Rep 20005146 & 10023651	249.89
20052578	Main Heat Exchanger Repaced 20011419	233.92
20055213	NG Jet	11.84
20055216	Burner (Original Ceramat)	95.25
20055453	Conveyor	34.44
20055454	Use 20069541	124.31
20055455	Timer/Display Module	94.71
20057326	Control Panel Cover (Rear)	5.65
20057328	Case Assembly	56.10
20057330	Knob	3.77
20057331	Front Panel	14.96
20057332	Wiring Harness CN8 to M2 to Clock & CN5.	9.69
20057346	Front Panel	13.57
20057350	Led light guide	2.69
20057351	Front Control Panel	14.00
20057751	LPG to NG Conversion Kit	4.31
20057833	Frame assembly	84.11
20057834	Case Assembly	103.32
20057837	Front Panel	37.67
20057854	Condensing exchanger assembly	365.93
20057855	Gas Pipe	25.13
20057856	Ignition electrode	10.76
20057857	Detection electrode	7.80
20057858	Tryton	19.37
20057859	Pipe	29.49
20057861	Pipe	33.90
20057862	Pipe	35.09
20057864	Pipe	28.52

SPARE PARTS

Part No.	Description	Price
20057865	Pipe	60.27
20057866	Pipe	53.81
20057868	CN9 to DHW flow switch, DHW NTC & Water pressure switch	13.62
20057870	Washer	2.37
20057871	Washer	2.15
20057872	Glass Fibre	3.32
20057873	Flow Pipe Assembly	53.81
20057874	CN1 to ign transformer, CN3 to fan.	21.90
20057875	CN2 to M3 mains connection, clock harness, pump & gas valve + 3 core fly lead	54.89
20057876	CN10 to fan & CN11 to flow/return NTC's, Flue NTC & high limit stat	33.37
20057878	Washer	4.03
20057880	Conveyor	18.03
20057882	Top flue outlet blanking cap	20.72
20057885	Air/gas manifold	11.30
20057887	Burner assembly	87.18
20057889	Washer	1.29
20057895	Hanging Bracket	5.39
20057896	Support kit	48.44
20058630	Condensing Exchanger Assembly	365.93
20058631	Front Panel	35.95
20058633	Burner Assembly	86.10
20058634	Pipe	55.43
20058635	Pipe	36.53
20058636	Support Kit	14.74
20059926	Use 20042114	2.69
20060133	Frame Assembly	28.35
20060559	Slave wiring Harness	235.20
20060560	Power wiring harness	82.80
20060561	Slave PCB	418.32
20060564	Ignition cable	82.79
20060566	Ignition electrode	74.89
20060569	Fan	601.34
20060571	Gas valve	369.60
20060573	Connector	82.80
20060574	Delivery manifold	152.78
20060575	O-ring	17.44
20060598	Cock	126.00
20060601	Hose	114.45
20060676	Clip	13.07
20060677	Clip	14.28
20060679	Gas pipe	43.58
20060682	O-ring	17.44
20060685	Connector	104.58
20060687	Temperature probe	69.73
20060689	Pipe	43.59
20060691	Pipe	26.15
20060692	Connector	122.02
20060694	Connection	52.29
20060695	Cable connector	43.59
20060696	Gaurd	17.44
20060697	Elbow	30.51
20060718	90° bend	152.50
20060725	Cock	204.79
20060727	Master PCB	396.54
20060728	Master wiring harness	126.36
20060729	Burner	165.57
20060730	Burner seal	65.36
20060731	O-ring	17.44
20060732	Flange	108.95
20060938	Card Reader Kit	48.44
20061168	Combustion Chamber Clip and 2 rivets	1.83
20061473	Gas manifold	418.32
20061474	Delivery manifold	718.99
20061475	Lateral panel	239.67
20061476	Rear panel	305.04
20061477	Heating return manifold	705.92

SPARE PARTS

Part No.	Description	Price
20061478	Upper Front Panel	165.57
20061480	Top panel	117.65
20061481	Lateral panel	0.00
20061482	Left Panel	239.67
20061484	Right Panel	418.32
20061486	Upper Front Panel	636.18
20061488	Top panel	56.66
20061489	Gas manifold	296.30
20061490	Heating return manifold	483.68
20061492	Delivery manifold	492.39
20061493	Connector	21.78
20061494	Connector	21.78
20061498	O-ring	13.07
20061501	Bend	43.59
20061502	Rear panel	65.36
20061504	Diaphragm	13.07
20061506	Flange	34.85
20061507	Top panel	557.75
20061508	Top panel	557.75
20061510	Left Hand Door	671.07
20061512	Right Hand Door	636.18
20061513	Left Panel	270.15
20061514	Rear panel	287.60
20061516	Right panel	270.15
20061517	Top panel	322.44
20061518	Rear panel	296.30
20063116	4 Pole Connector	5.88
20063463	Siphon	6.89
20063464	Siphon Cover	4.96
20063466	Condensing Pipe	5.87
20063467	Condensing Pipe	0.00
20063468	Washer	1.00
20063584	Air Pressure Switch	20.08
20063990	Left Hand Door	671.07
20063991	Left Panel	440.10
20066456	Plastic Condense Pipe Replaced 10027543	20.93
20066460	Plastic Condense Pipe Replaced 10027568	21.99
20066463	Plastic Condense Pipe Replaced 10028015	20.46
20066464	Plastic Condense Pipe Replaced 10027977	22.61
20067062	Wiring Harness CN6 to M6 to CN5.	27.66
20067305	Heat Exchanger	195.30
20067310	Combustion cable	43.70
20067421	Front Panel	134.54
20067579	Mixer	69.96
20067580	Pipe	24.64
20067581	Flexible Pipe	14.00
20067584	Mixer	70.50
20067585	Gas Pipe	14.00
20067807	Instrument Panel	13.57
20067812	Insulation Panel	0.00
20067813	NTC Sensor	5.92
20067815	Pipe	0.00
20067816	Pipe	43.83
20067826	Pipe	0.00
20068881	Plastic Condense Pipe Replaced 10024132	19.52
20068882	Plastic Condense Pipe Replaced 10024440	20.30
20068884	Plastic Condense Pipe Replaced 10024521	21.11
20068965	By Pass Valve Lock	1.19
20068999	Washer	1.19
20069007	Air Chamber Access Panel	39.55
20069510	Frame assembly	107.63
20069541	Printed circuit board Replaced 20055454 & 20025735	124.31
20069542	3/4 Connection	5.82
20069587	LPG to NG Conversion Kit	32.29
20069592	LPG to NG Conversion Kit	32.29
20069593	NG To LPG Conversion kit	32.29
20071334	Printed Circuit Board with display	102.25
20071802	Control Panel Cover (Rear)	5.49
20071908	Gas Pipe	28.52
20071909	Flow Pipe Assembly	57.05
20071910	Flow Pipe	32.29

SPARE PARTS

Part No.	Description	Price
20071911	Frame Assembly	96.86
20071912	Air box front cover	40.90
20071914	Burner Assembly	55.97
20071916	Support kit for Condensing Exchanger	11.30
20071918	Case Assembly	96.86
20071921	Condensing Exchanger Assembly	343.33
20072077	Sensing Electrode	9.69
20072084	Cover	11.52
20072330	Pipe	22.68
20073417	Heat Exchanger	3582.60
20073427	Flange	17.44
20073436	Fumes Connection	91.51
20073521	Control Panel	12.92
20073523	Case Assembly	64.58
20073678	Control Panel	12.92
20073700	Use 10022349	27.02
20073721	Control Panel	12.92
20073763	Condensing Assemby - Same as 20028765	398.22
20074451	Condensation Outlet Manifold	156.87
20074453	Exhaust Tube	98.44
20074454	Condensation Outlet Tube	17.44
20074458	Condensation Outlet Manifold	100.21
20074462	Exhaust Tube	100.21
20074728	Spark/Ignition electrode Replaced 10027620	16.95
20075973	Use 20000713	0.00
20076437	CN5 to Relay Board	1.94
20076889	Flexible Pipe	4.20
20076890	Combustion Cable	46.82
20076891	Flow Pipe Assembly	13.45
20076892	Front Panel	12.92
20076998	Mixer	67.81
20078170	Front Panel	14.00
20078171	Pipe	29.14
20078173	Case Assembly	102.25
20078350	Use 20081926	13.29
20078519	Instrument Panel	16.95
20079833	Frame Assembly	107.63
20079944	Printed Circuit Board - Replaced 20036547	159.46
20081059	Plug	0.55
20081316	Fan Assembly with Built in Mixer	202.27
20081318	Fan Assembly with Built in Mixer	202.27
20081537	Air Box	37.67
20081858	Slave Wiring Harness	191.72
20081859	Motor	326.81
20081860	Pipe	95.88
20081926	Thermistor/NTC Replaced 20003819 and 20004365	13.29
20081973	Wiring HARness - ERP	0.00
20082101	Use 10025647	0.00
20082915	LPG to NG Conversion Kit	12.40
20082917	NG to LPG conversion kit	12.09
20083194	Case	71.55
20083256	Pipe	20.90
20083257	Pipe	12.60
20083995	LPG to NG Conversion Kit	36.59
20083996	NG to LPG Conversion Kit	38.75
20084372	Fan Baffle R/H	6.46
20085965	Fan	251.99
20086250	Burner	44.61
20086269	Heat Exchanger Insulation	6.83
20086438	LPG to NG Conversion Kit	37.01
20086673	Burner	55.97
20087173	NG to LPG Conversion Kit	63.00
20087176	NG to LPG Conversion Kit	63.00
20087319	Burner	73.64
20087321	Mixer	72.06
20087379	Burner	0.00
20088617	Instrument Panel	13.39
20088621	Instrument Panel	13.39
20089382	High head pump	170.89
20089999	Plug and Nut	2.02
20090680	Pipe	15.96

SPARE PARTS

Part No.	Description	Price
20092620	Fitting / Union Replaced 10026194	4.33
20093799	Clip for High Limit stat onto Heat Exchanger	4.54
20095477	Casing	118.65
20096202	Degasser Connection Assembly	3.15
20096531	Wiring Harness ERP	33.32
20096793	Degasser Connection Assembly	3.15
20099105	ERP Pump Assembly	280.35
20099541	Wiring ERP	3.11
20099544	Pipe	14.92
20099545	Flow Pipe	17.01
20099548	Degasser Kit and Pipe	36.27
20100735	Pump Cable ERP	10.16
20100812	Wiring - ERP	10.12
20101177	Instrument Panel	13.07
20101178	Control Panel Cover	6.07
20101179	Instrument Panel and Cover Combined	18.00
20101312	M5 Screw (Phillips Head)	0.74
20101331	Flange Assembly	31.77
20101332	Bracket Assembly	5.71
20101723	Power Wiring Harness - ERP	34.42
20101724	Pressure Gauge Holder	1.39
20101725	Pressure Guage	12.80
20102262	PTFE teflon gasket Replaced 105904	12.84
20102628	Wiring Harness ERP	44.10
20102629	Flow Pipe	17.84
20102646	Flow Pipe	18.11
20104238	Heat Exchanger - Replaced 20036549	557.13
20104982	Instrument Panel	13.07
20104984	Wiring - ERP	9.89
20104985	Flow Pipe	38.79
20104986	Pipe	62.52
20104988	Flow Pipe	39.50
20104996	Pump	282.95
20104997	Power Wiring Harness - ERP	49.02
2033	Transformer (Repl 10023478)	85.28
2044	Use 10028141	0.00
2047	Heating bypass valve	5.06
2051	Use 2053	17.01
2052	Pipe	33.72
2053	Pump Pipe	11.79
2059	Air Box Side (Left)	19.24
2060	Air Box Side (Right)	19.24
2061	Use 10020430	0.00
2062	Case	114.39
2068	Obsolete	2.85
2069	Burner Baffle	3.09
2072	Air Chamber	45.14
2073	Air box bottom (Rep 10027894/1912)	51.48
2074	Boiler Bracket	8.14
2075	Use 10022029	0.00
2076	Fan Assembly	129.96
2080	Use 10020493	0.00
2089	Electronic Ignition Box	145.30
2090	Gas Pipe	13.91
2091	Use 2470	0.00
2092	Sensing Electrode	11.06
2093	Pipe	32.37
2095	Pipe	25.10
2096	Obsolete	35.37
2111	LPG jet 5.0	10.52
2127	Insert	0.85
2139	Gas Valve (replaced 2897)	177.59
2164	Use 10023603	9.78
2165	Use 10027757	0.00
2192	Use 10027864	0.00
2201	Use 10022533	39.41
2204	8 Litre Expansion Vessel	76.80
2211	Potentiometer Extention	0.90
2213	Obsolete	12.18
2214	Use 20046189	23.76

SPARE PARTS

Part No.	Description	Price
2216	Manifold Plug	2.38
2217	Screwed Connection	3.11
2218	Use 10022000	15.65
2219	Use 10022002	15.65
2222	Locking Pin	3.18
2223	Locking Pin	3.18
2225	Use 20002906	0.00
2226	Rubber Seal	2.87
2228	Combustion Cover	5.69
2229	Use 10024779	0.00
2230	Rear Insulation Panel for Combustion Chamber	7.13
2231	Side Insulation Panel for Combustion Chamber	5.54
2232	Front Insulation Panel for Combustion Chamber	7.60
2233	Blanking Plate	2.87
2234	Burner	55.44
2235	Burner Bar NG	31.90
2236	Obsolete	31.90
2237	Connection	8.86
2238	Cross Lighting Strip	0.90
2243	Obsolete	10.29
2255	Spark / ignition electrode and lead	19.80
2258	High Limit Thermostat	7.13
2260	Use 10022499	1.51
2261	Manifold Plug	2.91
2266	3/4" Gas cock	11.78
2294	Clock Harness (Option)	18.28
2310	Main Heat Exchanger	209.07
2353	NG Jet	11.84
2378	Use 01005246	78.75
2381	Use 01005245	85.61
2455	Screw Driver	0.70
2468	Pressure Gauge	16.39
2470	Spark Electrode	22.19
2490	Flexible Pipe	19.40
2491	Pipe	12.18
2492	Flexible Pipe	27.71
2493	Pipe	24.94
2494	Gas Pipe	13.86
2495	Wiring Harness	42.13
2554	M5 to Pump cable	12.37
2564	Pressure Gauge	28.23
2573	Expansion Vessel Rep 106333 10 Litre	84.76
2577	Obsolete	11.39
2578	Pipe	3.77
2586	44mm Restrictor Ring	1.10
2588	Clip	0.65
2600	Thermostat	20.96
2677	Air Pressure Switch	52.42
2678	Obsolete	19.22
2701	Ribbon Cable M9 to M2 between main PCB & display PCB	7.43
2703	Obsolete	0.00
2710	Fitting	4.34
2726	Water Pressure switch (10028141)	18.65
2776	Pipe	3.91
2785	Thermostat Shaft	2.06
2801	Burner NG	63.20
2802	Obsolete	63.20
2803	Obsolete	23.85
2804	Frame	58.03
2805	Pipe	27.87
2806	Obsolete	86.07
2810099	Obsolete	763.83
2819	Combustion Cover	13.79
2820	Air Baffle RH	2.38
2821	Obsolete	2.38
2822	45° Flow/Return Valve	21.03
2823	flow / return valves connector	9.10
2851	Obsolete	8.06
2860	Hood assembly	36.83
2865	Fan Assembly	127.66

SPARE PARTS

Part No.	Description	Price
2868	Venturi	9.50
2873	Side Insulation Panel for Combustion Chamber	7.48
2888	Obsolete	2.11
2897	Use 2139	111.07
2903	DHW Inlet Manifold	15.45
2904	Use 10020335	1.67
2905	Motorised Valve	37.11
2906	Motorised Valve Fixing Wrench	0.35
2907	Safety valve Replaced 8433 (Push Fit)	11.46
2908	Non Return Valve	2.09
2909	Valve For DHW Bypass	5.97
2910	3 Port Valve Bobbin	2.84
2911	Automatic by-pass plug	3.00
2913	Bobbin Seating Washer	1.33
2915	Distribution Manifold (Complete)	175.16
2916	Obsolete	158.94
2936	Hood Assembly	24.31
2939	Fan Flue Connection	15.26
2940	Bracket	0.96
2946	Fitting/union	2.77
2950	Use 10021792	0.00
2966	Cover	0.35
3020233	Premix Burner	163.86
3020235	Fan	261.86
3020400	Burner head silicone gasket	10.33
3087	Obsolete	2.87
3106	Obsolete	3.02
3107	Obsolete	8.97
3112	Obsolete	36.57
3113	Obsolete	8.99
3118	Obsolete	18.56
3135	Obsolete	0.00
3139	Sight Glass	4.66
3175	Heating Manifold	101.96
3183	Obsolete	0.00
3190006	Neutro door sea 1 metre	5.57
3207	3 Port Valve	107.35
3208	Obsolete	134.54
3212	Heating Thermostat	26.61
3267	Heating Thermostat	16.95
3387	Use 4188	226.01
3409	High Limit Stat	16.95
3412	Clip	0.75
3434	Obsolete	169.51
3464	Anti freeze stat	5.84
3478	3 Amp Fuse (individual)	1.62
3484	Obsolete	0.00
3497	Obsolete	12.43
3499	Obsolete	1.49
35026	Obsolete	580.65
3607	Obsolete	0.00
3611	Obsolete	6.14
3721	Obsolete	3.33
3740	Obsolete	0.55
3771	Use 4961	9.47
3774	Obsolete	0.00
3800	Obsolete	73.20
4007	Sight Glass Retaining Ring	0.60
4008	Obsolete	1.32
4009	Obsolete	144.38
4013	Obsolete	0.00
4014	Obsolete	16.62
4016	Obsolete	8.97
4026	3/4" BSP Locknut	1.09

SPARE PARTS

Part No.	Description	Price
4026225	Fan motor	57.38
4026226	Fan	19.79
4026229	Compressor	482.81
4026230	Anti-vibration feet	5.97
4026231	Accumulator	45.52
4026232	Liquid receiver	41.53
4026233	4 way valve	33.61
4026234	Liquid assy	49.46
4026235	Magnetizing coil valve	17.80
4026236	Outlet water pipe	91.02
4026237	Inlet water pipe	144.47
4026239	Reactor	47.50
4026240	Condensing pipe	2.97
4026241	Expansion vessel	57.38
4026244	Heat Exchanger	595.57
4026245	Pump	239.43
4026246	Water sensor	61.31
4026247	Flow switch	65.31
4026248	Air vent	16.18
4026249	Pressure valve	27.72
4026250	Discharge temp sensor	5.97
4026251	Exchanger detector	3.94
4026252	Suction detector	3.94
4026253	External temperature detector	3.94
4026254	Anti-vibration feet	1.96
4026255	Inverter Module Rep 4026258	368.05
4026257	Heat Exchanger	1305.99
4026258	Use 4026255	368.05
4026259	Compressor	538.19
4026260	Liquid Assy	59.38
4026261	Magnetizing Coil Valve	13.82
4026262	Liquid Receiver	59.38
4026263	Reactor	55.43
4026264	Liquid Receiver	106.88
4026265	Inlet Water Pipe	85.10
4026266	Compressor	1305.99
4026267	Anti-Vibration Feet	5.97
4026271	Heat Exchanger	1080.38
4026272	Detector	91.02
4026273	Detector	67.29
4026274	4 Way Valve	35.65
4026277	Fan	17.80
4026280	Printed Circuit Board	77.16
4026281	Inverter Module	461.07
4026283	Outlet Water Pipe	213.71
4026285	Discharge Temp Sensor	67.29
4026287	Pump	358.13
4026291	Guard	34.58
4026292	Condenser	653.16
4026295	Transformer	15.07
4028	Use 6493	0.00
4036	Obsolete	0.00
4037	Obsolete	3.40
4039	Obsolete	0.00
4045	Obsolete	8.97
4049	Obsolete	0.00
4061	Obsolete	0.00
4062	Obsolete	0.00
4065	Obsolete	0.00
4095	Obsolete	5.00
4105	Obsolete	0.00
4114	Obsolete	4.48
4144	Obsolete	0.00
4148	Triple Microswitch	23.73
4157	Obsolete	0.00
4174	Obsolete	6.64
4174A	Obsolete	6.53
4175	Obsolete	98.67
4188	Obsolete	226.01
4189	Obsolete	35.93

SPARE PARTS

Part No.	Description	Price
4250	Safety Valve (Screw Fit)	10.74
4254	Automatic Air Vent	9.61
4254G	Auto Air Vent	9.61
4257	Obsolete	8.97
4274	Obsolete	2.87
4298	Diaphragm	4.74
4302	Microswitch	14.13
4321	Obsolete	1.05
4325	Obsolete	0.00
4332	Obsolete	1.13
4333	Obsolete	0.00
4336	Obsolete	0.00
4357	Obsolete	0.00
4359	Obsolete	8.97
4426	Obsolete	0.00
4434	Obsolete	9.94
4441	Temperature Gauge (rep 7171)	16.19
4449	Obsolete	0.00
4472	Obsolete	21.65
4489	Obsolete	8.97
4490	Obsolete	15.57
4492	Expansion Vessel	73.46
4493	Obsolete	78.30
4494	Obsolete	0.00
4495	Obsolete	58.60
4496	Obsolete	8.97
4497	Obsolete	0.00
4505	Obsolete	0.00
4518	Obsolete	82.90
4534	Obsolete	0.00
4535	Obsolete	0.00
4537	Obsolete	3.66
4538	Obsolete	0.00
4539	Obsolete	12.46
4540	Obsolete	17.01
4541	Obsolete	20.78
4542	Obsolete	16.18
4543	Obsolete	0.00
4544	Connection for Dom Exp Vessel	2.80
4545	Obsolete	85.48
4546	Obsolete	34.39
4549	Domestic Heat Exchanger	163.86
4551	Obsolete	0.00
4559	Obsolete	25.40
4562	Obsolete	0.00
4563	Obsolete	0.00
4565	Obsolete	8.97
4573	Obsolete	0.00
4577	Obsolete	0.00
4580	Obsolete	0.00
4581	Obsolete	0.00
4583	Obsolete	0.00
4585	Obsolete	0.00
4587	Obsolete	0.00
4605	Obsolete	0.00
4611	Blanking Plug for Heating Manifold	0.70
4612	Obsolete	8.97
4617	Obsolete	0.00
4619	Obsolete	8.97
4625	Obsolete	99.40
4627	Obsolete	8.97
4628	Obsolete	0.00
4630	Obsolete	111.90
4632	Obsolete	0.00
4634	Obsolete	0.00
4636	Obsolete	1.27
4638	Obsolete	0.00
4640	Gas Valve	165.74
4641	Obsolete	0.00
4642	Obsolete	0.00

SPARE PARTS

Part No.	Description	Price
4650	Obsolete	0.00
4659	Obsolete	0.00
4663	Obsolete	0.00
4665	Obsolete	0.00
4668	Obsolete	0.76
4680	Obsolete	0.00
4681	Obsolete	0.00
4691	Obsolete	0.00
4692	Obsolete	5.93
4699	Obsolete	0.00
4716	Obsolete	0.00
4723	Obsolete	0.00
4751	Obsolete	23.53
4761	Obsolete	8.97
4768	Obsolete	0.00
4801	Obsolete	0.00
4802	Obsolete	0.00
4803	Obsolete	15.57
4806	Obsolete	0.76
4807	Lock Nut	0.33
4828	Obsolete	0.00
48309	Clip	2.04
48310	Stud	2.26
48355	Screw	1.04
48381	Clip	0.69
48382	Screw	1.04
48474	Use 5023	5.17
4851	Rubber Wall Liner	8.70
4866	Obsolete	6.25
4870	Obsolete	0.00
4874	Obsolete	8.97
4875	Obsolete	0.42
4881	Obsolete	0.00
4888	H/I Stat (replaces 6399)	32.77
48896	Clip x 4	6.59
48897	Cover (Not a spare)	0.65
48898	Main Printed Circuit Board	197.76
48899	Use 10024558	0.00
48900	Clip	2.78
48901	Hook	1.41
48902	Obsolete	5.69
48903	Seal	7.11
48904	Locking Nut	2.92
48905	Obsolete	5.05
48908	Use 5071	0.00
4891	Pilot Jet NG.27	0.80
48911	Use 6898	0.00
48914	Use 5070	2.98
48917	Use 8968	1.19
48918	Use 1947	0.84
48919	Clip	1.19
4892	Obsolete	0.76
48920	USE 1858	0.00
48921	Use 1864	13.74
48922	Cover	6.75
48923	Cover	8.60
48926	Use 10020217	15.97
48927	Use 1920	25.52
48928	Use 1549	12.52
48929	Use 5317	71.80
4893	Pilot Jet LPG 22	0.80
4897	Obsolete	0.00
4909	Obsolete	0.00
4910	Obsolete	0.00
4911	Obsolete	0.00
4916	Obsolete	0.00
4918	Obsolete	64.30
4923	Use 3434	91.34
4925	Obsolete	0.00
4930	Obsolete	0.74

SPARE PARTS

Part No.	Description	Price
4931	Pump Over-Run Thermostat	7.48
4932	Obsolete	8.97
4934	Obsolete	0.00
4935	Obsolete	0.00
4936	Obsolete	0.71
4937	Obsolete	0.00
4943	Obsolete	0.00
4944	Obsolete	0.00
4949	Obsolete	0.00
4961	Thermocouple	7.48
4962	Obsolete	209.87
4965	Obsolete	8.97
4975	Obsolete	0.00
4976	Obsolete	0.00
4977	Obsolete	0.00
4980	Obsolete	1.80
4981	Obsolete	0.00
4983	Obsolete	2.50
4994	Obsolete	0.00
4998	Obsolete	0.00
5023	3/4" Fibre Washer	0.35
5024	Obsolete	0.00
5025	Washer	0.75
5026	1/2" Fibre Washer	0.30
5027	Obsolete	8.97
5029	Obsolete	0.78
5036	Pump Washer	0.75
5038	Washer	0.35
5039	Washer	0.35
5040	Obsolete	0.77
5041	Washer	0.15
5042	Washer	0.20
5048	Obsolete	0.29
5049	Gasket	0.45
5050	Obsolete	0.00
5052	Clip	0.25
5055	Obsolete	0.00
5067	Obsolete	0.03
5068	Seal	0.40
5070	Fibre Washer	0.25
5071	Fibre Washer	0.20
5072	Fibre Washer	0.50
5077	Screw	0.10
5078	Obsolete	0.00
5079	Screw	0.08
5080	Screw	0.15
5081	Screw	0.18
5082	Obsolete	0.00
5083	Screw	0.10
5084	Obsolete	0.00
5085	Obsolete	0.06
5086	Obsolete	8.97
5092	Obsolete	0.02
5093	Obsolete	0.06
5094	Obsolete	0.04
5095	Obsolete	0.00
5097	Obsolete	3.39
5105	Machine Screw M4 x 10mm	0.75
5111	Obsolete	0.00
5122	Obsolete	0.06
5124	Screw	0.25
5128	Edge Clip	0.15
5129	Obsolete	0.02
5131	Obsolete	0.48
5132	Obsolete	0.00
5133	Obsolete	0.00
5134	Obsolete	0.00
5136	Obsolete	0.00
5140	Obsolete	0.00
5141	Obsolete	0.00

SPARE PARTS

Part No.	Description	Price
5142	Obsolete	8.97
5143	Obsolete	0.04
5150	Obsolete	0.00
5151	Edge Clip	0.14
5155	Obsolete	0.00
5163	Obsolete	0.00
5166	Obsolete	0.06
5168	Rivet	0.05
5169	Obsolete	0.00
5170	Screw	0.35
5171	Obsolete	0.12
5172	Burner Plate	0.25
5174	Obsolete	0.05
5175	Obsolete	0.04
5176	Screw	0.25
5178	Obsolete	0.00
5179	Obsolete	0.00
5180	Obsolete	8.97
5182	Obsolete	0.00
5183	Machine Screw Hex Head M6 x 13	0.89
5184	Machine Screw Hex Head M4 x 12	0.75
5186	Obsolete	8.97
5187	Obsolete	0.00
5188	Obsolete	0.25
5192	Fibre Washer	0.30
5195	Fibre Washer	0.30
5197	Obsolete	0.47
5203	Plastic Washer	0.15
5207	Obsolete	0.00
5208	Washer	0.15
5209	Obsolete	0.70
5212	Obsolete	0.00
5213	Small Screw DHW Heat Exchanger	0.70
5214	Large Screw DHW Heat Exchanger	0.80
5216	Obsolete	2.34
5219	Obsolete	0.00
5221	Use 20101312	0.74
5224	Clip	0.60
5228	Obsolete	0.14
5230	Clip	0.40
5231	Obsolete	0.08
5235	Screw	0.55
5236	Washer	0.55
5237	Washer 28mm	0.70
5240	Obsolete	0.09
5251	Obsolete	0.00
5254	Obsolete	0.00
5255	Obsolete	3.02
5256	Obsolete	3.02
5258	Obsolete	9.33
5259	Obsolete	0.00
5261	Obsolete	0.00
5262	Temperature Gauge	14.08
5263	Pressure Gauge	17.25
5264	Obsolete	1.17
5266	Obsolete	3.51
5269	Front Insulation Panel for Combustion Chamber	6.14
5270	Rear Insulation Panel for Combustion Chamber	5.88
5271	Side Insulation Panel for Combustion Chamber	7.55
5275	Obsolete	3.93
5277	Obsolete	34.59
5279	Gas valve support	1.86
5280	Pilot Assembly	11.64
5284	Obsolete	0.00
5295	Use 10020104	55.52
5296	Obsolete	0.00
5297	Main Burner LPG	78.65
5298	Obsolete	0.29
5299	Obsolete	0.00
5300	Metal Side Panel (L/H)	3.57

SPARE PARTS

Part No.	Description	Price
5301	Spindle	2.67
5303	Obsolete	0.24
5304	Plastic Bush	1.08
5305	Obsolete	2.07
5309	Spark electrode	6.32
5312	Back Side of Comb Chamber	6.04
5313	Obsolete	6.74
5315	Front Insulation Panel for Combustion Chamber	6.95
5316	Rear Insulation Panel for Combustion Chamber	6.57
5317	NG Burner (replaces 48929 and 10027564)	89.24
5318	Obsolete	0.00
5319	Main Burner LPG	90.95
5320	Obsolete	35.26
5322	Screw M5X45	1.14
5323	Washer	0.30
5329	Obsolete	3.10
5332	Obsolete	3.70
5333	Obsolete	0.35
5335	Obsolete	8.25
5351	Heat Exchanger	178.22
5356	Heat Exchanger	209.07
5366	Obsolete	7.48
5371	Obsolete	0.00
5388	Heat Exchanger with 2 x 5023 Washers	133.65
5394	Obsolete	24.94
5396	Obsolete	31.79
5436	Obsolete	8.97
5437	Obsolete	1.45
5438	Gas Valve	135.47
5441	High-limit Thermostat	5.95
5455	Obsolete	0.32
5456	Obsolete	1.19
5470	Obsolete	0.00
5472	Thermostat Clip	1.06
5475	Obsolete	0.00
5588	Obsolete	0.29
5589	Obsolete	13.21
5591	Obsolete	2.88
5592	Mode Selector Switch	2.52
5602	Obsolete	0.00
5603	Obsolete	0.00
5604	Obsolete	91.11
5606	Obsolete	148.85
5617	Obsolete	0.00
5631	Obsolete	5.97
5634	Gas Valve	175.16
5635	Obsolete	0.33
5637	Use 0940	0.00
5638	Obsolete	0.00
5640	Spark Electrode & Lead	12.46
5641	Sensing Electrode & Lead	12.46
5643	Circuit Board	141.26
5731	Obsolete	7.72
5733	Obsolete	8.97
5735	Obsolete	24.08
5739	Use 2076	116.83
5741	Obsolete	8.97
5742	Plate for gap between fan and Fan flue connector	1.58
5744	Obsolete	8.97
5753	Use 10027352	8.97
5757	Obsolete	0.82
5758	Obsolete	0.38
5776	Obsolete	0.00
5784	Obsolete	0.20
5797	Circuit Board	114.11
5798	Obsolete	129.52
5800	Piezo Ignitor	11.64
5808	Obsolete	75.09
5809	Obsolete	0.00

SPARE PARTS

Part No.	Description	Price
5811	Obsolete	0.00
5812	Main Burner NG	45.24
5813	Obsolete	0.00
5814	Obsolete	5.03
5852	Obsolete	121.65
5853	Electrode & Lead	12.46
5863	Gas Valve Gasket	0.50
5868	Obsolete	0.00
5869	Obsolete	1.27
5870	Obsolete	9.37
5876	Obsolete	0.00
5899	Obsolete	13.95
5900	Obsolete	0.00
5901	Obsolete	0.00
5903	Use 7705	0.00
5904	Obsolete	19.90
5905	Combustion Chamber seal (1 metre)	1.88
5906	Hood Assembly	27.95
5907	Hood Assembly	29.07
5908	Combustion Chamber Front (Metal)	7.68
5909	Combustion Chamber Front (Metal)	8.61
5910	Fan Assembly	84.67
5911	Fan Assembly	100.70
5912	Fan Gasket	10.06
5913	Flue Connection	7.08
5914	Obsolete	7.08
5915	Obsolete	0.00
5916	Use 7315	0.22
5917	Use 7317	1.48
5921	Venturi	8.09
5922	Obsolete	1.02
5923	Obsolete	1.44
5924	Obsolete	1.14
5926	Pressure Switch	50.85
5927	Seal	3.60
5929	Pipe	12.66
5930	Pipe	13.34
5931	Obsolete	40.80
5932	Obsolete	25.38
5938	Obsolete	3.33
5940	Obsolete	2.55
5944	Silicone Tube	1.66
5945	Obsolete	6.55
5948	Obsolete	0.00
5949	Air Baffle	1.61
5950	Obsolete	0.00
5951	Obsolete	0.32
5956	Obsolete	7.42
5957	Combustion Chamber Cover	14.30
5958	Hood Assembly	25.15
5960	Use 2819	5.17
5961	Combustion Chamber Front Panel	4.53
5962	Combustion Chamber Back Panel	4.53
5963	Fan Assembly	111.38
5964	Obsolete	9.08
5965	Obsolete	5.97
5966	Obsolete	0.00
5967	Obsolete	31.65
5968	Pump Pipe	7.52
5969	Obsolete	0.00
5970	Obsolete	16.04
5971	Silicon Tube	5.54
5972	Obsolete	0.00
5973	Obsolete	0.49
5974	Obsolete	8.61
6025	15/50 excel complete pump assy	176.14
6026	Combustion Chamber Assembly	16.44
6027	Combustion Chamber	17.36
6028	Combustion Chamber	17.79

SPARE PARTS

Part No.	Description	Price
6151	Obsolete	2.38
6160	Obsolete	0.00
6172	Obsolete	6.53
6173	Obsolete	26.51
6208	Obsolete	0.60
6228	Fan to Flue Connector (without Venturi's)	6.54
6266	Obsolete	0.00
6351	Obsolete	10.55
6352	Obsolete	134.02
6354	Obsolete	8.97
6357	Obsolete	6.53
6371	Obsolete	27.15
6373	Obsolete	0.00
6374	Obsolete	0.00
6375	Obsolete	5.74
6376	Obsolete	73.53
6377	Obsolete	0.00
6382	Obsolete	0.00
6384	Obsolete	25.60
6385	Obsolete	0.00
6387	Obsolete	83.29
6388	Obsolete	19.95
6394	Obsolete	0.00
6395	Obsolete	2.78
6396	Obsolete	7.48
6397	Obsolete	0.00
6398	Obsolete	62.15
6399	Use 4888	17.29
6400	Obsolete	0.00
6466	Reset Button	6.15
6471	Obsolete	7.25
6493	Resistor Replaced 4028	12.93
6494	Obsolete	3.09
6495	Obsolete	0.00
6516	Obsolete	151.90
6614	High Limit Stat	7.08
6615	Obsolete	0.48
6624	Obsolete	0.43
6638	Obsolete	23.25
666	Clip 24M	0.12
6676	Obsolete	0.80
6678	Obsolete	182.43
6679	Obsolete	0.00
6681	Obsolete	299.02
6685	Obsolete	0.00
6692	Obsolete	0.00
6693	Obsolete	24.98
6694	Obsolete	0.00
6695	Obsolete	0.00
6696	Obsolete	0.00
6704	Obsolete	84.54
6705	Obsolete	38.41
6706	Obsolete	0.00
6759	Obsolete	0.00
6781	Obsolete	13.94
6785	Obsolete	0.00
6802	Obsolete	16.09
6814	Obsolete	0.00
6815	Obsolete	248.12
6817	Obsolete	0.00
6818	Obsolete	0.00
6851	Obsolete	102.41
6853	Flow Manifold Cover	9.80
6854	Obsolete	0.00
6855	Nut (Rear of Flow Manifold)	7.29
6856	Obsolete	0.00
6857	Safety Valve Sleeve	4.98
6858	Obsolete	4.02
6859	Nut	2.30
6860	Front Seal	6.39



SPARE PARTS

Part No.	Description	Price
6862	Spring	2.43
6863	Use 8436	1.62
6864	Use 8437	1.62
6865	Spring	1.94
6866	Use 2910	1.62
6867	Bearer Plate	2.58
6868	Obsolete	4.77
6870	Washer	1.06
6871	Use 8441	0.90
6872	Diaphragm	2.00
6873	Use 8435	0.00
6874	Screw	1.30
6876	Front Plate	48.44
6877	Obsolete	4.00
6878	Obsolete	3.33
6879	Spring	0.75
6882	Diaphragm	4.75
6883	Bearer Plate	2.94
6884	Use 8438	0.00
6886	Venturi	4.62
6887	Push Rod	1.51
6888	Push Rod	1.21
6890	Push Rod	7.19
6891	Nut	14.95
6893	Use 1489	0.00
6894	O'Ring	0.85
6895	O'Ring	1.98
6896	Nut	7.97
6897	Pump Washer	0.60
6898	O Ring	0.85
6901	Use 01005043	0.00
6902	Obsolete	21.51
6903	Screw	1.27
6911	Obsolete	1.14
6912	Inlet Pipe	13.79
6913	Outlet Pipe	13.74
6914	Obsolete	2.09
6919	Front Seal	3.96
6920	Obsolete	0.36
6921	Obsolete	10.87
6985	Venturi (Positive)	3.87
7022	Use 10027352	0.00
7068	Obsolete	0.00
7070	Use 01005272	0.00
7071	Obsolete	7.31
7076	Obsolete	2.38
7081	Obsolete	119.14
7082	Obsolete	27.42
7085	Obsolete	328.91
7094	Obsolete	13.29
7095	Obsolete	85.22
7096	Main Burner	98.69
7097	Ignition Control PCB	197.76
7098	Gas Cock	20.81
7099	Water Supply Stop Cock	13.59
7100	3/4" Flow/Return Valve 90 Deg	22.51
7126	Obsolete	0.00
7130	By-Pass Retaining Nut	2.68
7131	Domestic By-Pass	2.68
7132	Domestic Manifold Top	107.63
7133	Obsolete	0.00
7134	Seating Plate	3.80
7135	O'Ring	1.02
7139	Non Return Valve	6.14
7140	Domestic Heat Exchanger	139.29
7141	Domestic Heat Exchanger	150.57
7153	Obsolete	0.00
7157	Obsolete	39.90
7159	Pressure Gauge	16.37
7160	Obsolete	1.58

SPARE PARTS

Part No.	Description	Price
7171	Use 4441	10.12
7172	Obsolete	0.36
7174	Obsolete	107.99
7175	Obsolete	0.00
7192	Obsolete	4.69
7201	Obsolete	61.06
7204	Expansion vessel 8L	84.76
7206	Obsolete	84.45
7207	Expansion Pipe	10.00
7209	Obsolete	0.00
7210	Obsolete	0.00
7211	Obsolete	18.61
7212	Obsolete	0.00
7216	Obsolete	0.00
7221	Pump Cable	6.98
7230	Obsolete	11.61
7232	Bridge	0.40
7233	Pipe	14.28
7236	NTC Sensor Rep 105922	8.05
7237	Obsolete	34.37
7238	Obsolete	1.02
7239	Pressure/Temp Gauge	29.80
7240	Obsolete	1.89
7243	L.E.D Plug and Lead	11.30
7260	Gas Valve	156.06
7261	Obsolete	0.00
7266	Obsolete	34.44
7280	Fan to Flue Connector (Without Venturi's)	7.07
7281	Silicon Tube	2.26
7301	Obsolete	0.00
7303	Gas Control Knob	3.72
7304	Obsolete	1.63
7311	High Limit Thermostat	24.76
7314	Obsolete	30.98
7315	Clamp	1.30
7316	Clamp	2.67
7317	Washer	1.06
7318	Washer	1.45
7330	Gas cock	30.48
738	Clock Wires (Twin Channel)	0.00
7602	Obsolete	132.06
7615	Heat Ex. Return Pipe	13.64
7616	Obsolete	114.95
7618	Use 5910	57.38
7619	Obsolete	0.00
7620	Expansion Vessel	82.41
7621	Heating Manifold	163.86
7622	Obsolete	0.00
7623	NG Burner	64.13
7624	Obsolete	64.73
7625	Gas valve	163.86
7701	Obsolete	2.86
7705	Obsolete	13.41
7714	Obsolete	14.55
7715	Obsolete	0.00
7723	Obsolete	2.78
7724	Obsolete	2.95
7725	Obsolete	16.75
7776	Obsolete	0.00
7777	Obsolete	0.00
7778	Obsolete	9.91
7779	Obsolete	10.72
7780	Pump Cable	5.83
7781	Pipe	12.64
7782	Obsolete	10.08
7783	Obsolete	15.98
7784	Obsolete	39.43
7785	Obsolete	5.28
7786	Obsolete	3.83
7787	Obsolete	2.26

SPARE PARTS

Part No.	Description	Price
7788	Bracket	2.26
7789	Obsolete	2.75
7790	Obsolete	1.02
7791	Ignition Box (Ineco)	134.54
7792	Obsolete	0.00
7793	Obsolete	0.00
7796	Obsolete	81.72
7804	Obsolete	141.09
7805	Use 10020076	13.87
7806	Combustion Chamber	33.52
7808	Ng burner	72.82
7809	NP 9 Main Burner LPG	89.17
7810	Heat Exchanger with 2 x 5023 Washers	152.96
7811	Use 2936	0.00
7812	Combustion Chamber Back Cover	5.47
7813	Combustion Chamber - Front	24.76
7814	Obsolete	0.00
7815	L/H Fan Baffle	15.75
7816	Obsolete	9.02
7817	Front Insulation Panel for Combustion Chamber	7.65
7818	Rear Insulation Panel for Combustion Chamber	7.00
7819	Obsolete	16.42
7820	Obsolete	17.39
7821	Obsolete	0.00
7822	Combustion Chamber Front Panel	16.62
7824	Air box side	23.68
7831	Obsolete	0.00
7832	Obsolete	0.00
7835	Use 9763	0.00
7836	Obsolete	16.13
7840	Obsolete	16.89
7841	Obsolete	84.99
7842	Obsolete	0.00
7843	Pipe	11.68
7844	Obsolete	21.87
7845	Obsolete	0.00
7846	Obsolete	0.00
7849	Air Chamber	40.07
7850	Obsolete	12.55
7905	Obsolete	103.51
7912	Obsolete	2.09
7915	Obsolete	0.76
7920	Obsolete	50.14
7948	Venturi Rep 6984 (Negative)	8.75
7999	O'Ring	0.55
8008	Flow governor (White)	4.20
8009	Flow governor (Blue)	2.88
8030	Brass Sleeve	10.79
8031	Modulator coil	25.83
8036	Domestic Heat Exchanger (with 4 x 7999 O'rings)	100.70
8037	Domestic Heat Exchanger	109.08
8076	Obsolete	0.00
8079	Obsolete	35.77
8083	Fan Flue Tube	9.35
8084	Air Box Hole Cap	3.23
8085	Use 10026933	0.00
8086	Brass Cap	2.04
8088	Obsolete	0.00
8094	Obsolete	0.88
8098	Obsolete	1.86
8158	Room sealed chamber	47.99
8159	Obsolete	16.13
8160	Obsolete	11.35
8161	Obsolete	4.99
8162	Obsolete	2.40
8163	Obsolete	24.01
8165	Obsolete	0.00
8166	Main Printed Circuit Board	44.78
8167	Obsolete	83.07
8173	Circuit Board	163.86

SPARE PARTS

Part No.	Description	Price
8174	Obsolete	134.85
8193	Obsolete	97.68
8194	Obsolete	96.99
8195	Use 01005272	30.11
8196	Obsolete	0.00
8199	Obsolete	38.50
8200	Obsolete	133.11
8214	Ignition Box (Brahma)	118.91
8221	Obsolete	4.41
8277	Gas Valve	146.91
8282	Spark Electrode Inc Lead	11.60
8283	Obsolete	6.27
8301	Sensing Electrode with Lead	14.47
8306	Obsolete	0.41
8308	Spark Electrode	14.43
8319	Obsolete	39.38
8322	Obsolete	2.35
8344	Obsolete	58.75
8345	Gas Valve	209.87
8346	Obsolete	38.44
8347	Obsolete	0.00
8348	Obsolete	0.00
8349	Obsolete	30.73
8350	Obsolete	0.00
8353	Printed Circuit Board	87.63
8354	Obsolete	6.27
8355	Pressure Gauge	13.39
8360	Ignition Box (9962)	159.82
8361	Obsolete	0.38
8364	Spark Electrode Inc Lead	12.46
8367	Use 2258	0.00
8377	Pressure Gauge	15.78
8378	Quick primer pressue gauge	12.50
8381	3 Way Valve	129.96
8402	Obsolete	0.00
8404	Obsolete	0.00
8428	Heating Manifold	84.76
8429	Domestic Manifold	43.74
8430	Htg. Manifold Top	16.39
8431	Dom. Manifold Top	37.67
8432	Exchanger Connection	12.81
8433	Use 2907	11.46
8434	Venturi	2.67
8435	By-Pass Bobbin	1.13
8436	By-Pass Spring	1.54
8437	Spring	1.54
8438	Spring	1.34
8439	Plug	5.55
8440	Seating Plate	3.62
8441	Seating	3.72
8442	Fulcrum Arm	5.66
8444	O'Ring	1.47
8445	Gasket	0.75
8446	Use 1489	0.00
8447	Use 01005177	7.39
8448	Screw	0.85
8460	Pipe	12.45
8465	Obsolete	4.98
8468	Use 01005177	10.90
8477	Obsolete	4.29
8478	Spark Electrode with Lead	13.50
8481	Printed Circuit Board	153.01
8484	Use 10027352	8.06
8528	Obsolete	7.25
8529	Obsolete	7.92
8530	Obsolete	7.92
8533	Heating Distribution Manifold	197.76
8536	Domestic Water Manifold	73.46
8537	Connection	6.34
8538	Pressure Sensor Pipe	8.88

SPARE PARTS

Part No.	Description	Price
8539	Deressure Sensor Pipe	8.88
8540	Obsolete	0.48
8541	Clip	0.60
8542	O-Ring	0.60
8544	Obsolete	14.65
8545	Obsolete	1.98
8546	Obsolete	3.14
8547	Combined High limit Flue Stat	22.43
8548	Expansion Vessel Pipe (Maxin)	9.19
8549	Flow Pipe	20.90
8550	Obsolete	17.22
8558	Microswitch Clip	0.55
8559	Obsolete	51.22
8584	Pipe	16.53
8585	Pipe	12.78
8589	Obsolete	14.21
8602	Use 1606	42.98
8607	Obsolete	50.42
8631	Obsolete	88.08
8633	Obsolete	3.55
8634	Obsolete	2.94
8635	Obsolete	0.96
8654	Clock Blanking Plate	1.77
8673	Obsolete	1.32
8675	Flue Clamp and Gasket	4.99
8799	Obsolete	81.72
8809	Gauge	22.43
8852	Use 1191	30.25
8855	NTC Sensor	19.37
8860	Use 1194	7.74
8861	Obsolete	18.61
8862	Obsolete	0.00
8863	Obsolete	0.00
8864	Obsolete	169.77
8866	Brass Cap	1.00
8868	Pipe	19.65
8869	Obsolete	8.97
8871	Obsolete	18.10
8872	Use 9731	14.39
8873	Fitting/union	5.72
8874	Use 9730	8.34
8876	Pump	167.42
8877	Obsolete	8.40
8878	Use 1044	0.00
8880	Obsolete	65.46
8881	Obsolete	11.19
8882	Use 1035	0.00
8883	Obsolete	1.68
8884	Use 2810099	253.86
8885	Use 1033	0.00
8886	Obsolete	145.43
8887	Use 1016	0.00
8888	Use 1193	0.00
8889	Use 1196	0.00
8890	Spreader Plate	18.67
8891	Use 10022853	0.00
8892	Use 1019	0.00
8893	Fan Gasket	4.73
8896	Gasket	0.55
8897	Obsolete	8.40
8899	Use 9299	0.84
8900	Pilot Glass	2.50
8901	Obsolete	0.53
8902	Washer	1.53
8903	Washer	0.81
8904	Sleeve	2.26
8906	Obsolete	14.56
8907	Obsolete	9.66
8908	Obsolete	6.71
8909	Plug	2.71

SPARE PARTS

Part No.	Description	Price
8910	Non Return Valve	3.24
8911	Extension for AAV's (4254 + 9806)	3.81
8912	Washer	4.20
8913	Obsolete	5.21
8914	Gasket	0.90
8915	Obsolete	4.99
8916	Pressure Nipple	1.37
8918	Input P.C.B.	103.75
8921	Obsolete	7.75
8922	Obsolete	17.41
8951	Obsolete	493.67
8952	Obsolete	20.13
8953	Obsolete	71.84
8954	Obsolete	2.43
8955	Pipe	31.53
8956	Pipe	9.31
8957	Pipe	16.66
8958	Connection Manifold	15.40
8959	O'Ring	0.80
8960	Obsolete	61.87
8967	Obsolete	1.83
8968	Fuse (Individual) 2 AMP	0.65
8969	3.15 Amp fuse	0.65
8970	Main Burner Jet NG 3.8	4.67
8974	Obsolete	8.97
8975	Washer	2.26
9129	Obsolete	2.03
9154	Obsolete	8.97
9156	Obsolete	8.97
9164	Use 7281	0.00
9232	Use 01005272	0.00
9233	Obsolete	0.69
9263	Pump Lock Key	0.70
9264	Combustion chamber	14.35
9265	Obsolete	51.74
9266	Expansion Vessel - (8548 Pipe Needed If Old Vessel is Rectangle)	78.96
9268	Return Distribution Manifold	104.38
9269	Obsolete	495.45
9270	Obsolete	511.68
9271	Safety Valve Pipe	7.27
9272	Obsolete	13.06
9273	Obsolete	45.20
9274	Obsolete	15.05
9275	Obsolete	0.00
9285	Burner Washer	14.95
9286	Obsolete	0.53
9287	Washer	6.52
9288	Spark Electrode	8.61
9289	Obsolete	0.27
9291	Obsolete	0.00
9292	Screw	6.18
9295	Main burner jet LPG	8.62
9296	Spring	0.60
9299	Washer	0.60
9430	Flow governor (Red)	2.88
9461	Selector Switch	3.60
9576	Obsolete	20.38
9581	Use 0443/10SE 0444/14SE 0445	0.00
9582	Pressure Gauge	15.30
9583	Obsolete	8.97
9586	Mynute 10, 14 & 20SE Harness	58.96
9587	Obsolete	31.02
9594	Pipe	24.00
9599	Knob	1.83
9695	Thermostat	6.32
9696	Obsolete	8.97
9701	Front Panel	20.41
9709	Clock blanking plate	4.44
9716	Eclipse ESS Printed Circuit Board	379.88
9718	Flow governor (Black)	4.10

SPARE PARTS

Part No.	Description	Price
9730	Condense Connecting Nipple	9.03
9731	Condense Pipe replaced 8872	18.03
9732	Washer	0.70
9752	Cover	0.60
9753	Obsolete	2.63
9754	Obsolete	39.17
9756	Expansion Vessel Pipe	9.98
9757	Obsolete	12.83
9758	Pipe	18.76
9759	Knob	1.62
9761	Obsolete	113.98
9762	Obsolete	119.65
9763	3/4" Flow/Return Valve Straight	25.11
9764	Water Stop Cock	20.38
9766	Connection	7.56
9771	Obsolete	7.27
9772	Obsolete	25.46
9773	Water Supply Stop Cock	24.58
9774	Mixing Valve	114.65
9786	Obsolete	13.03
9794	Eclipse ESC Printed Circuit Board	379.88
9797	Gas Cock	19.86
9799	Obsolete	58.82
9800	Ignition Box	147.99
9805	Air Switch Bracket	1.00
9806	Auto Air Vent	9.14
9807	Fitting/union	14.48
9814	Obsolete	3.57
9842	Gas Valve	134.54
9849	Use 9806	6.95
9959	Use 1196	127.70
9960	Spark Electrode Cable	14.69
B81508	Case	0.00
B81510	Pressure Switch	249.39
B81511	Premix Burner	223.03
B81512	Detector	46.82
B81513	Pipe	73.62
B81514	Pipe	23.98
B81515	Use 105910	67.60
B81516	Replace Pipe 105910	16.55
B81517	Wiring Harness	56.23
B81518	Slave Wiring Harness	158.33
B81519	Master Wiring Harness	84.76
B81520	Serial Wiring	68.01
S10002	Obsolete	0.81
S10003	Obsolete	71.44
S10005	Obsolete	0.93
S10006	Obsolete	0.20
S10007	Obsolete	1.34
S10008	Obsolete	6.78
S10009	Obsolete	0.70
S10010	Obsolete	5.78
S10011	Obsolete	0.00
S10012	Obsolete	2.87
S10013	Use 10024364	0.00
S10014	Obsolete	1.12
S10015	Obsolete	8.68
S10017	Obsolete	2.69
S10018	Obsolete	0.20
S10019	Obsolete	0.32
S10020	Obsolete	26.70
S10021	Obsolete	0.60
S10023	Obsolete	2.72
S10024	Obsolete	0.82
S10025	Obsolete	7.55
S10026	Obsolete	1.47
S10027	Obsolete	7.55
S10028	Obsolete	0.82
S10029	Obsolete	14.40
S10030	Obsolete	15.09

SPARE PARTS

Part No.	Description	Price
S10031	Obsolete	2.68
S10032	Obsolete	15.09
S10033	Obsolete	6.04
S10034	Obsolete	1.12
S10035	Obsolete	10.06
S10036	Obsolete	8.60
S10037	Obsolete	1.86
S10038	Obsolete	0.45
S10040	Obsolete	0.45
S10041	Obsolete	6.35
S10042	Obsolete	0.81
S10048	Obsolete	9.87
S10049	Obsolete	4.94
S10050	Obsolete	0.00
S10055	Obsolete	112.46
S10057	Obsolete	107.74
S10061	Obsolete	1.21
S10063	Use 5911	106.84
S10064	Use 10023699	0.00
S10069	Obsolete	37.73
S10070	Obsolete	50.32
S10071	Obsolete	2.75
S10082	Obsolete	0.20
S10083	Obsolete	0.12
S10084	Obsolete	2.26
S10086	Obsolete	4.94
S10087	Obsolete	4.94
S10088	Obsolete	4.94
S10089	Obsolete	4.94
S10090	Obsolete	31.37
S10091	Obsolete	9.98
S10092	Obsolete	57.84
S10093	Obsolete	0.66
S10095	Obsolete	0.32
S10096	Use S10098	2.06
S10097	Obsolete	4.54
S10098	Obsolete	2.06
S10099	Obsolete	0.72
S10106	Obsolete	0.20
S10108	Obsolete	6.78
S10111	Obsolete	1.26
S10113	Obsolete	6.78
S10114	Obsolete	0.12
S10115	Obsolete	178.37
S10116	Obsolete	100.62
S10118	Obsolete	104.02
S10119	Obsolete	6.78
S10123	Obsolete	1.32
S10124	Obsolete	1.21
S10129	Obsolete	0.00
S10131	Obsolete	0.04
S10132	Obsolete	13.58
S10133	Obsolete	127.07
S10134	Obsolete	0.76
S10135	Obsolete	0.47
S10137	Obsolete	3.57
S10140	Obsolete	1.59
S10144	Obsolete	7.55
S10145	Use S10144	7.55
S10148	Not available Complete	74.14
S10149	Use 10021235	9.65
S10153	Obsolete	5.63
S10154	Obsolete	4.14
S10160	Obsolete	0.40
S10164	Obsolete	0.17
S10166	Obsolete	6.03
S10167	Obsolete	198.72
S10168	Obsolete	143.97
S10169	Obsolete	1.30
S10170	Obsolete	0.36

## SPARE PARTS

Part No.	Description	Price
S10171	Obsolete	0.00
S10172	Obsolete	1.74
S10173	Obsolete	1.74
S10174	Obsolete	0.00
S10176	Obsolete	4.45
S10177	Obsolete	5.32
S10178	Obsolete	0.00
S10179	Obsolete	66.87
S10180	Obsolete	12.46
S10181	Obsolete	7.55
S10182	Obsolete	4.27
S10183	Use S10118	0.00
S10184	Obsolete	2.30
S10185	Obsolete	0.22
S10186	Obsolete	0.19
S10187	Obsolete	5.90
S10188	Obsolete	1.30
S10189	Obsolete	7.85
S10190	Obsolete	7.85
S150	Aquanova hanging bracket	5.71
S152	Knob	7.36
S159	Valve	96.05
S419	Obsolete	45.73
S432	Lateral Insulating Panel	5.39
S433	Front Insulating Panel	5.39
S435	Rear Insulating Panel	5.39
S438	Proof Chamber Cover (W7050168)	22.65
S474	Proof Chamber Cover	28.22
S538	Sensing Electrode	16.13
S597	Spring	1.10
S606	Frame (W7050335)	23.33
S612	Sight glass Kit	7.20
S656	Burner (without diffuser)	106.23
S659	Obsolete	31.37
S660	LPG Diffuser (for Burner)	31.37
S663	Hood Assembly	35.86
S675	Sensing Electrode (W7080195)	26.89
S757	Adaptor Ring	2.70
S758	Fan	94.11
T0001	Service Kit	43.32
T0002	3 Port Valve Service Kit	41.81
T0019	Excell Service Kit	30.38
T0028	Wind Modification Kit	19.94
T0041	Blanking Kit	4.68
T0042	Obsolete	13.46
T0043	Obsolete	11.25
T0044	Obsolete	9.50
T0045	Obsolete	13.46
T0053	Obsolete	13.73
T0055	Obsolete	0.13
T0058	Maxin Service Kit	41.43
T0063	Linea Service Kit	30.50
T0078	Use 1859	2.04
T0079	Use 1860	2.04
T0090	Linea 7/Syntesi service kit	21.61
W7060407	Use S150	0.00

## SPARE PARTS

Part No.	Description	Price
6090	Pump 25-50	91.49
6110	Pump 25-60	67.38
T0046	Gas valve adjustment tool	12.15
T0052	Venturi Extractor	9.50

\*No discount available on these items.



**Registered address:**

Vokera Ltd  
Borderlake House  
Unit 7 Riverside Industrial Estate  
London Colney  
Herts AL2 1HG

[enquiries@vokera.co.uk](mailto:enquiries@vokera.co.uk)

[www.vokera.co.uk](http://www.vokera.co.uk)  
[www.vokera.ie](http://www.vokera.ie)

**Sales, General Enquiries:**

**T** 0844 391 0999

**F** 0844 391 0998

Vokera Ireland  
West Court, Callan  
Co Kilkenny  
**T** 056 7755055  
**F** 056 7755060

Vokera Limited reserve the right to change  
specification without prior notice.  
Consumers statutory rights are not affected.

Company Reg No: 1047779

Search Vokera Ltd

