▲/▼	Changes the set room temperature
◄/►	Changes the operating program
⮌	Takes you one step back in the menu
OK	Confirms your selections or settings
?	Calls up additional information
☰	Calls up the extended menu
✥	Cursor keys Scroll through the menu or adjust values

Extended menu

Press ☰



Note

The maximum number of displays is shown. Depending on the system equipment level, some displays will not appear.

5592 693 GB Subject to technical modifications