

Eurocondense three

Installation operation and maintenance manual

Floor Standing Condensing Gas Boilers

125 to 300kW



Working towards
a cleaner future

POTTERTON
COMMERCIAL

heating specialists

Table of contents

| | | |
|-----------|--|-----------|
| 1. | Regarding this Manual..... | 5 |
| 1.1 | Content of this manual..... | 5 |
| 1.2 | Overview table..... | 5 |
| 1.3 | Used symbols..... | 6 |
| 1.4 | For whom is this manual intended?..... | 6 |
| 2. | Safety..... | 7 |
| 2.1 | Use appropriate..... | 7 |
| 2.2 | General safety instructions..... | 7 |
| 2.3 | Regulations and standards..... | 8 |
| 2.4 | Liquid gas under ground..... | 8 |
| 2.5 | CE-Marking..... | 8 |
| 2.6 | Conformity declaration..... | 9 |
| 3. | Technical Data..... | 10 |
| 3.1 | Dimensions and connections..... | 10 |
| 3.2 | Technical Data..... | 11 |
| 3.3 | Hydraulic resistance..... | 13 |
| 3.4 | Wiring Diagram..... | 14 |
| 3.5 | Sensor value tables..... | 15 |
| 4. | Before installation..... | 16 |
| 4.1 | Converting the exhaust and supply air connection..... | 16 |
| 4.1.1 | Converting the exhaust connection..... | 16 |
| 4.1.2 | Converting the supply air connection..... | 16 |
| 4.2 | Corrosion protection..... | 18 |
| 4.3 | Requirements for heating circuit water..... | 18 |
| 4.3.1 | Further information on the heating water..... | 19 |
| 4.3.2 | Diagramm Wasserhärte..... | 19 |
| 4.4 | Notes for installation location..... | 21 |
| 4.5 | Space requirement..... | 22 |
| 4.6 | Transportation..... | 23 |
| 4.7 | Application examples..... | 24 |
| 4.8 | Legend..... | 33 |
| 5. | Installation..... | 34 |
| 5.1 | Connect heating circuit..... | 34 |
| 5.2 | Condensate water connection..... | 34 |
| 5.3 | Sealing and filling of the plant..... | 34 |
| 5.4 | Flue system..... | 34 |
| 5.5 | Gas connection..... | 35 |
| 5.6 | Check tightness..... | 35 |
| 5.6.1 | Purging the gas line..... | 35 |
| 5.7 | Factory settings..... | 35 |
| 5.8 | CO ₂ -Content..... | 36 |
| 5.9 | Changing over from LPG to natural gas and vice versa..... | 36 |
| 5.10 | Controller Stop Mode (Manual Adjustment of Burner Load)..... | 37 |
| 5.11 | Check and adjust CO ₂ content..... | 38 |
| 5.12 | Electrical connection (general)..... | 39 |
| 5.12.1 | Cable lengths..... | 39 |
| 5.12.2 | Strain reliefs..... | 39 |
| 5.12.3 | Circulating pumps..... | 39 |
| 5.12.4 | Fuses..... | 40 |
| 5.12.5 | Connection sensor / components..... | 40 |
| 5.12.6 | Replacing cables..... | 40 |

| | | |
|-----------|--|------------|
| 5.12.7 | Protection against contact..... | 40 |
| 6. | Commissioning..... | 41 |
| 6.1 | Menu-Commissioning..... | 41 |
| 6.2 | Check water pressure..... | 41 |
| 6.3 | Switching-on..... | 41 |
| 6.4 | Temperatures for heating and drinking water..... | 42 |
| 6.5 | Individual time programme..... | 42 |
| 6.6 | Instruction for the customer..... | 42 |
| 7. | Operation..... | 44 |
| 7.1 | Operating elements..... | 44 |
| 7.2 | Display..... | 45 |
| 7.3 | Setting up heating operation..... | 45 |
| 7.4 | Stop drinking water operation..... | 46 |
| 7.5 | Setting room setpoint..... | 46 |
| 7.6 | Display information..... | 47 |
| 7.7 | Error message..... | 47 |
| 7.8 | Servicing message..... | 48 |
| 7.9 | Emergency mode (Manual control)..... | 48 |
| 7.10 | Restoring factory setting..... | 48 |
| 8. | Programming..... | 49 |
| 8.1 | Programming procedure..... | 49 |
| 8.2 | Modification of parameters..... | 50 |
| 8.3 | Setting table..... | 52 |
| 8.4 | Explanations for setting table..... | 78 |
| 8.4.1 | Time and date..... | 78 |
| 8.4.2 | Operator section..... | 78 |
| 8.4.3 | Radio..... | 80 |
| 8.4.4 | Time programs..... | 80 |
| 8.4.5 | Holiday programs..... | 81 |
| 8.4.6 | Heating circuits..... | 81 |
| 8.4.7 | DHW..... | 90 |
| 8.4.8 | Consumer circuit and swimming pool circuit..... | 92 |
| 8.4.9 | Swimming pool..... | 92 |
| 8.4.10 | Primary contr/system pump..... | 93 |
| 8.4.11 | Boiler..... | 93 |
| 8.4.12 | Cascade..... | 97 |
| 8.4.13 | Solar..... | 98 |
| 8.4.14 | Solid fuel boiler..... | 101 |
| 8.4.15 | Buffer storage..... | 102 |
| 8.4.16 | DHW-storage..... | 104 |
| 8.4.17 | Configuration..... | 108 |
| 8.4.18 | LPB-system..... | 117 |
| 8.4.19 | Fault..... | 118 |
| 8.4.20 | Service / special operation..... | 119 |
| 8.4.21 | Input/output test..... | 120 |
| 8.4.22 | State..... | 120 |
| 8.4.23 | Diagnostics cascade/heat generation/consumers..... | 126 |
| 8.4.24 | Burner control..... | 127 |
| 8.4.25 | Info Option..... | 127 |
| 9. | Maintenance..... | 128 |
| 9.1 | Inspection and need dependent service..... | 128 |
| 9.2 | Boiler view..... | 129 |
| 9.3 | Disassembling and installing burner..... | 130 |
| 9.4 | Check combustion room insulation..... | 133 |
| 9.5 | Installing the combustion room insulation..... | 133 |

| | | |
|------|---|-----|
| 9.6 | Check and replacing Ignition electrode..... | 134 |
| 9.7 | Check and replacing ionisation electrode..... | 135 |
| 9.8 | Electrode spacing and installation locations..... | 136 |
| 9.9 | Clean burner pipe..... | 136 |
| 9.10 | Clean heat exchanger..... | 137 |
| 9.11 | Clean fan..... | 139 |
| 9.12 | Fault switch-off..... | 140 |
| 9.13 | Fault code table..... | 141 |
| 9.14 | Maintenance code table..... | 144 |
| 9.15 | Operating phases of the Control Centre LMS..... | 144 |

1. Regarding this Manual



Read this instruction thoroughly before operating the device!
These instructions are from the original German document.

1.1 Content of this manual

This manual contains the instructions for the installation of the boilers EuroCondense three for standard application with 1 pumped heating circuit and 1 DHW storage tank.

Further applications can be made available (mixing heating circuit, solar connection, etc.) by installing extension modules (clip-ins).

Below is an overview of the further documents relating to this heating system. Keep all documents relating to the boiler on site!

1.2 Overview table

| Documentation | Contents | Intended for |
|---|--|------------------------------|
| Technical information | <ul style="list-style-type: none"> - Planning documents - Description of function - Technical data/circuit diagrams - Basic equipment and accessories - Application examples - Call-for-tender texts | Planner, Heating specialist |
| Installation Handbook | <ul style="list-style-type: none"> - Usage according to purpose - Technical data/circuit diagram - Regulations, standards, CE - Notes for installation location - Application example Standard application - Commissioning, operation and programming - Maintenance | Heating specialist |
| Operating Instructions | <ul style="list-style-type: none"> - Commissioning - Operation - User settings/programming - Disturbance table - Cleaning/maintenance - Energy saving tips | Customer |
| Programming and Hydraulic system manual | <ul style="list-style-type: none"> - Setting table including all parameters and explanations - further application examples | Heating specialist |
| Online database | - Anwendungsbeispiele für registrierte Benutzer auf der Internetseite www.broetje.de | Planner, Heating specialist |
| Asset ledger | <ul style="list-style-type: none"> - Commissioning report - Check list for commissioning - Maintenance | Heating specialist |
| Brief instruction | - Operation in brief | Customer |
| Servicing booklet | - Report of carried out services | Heating specialist |
| Accessories | <ul style="list-style-type: none"> - Installation - Operation | Heating specialist, customer |

Regarding this Manual

1.3 Used symbols



Danger! Danger exists for body and life in case it is not observed.



Danger of electric shock! In case it is not observed, danger from electricity exists for body and life!



Caution! If warning is not observed, danger exists for environment and the device.



Note/tip: Here, you can find background information and useful tips.



Reference to additional information in other documents.

1.4 For whom is this manual intended?

This installation manual is intended for the heating specialist.

2. Safety



Danger! Observe the following safety information! Otherwise you are endangering yourself and others.

2.1 Uso appropriato

Le caldaie condensazione a gas della serie EuroCondense three sono generatori di calore in impianti di riscaldamento ad acqua sanitaria secondo DIN EN 12828. Soddisfano le norme DIN EN 676, DIN 4702 parte 6 e DIN EN 677, tipo installazione B23, C33, C53, C63x e C83.



Per i tipi installazione C₃₃, C₅₃, C_{63x} e C₈₃ osservare le istruzioni del set di accessori.

Paese di destinazione ITA: Categoria II_{2H3+}

2.2 General safety instructions



Danger! Danger to life!

A danger of significant damages to persons, environment and property exists during installation of heating systems. Therefore, heating systems must only be installed by specialist companies and commissioned by specialists of the installing company!



Danger of electric shock! Danger to life due to live components!

All electrical work in connection with the installation must only be carried out by a trained electrician!



Danger! Danger to life if heating unit used improperly!

- This device is not intended to be used by persons (including children) with limited physical, sensory or mental abilities or lack of experience and/or lack of knowledge, only if they are supervised by a person responsible for their safety or receive instructions on how to use the device.
- Children must be supervised to ensure that they do not play with the device.



Danger! Danger to life through modifications to the device!

Unauthorised conversions and modifications of the device are not permitted, as this can endanger persons and lead to damage to the device. In case of not observing this, the approval of the device becomes void.

Setting, maintenance and cleaning of the device must only be carried out by a qualified gas heating specialist!

Used accessories must comply with the technical rules and have been approved in connection with the device by the manufacturer.



Caution! Only original spare parts must be used.

Safety

2.3 Regulations and standards

Beside the general technical rules, the relevant standards, regulations, ordinances and guidelines should be followed:

- DIN 4109; Noise protection in construction engineering
- DIN EN 12828; Heating plants in buildings
- EnEV - Energy saving regulation
- Federal Immission Control Ordinance 3. BImSchV
- DVGW-TRGI 1986 (DVGW-worksheet G 600); Technical Rules for gas installation
- TRF; Technical Rules LPG
- DVGW-Data sheet G 613 Gas appliances- Installation, maintenance and operating instructions
- DIN 18380; Heating plants and central hot water plants (VOB)
- DIN EN 12831; Heating plants in buildings
- DIN 4753; Hot water plants for drinking and water supply
- DIN 1988; Technical Rules for drinking water installations (TRWI)
- VDE 0700-102, DIN EN 60335-2-102: Safety of electrical appliances for household use and similar purposes: Special requirements for gas-, oil- und solid fuel appliances with electrical connections
- Fuel Ordinance, State Ordinances
- Regulations of the local Electricity Board
- Obligation to register (possibly. Group Exemption Regulation)
- ATV-Code-of-practice M251 of the waste water technology association
- Regulations of the Public Authorities for the run-off of condensate.

2.4 Liquid gas under ground

The EuroCondense three complies with DIN EN 126 and DIN EN 298 and, therefore does not need an additional shut-off valve for operation with liquid gas under ground

2.5 CE-Marking

The CE-marking means that the gas-fired fuel value devices meet the requirements of the gas devices guideline 2009/142/EG, the low voltage guideline 2006/95/EG, as well as, the guideline 2004/108/EG (electro-magnetic compatibility, EMV) of the Commission to balance the legal regulations of the member states. Meeting the protection requirements according to guideline 2004/108/EG is only guaranteed by operation of the boiler according to purpose.

The ambient conditions according EN 55014 must be met.

Operation is only allowed with correctly fitted casing.

Correct electrical earthing has to be ensured by regular check (e.g. annual inspection).

When replacing device parts, only original parts as specified by the manufacturer must be used.

The gas condensing-boilers fulfill the basic requirements of the Efficiency Guideline 92/42/EG as condensing boiler.

When natural gas is used, the gas condensing-boiler emit less than 60 mg/kWh NO_x corresponding to the requirements as per §6 of the Ordinance regarding small firing places dated 26.01.2010 (1. BImSchV).

2.6 Conformity declaration



Declaration of conformity

| | |
|------------------------|---|
| Product | Condensing gas boiler |
| Trade mark | EuroCondense |
| Product ID number | CE-0085 CL 0072 |
| Type, Model | EuroCondense three 125, 170, 215, 260, 300 |
| EU directives | 2006/95/EEC, 2004/108/EEC, 90/396/EEC , 92/42/EEC |
| Standards | DIN EN 15417, DIN EN 15420-1, DIN EN 656/A1:2006-12 DIN EN 60335-1 (VDE 0700 Teil 1):2001-08; EN 60335-1:94+A1+A2+A11 bis A16:2001 DIN EN 50366 (VDE 0700 Teil 366):2003-11; EN 50366:2003 DIN EN 50165 (VDE 0700 Teil 450):2001-08; EN 50165:1997+A1:2001 DIN EN 55014-2 (VDE 0875 Teil 14-2):2002-08; EN 55014-2:1997+A1:2001 Requirements of category II DIN EN 55014-1 (VDE 0875 Teil 14-1):2003-09; EN 55014-1:2000+A1:2001+A2:2002 DIN EN 61000-3-2 (VDE 0838 Teil 2):2005-09; EN 61000-3-2:2000+A2:2005 DIN EN 61000-3-3 (VDE 0838 Teil 3):2002-05; EN 61000-3-3:1995+Corr.:1997+A1:2001 |
| EC type examination | DVGW Deutsche Vereinigung des Gas- und Wasserfaches e.V. 53123 Bonn Notified Body 0085 |
| Surveillance procedure | Yearly surveillance audit DVGW Deutsche Vereinigung des Gas- und Wasserfaches e.V. 53123 Bonn |

The producer states the following:

The above named products fulfil the requirements of the directives and standards. They are identical with the prototype examined. The production process follows the guidelines of the surveillance procedure. The above named products are only for installations in hot water heating systems. The installer has to assure that the directives for installation and operation are being followed.


ppa. H. Wilken
Leiter Entwicklung

i.V. U. Patzke
Leiter Versuch/Labor und
Dokumentationsbevollmächtigter

Technical Data

3. Technical Data

3.1 Dimensions and connections



Tab. 1: Dimensions

| Model | Description | EC three 125 | EC three 170 | EC three 215 | EC three 260 | EC three 300 |
|-------------|-----------------------------|-----------------|-----------------|-----------------|-----------------|-----------------|
| Dimension A | Gas Connection | R 1" | R 1½" | R 1½" | R 1½" | R 1½" |
| Dimension B | Safety Group Connection | R 1" | R 1" | R 1¼" | R 1¼" | R 1¼" |
| Dimension C | Flue | 160 mm | 160 mm | 200 mm | 200 mm | 200 mm |
| Dimension D | Depth | 1008 mm | 1008 mm | 1171 mm | 1264 mm | 1357 mm |
| Dimension E | Centre of Return | 301 mm | 301 mm | 351 mm | 351 mm | 351 mm |
| Dimension F | Centre of Flow | 401 mm | 401 mm | 514 mm | 607 mm | 700 mm |
| Dimension G | Centre of Flue | 134 mm | 134 mm | 163 mm | 163 mm | 163 mm |
| Dimension H | Centre of Safety | 14 mm | 14 mm | 14 mm | 14 mm | 14 mm |
| Dimension I | Centre of Gas | 687 mm | 687 mm | 851 mm | 944 mm | 1037 mm |
| Dimension K | Centre of Flue (optional) | 530 mm | 530 mm | 530 mm | 630 mm | 630 mm |
| Dimension L | Depth of Flue (optional) | 30 mm | 30 mm | 90 mm | 50 mm | 90 mm |
| Dimension M | Distance to Flue (optional) | 139 mm | 139 mm | 50 mm | 302 mm | 50 mm |
| Dimension N | Centre of Supply (optional) | 450 mm | 450 mm | 202 mm | 202 mm | 202 mm |
| Dimension O | Centre of Supply (optional) | 150 mm | 150 mm | 167 mm | 167 mm | 167 mm |

3.2 Technical Data

Tab. 2: Technical Data

| Model | | | EC three 125 | EC three 170 | EC three 215 | EC three 260 | EC three 300 |
|---|-----------------|--------------------|-----------------|-----------------|-----------------|-----------------|-----------------|
| Product-ID-No. | CE-0085 CL 0072 | | | | | | |
| Nominal heat input range | | | | | | | |
| Natural gas | heating | kW | 20.0-125.0 | 28.0-170.0 | 35.0-215.0 | 42.0-260.0 | 48.0-300.0 |
| LPG | heating | kW | 35.0-125.0 | 35.0-170.0 | 48.0-215.0 | 58.0-260.0 | 58.0-300.0 |
| Nominal heat output range | | | | | | | |
| Natural gas | 80/60°C | kW | 19.2-121.6 | 26.8-165.8 | 33.5-210.1 | 40.2-254.5 | 45.9-294.0 |
| | 50/30°C | kW | 21.3-133.1 | 29.8-181.3 | 37.4-229.6 | 44.9-278.1 | 51.4-321.3 |
| LPG | 80/60°C | kW | 33.5-121.6 | 33.5-165.8 | 46.0-210.1 | 55.5-254.5 | 55.5-294.0 |
| | 50/30°C | kW | 37.2-133.1 | 37.3-181.3 | 51.2-229.6 | 62.0-278.1 | 62.1-321.3 |
| Gross efficiency 100% load | 80/60°C | % Gross | 87.74 | 87.94 | 88.13 | 88.28 | 88.37 |
| | 50/30°C | % Gross | 96.03 | 96.17 | 96.31 | 96.45 | 96.57 |
| Gross efficiency 30% load | 40/30°C | % Gross | 96.57 | 96.70 | 96.82 | 96.93 | 97.05 |
| Data for design of the chimney to DIN EN 13384 (room air-dependent operation) | | | | | | | |
| Exhaust gas temperature | 80/60°C | °C | 57-61 | 57-61 | 57-61 | 57-61 | 57-61 |
| | 50/30°C | °C | 30-37 | 30-37 | 30-37 | 30-38 | 30-38 |
| Exhaust gas mass flow | | | | | | | |
| Natural gas | 80/60°C | m ³ /hr | 24.5-152.9 | 34.3-208.0 | 42.8-263.1 | 51.4-318.1 | 58.7-367.1 |
| | 50/30°C | m ³ /hr | 22.5-142.0 | 31.5-193.0 | 39.3-243.9 | 47.1-294.7 | 53.9-339.7 |
| LPG | 80/60°C | m ³ /hr | 40.6-145.1 | 40.6-197.4 | 55.7-249.6 | 67.3-301.8 | 67.3-348.3 |
| | 50/30°C | m ³ /hr | 38.6-134.2 | 37.8-182.3 | 52.2-230.4 | 63.1-278.4 | 62.5-320.9 |


Technical Data

| Model | | EC three 125 | EC three 170 | EC three 215 | EC three 260 | EC three 300 |
|---|--------------------|-----------------------------|-----------------|-----------------|-----------------|-----------------|
| Supply pressure for natural gas | | min. 18 mbar - max. 25 mbar | | | | |
| CO ₂ -content natural gas * | % | 9.3 (9.1-9.5 allowed) | | | | |
| Supply pressure LPG | | nominal 37 bar | | | | |
| CO ₂ -content LPG | % | 11.0 (10.8-11.2 allowed) | | | | |
| Max. delivery pressure at exhaust gas outlet | mbar | 1.0 | | | | |
| Exhaust gas connection | mm | 160 | | 200 | | |
| Gas consumption | | | | | | |
| Natural gas | m ³ /hr | 2.1-13.2 | 3.0-18.0 | 3.7-22.8 | 4.4-27.5 | 5.1-37.7 |
| LPG | kg/hr | 2.7-9.7 | 2.7-13.2 | 3.7-16.7 | 4.5-20.2 | 4.5-23.3 |
| NO _x emission at 0% O ₂ (dry) | mg/ kWh | 35 | | | | |
| Max. delivery pressure at flue gas outlet | mbar | 1.0 | | | | |
| Flue gas connection | mm | 160 | | 200 | | |
| Flow connection | | DN 65 | | | | |
| Return connection | | DN 65 | | | | |
| Connected loads | | | | | | |
| International protection | | IP 22 | | | | |
| Electrical connection | V/Hz | 230 / 50 | | | | |
| Max. electr. power consumption | W | 170 | 200 | 330 | 350 | 410 |
| Max. water pressure | bar | 6.0 | | | | |
| Min water pressure | bar | 1.0 | | | | |
| Max. flow temp | °C | 86 | | | | |
| Hydraulic resistance | | | | | | |
| ΔT=20 K | kPa | 2.80 | 3.40 | 3.70 | 3.90 | 4.00 |
| ΔT=11 K | kPa | 9.00 | 11.00 | 12.10 | 12.70 | 12.90 |
| Boiler weight (dry) | kg | 205 | 240 | 285 | 314 | 344 |
| Boiler water content | l | 29 | 34 | 38 | 45 | 53 |
| Height above everything | mm | 1455 | | | | |
| Width | mm | 692 | | | | |
| Depth | mm | 1008 | | 1171 | 1264 | 1357 |

* in case of fluctuating natural gas composition see section 5.11 CO₂-content

3.3 Hydraulic resistance


Fig. 2: Hydraulic resistance SGB 125 - 300 E



Technical Data

3.4 Wiring Diagram

Fig. 3: Wiring Diagram



3.5 Sensor value tables

Tab. 3: Resistance values for outside temperature sensor ATF

| Temperature [°C] | Resistance [Ω] |
|------------------|----------------|
| -20 | 8194 |
| -15 | 6256 |
| -10 | 4825 |
| -5 | 3758 |
| 0 | 2954 |
| 5 | 2342 |
| 10 | 1872 |
| 15 | 1508 |
| 20 | 1224 |
| 25 | 1000 |
| 30 | 823 |

Tab. 4: Resistance values for flow sensor KVS, drinking water sensor TWF, return sensor KRV, sensor B4

| Temperature [°C] | Resistance [Ω] |
|------------------|----------------|
| 0 | 32555 |
| 5 | 25339 |
| 10 | 19873 |
| 15 | 15699 |
| 20 | 12488 |
| 25 | 10000 |
| 30 | 8059 |
| 35 | 6535 |
| 40 | 5330 |
| 45 | 4372 |
| 50 | 3605 |
| 55 | 2989 |
| 60 | 2490 |
| 65 | 2084 |
| 70 | 1753 |
| 75 | 1481 |
| 80 | 1256 |
| 85 | 1070 |
| 90 | 915 |
| 95 | 786 |
| 100 | 677 |

Before installation

4. Before installation


4.1 Converting the exhaust and supply air connection

The exhaust and supply air connection can be converted to adapt to the local conditions of the installation room.

4.1.1 Converting the exhaust connection

In the following picture the conversion of the top passage to the side or rear passage of the exhaust connection is represented.

Fig. 4: Conversion of the exhaust connection




1. Remove lower rear wall (2) of the EuroCondense three
2. Remove the gas connection leading upward and make a 87°arc (1)
3. Turn 87°arc (1) in the desired position (side or towards the rear)
4. Remove either the rear cover plate (3) or the side cover plate (4)
5. Mount lower rear wall (2)
6. Glue upper cover plate (5)

4.1.2 Converting the supply air connection

In the following picture the conversion of the top passage to the side or rear passage of the supply air connection is represented.

Fig. 5: Conversion of the supply air connection



Side supply air connection (A)

1. Remove lower rear wall (2) of the EuroCondense three
2. Loosen screws and remove the cover plate (1)
3. Remove the intake pipe leading upward from the intake pipe elbow (3)
4. Turn intake pipe elbow (3) into the side position
5. Mount lower rear wall (2)

Rear supply air connection (B)

1. Remove lower rear wall (3) of the EuroCondense three
2. Take out cover plate (2) from lower rear wall (3)
3. Remove the intake pipe leading upward with intake pipe elbow
4. Mount straight intake pipe (1)
5. Mount lower rear wall (3)

Before installation

4.2 Corrosion protection



Caution! Risk of damage of the device!

The combustion air must be free from corrosive elements - especially fluorine and chlorine containing vapours which are found, for example, in solvents and cleaning agents, propellant gases etc.

When connecting heat generators to under-floor heating systems, employing plastic pipe work which is not impervious to oxygen in accordance to DIN 4726, heat exchangers must be used for separation purposes.



Note: Avoidance of damage in hot water heating systems due to corrosion from water.

If the pH-values of the system water during operation are outside of the limit values according to VDI guideline 2035-2 a treatment of the fill water for corrosion is required. For under-floor heating systems and piping with is not impervious to oxygen, a system separation between the boiler and other system components at risk of corrosion must be used.

4.3 Requirements for heating circuit water

To ensure economical operation and to keep the heat exchanger in serviceable condition it may be necessary to treat the filling water with additives. If the water hardness is greater than 17.5 degrees Clarke or 259mg/litre of Calcium then, this must be treated. The treatment depends on the total water hardness, system volume and the size of the boiler.

If, in a special case, a need exists to use additives in a mixture (e.g. hardness stabiliser, frost protection agent, sealing agent, etc.) it has to be observed that the agents are compatible with each other and the pH-value is not altered. Preferably, agents from the same manufacturer should be used.

The instructions of the additive manufacturer must be observed.

Released additives

Currently, the following agents have been approved by Potterton Commercial:

- "Full heating protection" from Fernox
- "Sentinel 100" from GE Betz

As a single frost protection agent, also Tyfocor® L may be used.

If not approved agents are used, the guarantee becomes void!

When softener facilities are used, water softening to a hardness of minimum 6 to 8 °dH is recommended.

The pH-value must not exceed the permissible value of 8.3.

Maintenance instructions

The water hardness of the heating water has to be checked within the scope of the recommended maintenance of the boiler (every two years) and, possibly, the respective amount of additive has to be added.

4.3.1 Further information on the heating water


- The water must not have any foreign matter, such as sweat beads, rust particles, scale or sludge. During filling, flush the system until only clean water runs out. When flushing the system, ensure that the water does not flow through the heat exchanger in the boiler, that the thermostatic radiator valves are removed and the valve inserts are set to the maximum flow rate.
- If additives are used it is important to follow the instructions of the manufacturer.
If, in a special case, it is necessary to use additives in a mixture (e.g. hardness stabiliser, frost protection agent, sealing agent, etc.) it has to be observed that the agents are compatible with each other and the pH-value is not altered. Preferably, agents from the same manufacturer should be used.
- For buffer cylinders in conjunction with solar thermal systems or solid fuel boilers, take the buffer capacity into consideration when determining the fill water volume.

4.3.2 Diagramm Wasserhärte

Zur Vermeidung von Schäden durch Kesselsteinbildung im Kessel ist *Fig. 6* zu beachten.

Before installation

Fig. 6: Diagramm Wasserhärte



Beschreibung:

Der Kesseltyp, die Wasserhärte und das Wasservolumen der Anlage müssen bekannt sein. Liegt das Volumen oberhalb der Kurve, ist eine Teil-Enthärtung des Leitungswassers oder ein Zusatz von Härtestabilisatoren erforderlich.

Beispiel:

SGB 125 E; Wasserhärte 14°dH; 1200 l Wasservolumen

→ kein Zusatz erforderlich

Berücksichtigt wurde ein übliches Nachfüllvolumen der Anlage.

4.4 Notes for installation location



Caution! Danger of damage from water!

The following has to be observed for the installation of the EuroCondense three: In order to prevent damage due to water, particularly due to leakages in the DHW storage tank, suitable precautionary measures should be taken regarding installation.

The installation room must be dry and the room temperature must be between 0 and 32°C.

The installation location has to be selected, especially, with respect to ducting of the exhaust gas ducts. When installing the boiler, the specified wall clearances have to be maintained.

Along with the general rules of the technology, especially the regulations of the states, such as fire and construction ordinances as well as heating room guidelines, are to be observed. Sufficient space should exist in the front to carry out inspection and maintenance work.



Caution! Danger of damaging the device!

Aggressive foreign substances in the combustion supply air can destroy or damage the heat exchanger. Therefore the installation in rooms with high humidity (see also "Operation in wet rooms") or heavy dust accumulation is only allowed with room air independent operating modes.


If the EuroCondense three is operated in rooms in which solvents, chlorine containing cleaning agents, paint, glues or similar substances are worked with or in which such substances are stored, only room air independent operation is permissible. This applies especially for rooms in which ammonia and its compounds are heavily used, as well as nitrites and sulphides (animal breeding and recycling facilities, battery and galvanising rooms, etc.).

For damages occurring due to the installation in an unsuitable location or based on improper combustion air supply, there is no warranty claim.

Before installation

4.5 Space requirement


Fig. 7: Recommended space requirement



| | EC three 125 | EC three 170 | EC three 215 | EC three 260 | EC three 300 |
|---------------------|--------------|--------------|--------------|--------------|--------------|
| Dimension A (front) | 60 cm | 70 cm | 80 cm | 90 cm | 100 cm |
| Dimension B (above) | 50 cm | | | | |
| Dimension C (sides) | 50 cm | | | | |
| Dimension D (rear) | 10 cm | | | | |

4.6 Transportation

Fig. 8: Transport equipment



For transporting the boiler to the installation location using a crane, transport eyes found on the top of the boiler (*Fig. 8, Pos. 1*) can be used. Remove the centre covering lid of the EuroCondense three to do this.


For the transport of the boiler to installation location manually, push 2 sufficiently large steel pipes ($\varnothing = 1''$, not included!) through the carrying fixture (*Fig. 8, Pos. 2*), so that the boiler can be lifted and transported.

Danger of injury! The boiler must absolutely be secured from sliding on the steel pipes! For transport manually safety shoes must be worn! For transport with the aid of a carrier fixture at least 4 persons are required.




Before installation

4.7 Application examples



Wiring plan



The following parameters are to be adapted, if a first room device RGT is applied for circuit 1:


Parameters to set:

| Menu item | Function | Settings |
|------------------|-----------|-------------|
| Operator section | | |
| 40 | Used as : | Room unit 1 |

Parameters to set EC3:

| Menu item | Function | Settings |
|-----------|--------------------|------------------|
| 5890 | Relay output QX1 | Circulating pump |
| 6085 | Function output P1 | None |

Before installation




Wiring plan

Parameters to set:

| Menu item | Function | Settings |
|-----------|-----------------------------|-------------------|
| 5890 | Relay output QX1 | Circulating pump |
| 5892 | Relay output QX3 | DHW ctrl elem Q3 |
| 6020 | Function extension module 1 | Heating circuit 1 |


Configuration:




Before installation

Application example 3: EC three with three mixed circuits and DHW preparation

Hydraulic plan




Wiring plan




Before installation

Application example 4: Cascade with two EC three, three mixed circuits, hydraulic bypass and DHW preparation

Hydraulic plan





Before installation

Wiring plan (left EC three)

Parameters to set:

| Menu item | Function | Settings |
|-----------|-----------------------------|-------------------|
| 5890 | Relay output QX1 | DHW ctrl elem Q3 |
| 5891 | Relay output QX2 | Boiler pump Q1 |
| 5892 | Relay output QX3 | Circulating pump |
| 6020 | Function extension module 1 | Heating circuit 1 |
| 6021 | Function extension module 2 | Heating circuit 2 |
| 6022 | Function extension module 3 | Heating circuit 3 |

LPB system:

| | | |
|---|----------------|---|
| 6600 | Device address | 2 |
| 3) Addressing of the extension module on address 2 (dip switch) | | |
| 4) Addressing of the third extension module on address 3 (dip switch) | | |

The following parameters are to be adapted, if a second room devise RGT is applied for circuit 2:

Parameters to set:

| Menu item | Function | Settings |
|------------------|----------|-------------|
| Operator section | | |
| 40 | Used as | Room unit 2 |

The following parameters are to be adapted, if a third room devise RGT is applied for circuit 3:

Parameters to set:

| Menu item | Function | Settings |
|------------------|----------|-------------|
| Operator section | | |
| 40 | Used as | Room unit 3 |


Parameters to set:

| Menu item | Function | Settings |
|-----------|-------------------|---------------------------|
| 5710 | Heating circuit 1 | Off |
| 5891 | Relay output QX2 | Boiler pump Q1 |
| 5930 | Sensor input BX1 | Common flow sensor B10 |
| 5931 | Sensor input BX2 | Cascade return sensor B70 |

LPB system:

| | | |
|------|----------------|---|
| 6600 | Device address | 1 |
|------|----------------|---|

Configuration:



4.8 Legend

Sensor designations:

| Title in the hydraulic | Title in the regulation | Function / Declaration | Type |
|------------------------|--------------------------------|--|-------|
| ATF | Outdoor temp. sensor B9 | Measuring the outdoor-temperature | QAC34 |
| HVF | Flow sensor B1/B12/B16 | Sensor of mixing circuit | D 36 |
| KRF | Boiler return sensor B7 | Measuring return temperature, e.g. for elevation of return temperature | Z 36 |
| RTF | Return sensor B73 | Measuring return temperature of installation, e.g. for elevation of return temp. (Solar) | Z 36 |
| VFK | Flow sensor B10 | Measuring flow temperature of installation, e.g. for low loss header | Z 36 |
| RFK | Return sensor B70 | Measuring return temperature of cascade | Z 36 |
| TWF | Tank sensor B3 | Measuring of upper DHW tank temperature | Z 36 |
| TWF2 | Tank sensor B31 | Measuring of lower DHW tank temperature / storage tank | Z 36 |
| TLF | DHW charging sensor B36 | Measuring of charging temperature of charging system LSR | D 36 |
| SKF | Collector sensor B6 | Measuring temperature of solar collector | Z 36 |
| SKF2 | Collector sensor B61 | Measuring temperature of solar collector (secondary field) | Z 36 |
| SVF | Solar flow sensor B63 | Measuring of flow temperature solar circuit | Z 36 |
| SRF | Solar return sensor B64 | Measuring of return temperature solar circuit | Z 36 |
| PSF1 | Upper storage tank sensor B4 | Measuring of upper storage tank temperature | Z 36 |
| PSF2 | Lower storage tank sensor B41 | Measuring of lower storage tank temperature | Z 36 |
| PSF3 | Middle storage tank sensor B42 | Measuring of storage tank temperature / mid - tank | Z 36 |
| FSF | Solid fuel boiler sensor B22 | Measuring of temperature of wood boiler | Z 36 |
| SBF | Swimming pool sensor B13 | Measuring of pool temperature | Z 36 |
| KVF | Boiler flow sensor B2 | Measuring of boiler temperatur | Z 36 |

Type D is a dockable sensor, Type Z is a diving sensor, the collector sensor has a black silicon cable, the sensor of the SOR S/M are Pt 1000 Fühler.

Pumps:

| Title in the hydraulic | Title in the regulation | Function / Declaration |
|------------------------|------------------------------|--|
| TLP | DHW pump Q3 | DHW charging pump |
| TZP | Circulating pump Q4 | DHW circulating pump |
| SDP | DHW mixing pump Q35 | Thorough mixing of DHW tank during legionella function |
| SUP | St tank transfer pump Q11 | Shuffles DHW from storage to DHW tank |
| ZKP | DHW interm circ pump Q33 | DHW pump in secondary circuit of tank charging system (e.g. LSR) |
| HP | Heating circuit pump Q2; Q6 | Pump of a heating circuit |
| HKP | Heating circuit pump HCP Q20 | Pump for circuit HKP |
| SKP | Collector pump Q5 | Pump of solar circuit |
| SKP2 | Collector pump Q16 | Pump of 2nd solar circuit |
| FSP | Solid fuel boiler pump Q10 | Boiler pump for wood boiler |
| ZUP | System pump Q14 | Additional pump for supply of distant circuit |
| SBP | Pump Hx Q15, Q18, Q19 | Pump for swimmingpool |
| H1 | H1 pump Q15 | Pump for high temperature circuit e.g. ventilation |
| H2 | H2 pump Q18 | Pump for high temperature circuit e.g. ventilation |
| H3 | H3 pump Q19 | Pump for high temperature circuit e.g. ventilation |
| BYP | Bypass pump Q12 | Pump for return temperature elevation |
| SET | Solar pump ext. exch. K9 | Pump for secondary circuit of solar heat exchanger |
| KP | Kesselpumpe Q1 | Boiler pump, in parallel to boiler operation |

Valves:

| Title in the hydraulic | Title in the regulation | Function / Declaration |
|------------------------|--------------------------------|--|
| DWV | | Three way valve general |
| DWVP | Solar ctrl elem buffer K8 | Switches solar circuit to storage tank |
| DWVS | Solar ctrl elem swi pool K18 | Switches solar circuit to swimming pool |
| DWVE | Heat gen shutoff valve Y4 | Separates boiler from circuits hydraulically |
| DWVR | Buffer return valve Y15 | Switches return to elevation of return temperature (utilisation of solar energy) |
| HM | Heat circ mix valve Y1/2; Y3/4 | Mixing circuit |
| USTV | | Overflow valve (optional extra) |

General:

| Shortcut | Function / Declaration | Shortcut | Function / Declaration |
|------------|---|----------|---|
| BE | Display of boiler or wall mounted control | TWW | DHW hot |
| Bus BE | Bus connection for display | TWK | DHW cold |
| Bus EM | Bus connection to extension module | TWZ | DHW circulation |
| FB | Connection distance control RGT; RGTF; RGTK | S1 | Boiler switch |
| BXx | Input multifunctional (Sensor entrance) | F1 | Fuse |
| QXx | Output multifunctional | FB | Connection distance control RGT; RGTF; RGTK |
| H1; H2; H3 | Input multifunctional (potential free) | *) | Accessory to be orderd separately |

Stand 03.02.2010

Installation

5. Installation

5.1 Connect heating circuit



Note: It is recommended that a filter be fitted in the heating return. In the case of old plants, the whole heating plant should be thoroughly flushed before installation.

Safety valve

In case of open heating plants, connect the safety header and return pipeline; in case of closed heating plants install the expansion vessel and safety valve.



Caution! The connecting pipe between the boiler and the safety valve must not be blockable. The fitting of pumps and fittings or pipe reducer pieces is not permissible. The blow-off line of the safety valve must be so designed that the pressure does not increase as one approaches the safety valve. It must not be led into free space, the opening must be clear and observable. Heating water that may possibly escape should be safely drained off.

5.2 Condensate water connection

A direct run-off of the condensate into the domestic drainage system is only allowed if the system only comprises of corrosion resistant materials (e.g. PP-pipe, stoneware or similar materials). If this is not the case, a suitable neutralisation system must be installed.

The condensate must be able to flow freely into a tundish. A syphon trap must be installed between the tundish and drainage system. The condensate hose of the EuroCondense three must be inserted through the opening in the rear or side wall. If there is no drain underneath the condensate discharge, the use of a suitable neutralisation system and pump is necessary.

5.3 Sealing and filling of the plant

- Filling the heating plant
- Check tightness (max.water test pressure 6 bar).

5.4 Flue system

The Flue system must provide satisfactory control of condensation, in accordance with Part J of the Building Regulations:

- Use components that are impervious to condensates and suitably resistant to corrosion (i.e. stainless steel grade 316 etc.)
- Make provision for draining, avoid ledges, crevices etc (e.g. flexible liners are not suitable)
- Make provision for disposal of condensate to suitable drain point (e.g. PP pipe or stainless steel condensate drain with water seal syphon trap. Copper should not be used)

Owing to low flue gas temperatures only single skinned flue pipe is necessary in areas where personal protection is required (maximum temperature of 90°C.) The number of bends used should be kept to a minimum and bends used should be of the swept type. 90° bends should **not** be used. If an existing chimney is being re-used, this must be lined with a correct liner suitable for condensing operation. Termination of flue must be to current standards both for height and distance from adjacent objects i.e. other terminals, opening windows or doors and walls.

Flue lengths

Permissible Flue Lengths for Room Air Dependent Operation:

| Modell | Flue Size | Maximum Flue Length incl. one 87° elbow |
|--------------|-----------|--|
| EC three 125 | Ø 160 mm | 60 m |
| EC three 170 | Ø 160 mm | 50 m |
| EC three 215 | Ø 200 mm | 60 m |
| EC three 260 | Ø 200 mm | 60 m |
| EC three 300 | Ø 200 mm | 60 m |

These lengths only apply to single boilers. For more elbows the following deductions should be made:

1 x elbow 87°: 5 m

1 x elbow 45°: 2 m



For installation of multiple boilers, a flue specialist should be instructed to assist.

Standards

Flue systems should meet the applicable sections of:

- BS6644.
- CIBSE Applications Manual AM14 Non-Domestic Hot Water Heating Systems
- Clean Air Act 1993
- the current Building Regulations must also be strictly observed

The boiler should be installed in accordance with BS6644 with respect to protecting the boiler from damage, air for combustion and ventilation, discharge of products of combustion, clearances for service and access, temperatures, noise levels, the disposal of boiler water and the effects of flooding of the boiler house.

5.5 Gas connection

The gas side connection must only be carried out by an approved heating specialist. For the gas side installation and setting, the factory setting data of the equipment and optional label should be compared with the local supply conditions.

An approved thermally activated shut-off device has to be installed.

In case of regionally existing old gas pipes, the installation of a gas filter is recommended.

Residues in pipes and pipe joints should be removed.

5.6 Check tightness



Danger! Danger of life from gas!

The entire gas inlet pipe, particularly the joints must be checked for leakages before commissioning.

5.6.1 Purging the gas line

The gas line has to be purged before commissioning. For this, open the measuring nozzle for the connecting pressure and purge by observing the safety precautions. Check for tightness of the connection after purging!

5.7 Factory settings

The set gas type can be seen on the affixed label on the burner. The data, set by the manufacturer, has to be checked with the local supply conditions before installation of the EuroCondense three. The gas pressure controller of the gas valve has been sealed.

Installation

5.8 CO₂ -Content

The CO₂ content in the exhaust gas must be checked during commissioning and during regular maintenance of the boiler, as well as, after reconstruction work on the boiler or on the exhaust gas system.

CO₂-content during operation see section *Technical data*.



Caution! Risk of damage of the burner!

Too *high* CO₂ -values can lead to unhygienic combustion (high CO-values) and damage to the burner.

Too *low* CO₂ -values can lead to ignition problems.

The CO₂ -value is set at the gas valve by adjusting the gas pressure (see Fig. 9). In case of employment of the EuroCondense three in areas with fluctuating natural gas composition, the CO₂-content should be adjusted in accordance with the Wobbe Index at any given time (ask the gas supply company).

The CO₂-content to be set can be decided as follows:

$$- \text{CO}_2\text{-content} = 9,3 - (W_{\text{ON}} - W_{\text{ocurrent}}) * 0,5$$

The air quantity set in the factory must not be changed.

5.9 Changing over from LPG to natural gas and vice versa



Danger! Danger of life by gas!

The gas type of the EuroCondense three must only be modified by an approved heating specialist.

To change to other type of gas only the CO₂- content must be reset by adjusting the jet pressure on the gas valve (see Fig. 9).

Moreover, the following parameters of the LMS control have to be adapted - see the values of the following tables:


| Function | Prog. no. | Setting level | EC three 125 | | EC three 170 | | EC three 215 | |
|-----------------------------------|-----------|---------------|--------------|-------|--------------|-------|--------------|-------|
| | | | Natural gas | LPG | Natural gas | LPG | Natural gas | LPG |
| Boiler | | | | | | | | |
| | 2331 | E | 20 | 35 | 28 | 35 | 35 | 48 |
| Burner control | | | | | | | | |
| Required output prepurging | 9504 | E | 59.3 | 66.3 | 75.5 | 86.8 | 77.1 | 89.3 |
| Required output ignition | 9512 | E | 59.3 | 66.3 | 75.5 | 86.8 | 77.1 | 89.3 |
| Required output LF | 9524 | E | 20.0 | 35.0 | 28.0 | 35.0 | 35.0 | 48.0 |
| Fan output/speed slope | 9626 | E | 37.1 | 33.9 | 27.6 | 24.1 | 26.4 | 23.0 |
| Fan output/speed Y-section | 9627 | E | 501.1 | 453.9 | 517.2 | 507.4 | 464.4 | 446.3 |
| CO ₂ content (± 0.2 %) | | | 9.3 | 11.0 | 9.3 | 11.0 | 9.3 | 11.0 |

| Function | Prog. no. | Setting level | EC three 260 | | EC three 320 | |
|----------------------------|-----------|---------------|--------------|-------|--------------|-------|
| | | | Natural gas | LPG | Natural gas | LPG |
| Boiler | | | | | | |
| | 2331 | E | 42 | 58 | 48 | 58 |
| Burner control | | | | | | |
| Required output prepurging | 9504 | E | 97.7 | 110.3 | 103.9 | 115.5 |
| Required output ignition | 9512 | E | 97.7 | 110.3 | 103.9 | 115.5 |
| Required output LF | 9524 | E | 42.0 | 58.0 | 48.0 | 58.0 |

| Function | Prog. no. | Setting level | EC three 260 | | EC three 320 | |
|-----------------------------------|-----------|---------------|--------------|-------|--------------|-------|
| | | | Natural gas | LPG | Natural gas | LPG |
| Fan output/speed slope | 9626 | E | 21.5 | 19.9 | 19.9 | 19.0 |
| Fan output/speed Y-section | 9627 | E | 398.4 | 305.7 | 431.7 | 306.1 |
| CO ₂ content (± 0.2 %) | | | 9.3 | 11.0 | 9.3 | 11.0 |


5.10 Controller Stop Mode (Manual Adjustment of Burner Load)

For setting and controlling the CO₂ values the EuroCondense three is operated in the **control stop function**.



Press operation mode button Heating Operation for **approximately 3 seconds** => the message *Controller Stop Function ON* is displayed.

2. Wait, until the display has reached the basic display again.



Press information button
=> The message *Controller stop setpoint adjust* appears in the display. The actual modulation degree will be displayed on the display.

4. Press OK button

= > The nominal value can now be changed.

5. Press OK button

=> The displayed nominal value is taken over by the control.




Note: The regulator stop function is stopped by pressing the *operating mode button Heating Operation* for approximately 3 seconds, reaching the maximum boiler temperature or a time limit.

If a heat demand from a cylinder with internal indirect coil is present, this demand will continue to be met while the controller stop function is running.

Installation

5.11 Check and adjust CO₂ content

Fig. 9: Gas valve



- | | |
|---|--|
| 1 Compensation line | 4 Gas pressure monitor |
| 2 Adjustment screw for full load (Allen key 3 mm) | 5 Adjustment screw for low load (Torx TX 40) |
| 3 Measuring nozzle for inlet pressure | |

Set CO₂-content at max. output

1. EuroCondense three in the controller stop mode (refer to previous section) operated at full load
2. Remove safety cap from the adjustment screw for full load (2)
3. Set CO₂ content on the adjustment screw for full load (2) according to *Technical Data* section with a 3 mm Allen key
 - Clockwise: CO₂ content is decreased
 - Counter-clockwise: CO₂ content is increased
4. Replace safety cap on the adjusting screw for full load (2)

Set CO₂-content at min. output

1. EuroCondense three in the controller stop mode (refer to previous section) operated at low load
2. Remove safety cap from the adjustment screw for small load (5)
3. Set CO₂ content on the adjustment screw for small load (5) according to *Technical Data* section with a Torx key TX 40
 - Clockwise: CO₂-content is increased
 - Counter-clockwise: CO₂ is reduced
4. Replace safety cap on the adjusting screw for low load (5)

Note: After successful adjustment of the gas valve, the CO₂ content must again be controlled at maximum and minimum output and corrected if necessary



5.12 Electrical connection (general)



Risk of electric shock! Risk to life through incorrect work!

All electrical work in connection with the installation must only be carried out by a qualified electrician.

- Mains supply AC 230 V +6% -10%, 50 Hz

In Germany the VDE 0100 and local regulations must be followed during installation; in all other countries, follow the relevant regulations.

The electrical connection has to be carried out to the correct poles and so polarity cannot be mistaken. In Germany, the connection can be carried out with an accessible, unmistakable plug-in connection or as a permanent connection. In all other countries, provide a permanent connection.

For the power supply, use the power cable attached to the boiler or cable types H05VV-F 3 x 1 mm² or 3 x 1.5 mm².

We recommend the installation of a mains isolator upstream of the EuroCondense three. It should be a double pole switch with a contact gap of min. 3 mm.

All connected components must comply with VDE [or local regulations]. Always apply strain relief to connecting cables.

5.12.1 Cable lengths

Bus/sensor lines do not have mains voltage, but small protective voltage. They must not be installed **in parallel with mains lines** (induced signals). Shielded cables have to be installed if this is unavoidable.


Permissible cable lengths for all bus sensors:

- Cu-cable up to 20m: 0,8 mm²
- Cu-cable up to 80m: 1 mm²
- Cu-cable up to 120m: 1,5 mm²

5.12.2 Strain reliefs

All electrical cables have to be installed from the boiler rear wall to the boiler switch panel. Here, the lines have to be fixed into the strain relief of the switching panel and to be connected according to the wiring diagram (Fig. 10).

Fig. 10: Strain relief



5.12.3 Circulating pumps

The permissible current load per pump exit is $I_{N \max} = 1A$.

5.12.4 Fuses

Fuses in the Control Unit ISR:
- Mains fuse: T 6,3A H 250V

5.12.5 Connection sensor / components



Danger of electric shock! Danger of life, if handled inappropriately!

The wiring diagram must be followed! Optional accessories must be fitted and connected according to the instructions provided. Connect to the mains. Check earthing.

Outdoor temperature sensor (included in delivery)

The outdoor temperature sensor is located in the accessory bag. For connection see connection diagram.

5.12.6 Replacing cables

All connecting cables apart from the mains cable must be replaced when necessary with Potterton Commercial special cables. When replacing the mains cable only cables complying with BS6500 must be used.

5.12.7 Protection against contact



Risk of electric shock! After opening the EuroCondense three the paneling parts to be screwed on must be retightened with the appropriate screws to ensure protection against contact.

6. Commissioning




Danger! The Commissioning must only be carried out by an approved heating specialist! The heating specialist checks the tightness of connections, the correct functioning of all regulating, control and safety installations and measures the combustion values. In case of incorrect performance possible danger of considerable damage to persons, environment and property!



Caution! In dusty environment, e.g. during construction work, the boiler shall not be commissioned. The boiler could be damaged!

6.1 Menu-Commissioning

During first commissioning, the menu Commissioning is showing up one-time.



Select *Language* and confirm by pressing OK

2. Select *Year* and confirm
3. Set *Date* and confirm
4. Set *Time* and confirm
5. Finalize by pressing OK



Note: If the menu commissioning is interrupted by pressing ESC, the menu is showing up again during the next switch-on of the device.

6.2 Check water pressure



Caution! Check before switching-on, if the manometers show sufficient water pressure. The value has to be between 1,0 and 2,5 bar.

- Less than 0,5 bar: Top up water .
Caution! The maximum admissible installation pressure has to be considered!
- Over 6,0 bar: Do not start boiler. Drain out some water.
Caution! The maximum admissible installation pressure has to be considered!
- Check if a collecting container is placed under the blow-down pipeline of the safety valve. In case of overpressure it collects running out heating circuit water.


6.3 Switching-on



Danger of scalding! Hot water may exit from the blow pipe of the safety valve.

Commissioning

1.





Switch on heating isolator switch

2. Open gas shut-off installation


3. Open front panel cover and switch on the operating switch on the front panel of the boiler

4.



Select the operation mode **automatic operation** with the operation mode button on the control unit 

5.



Set the required room temperature on the rotating knob of the control unit

6.4 Temperatures for heating and drinking water

The information in the section *Programming* for setting the temperatures for heating and drinking water.

For DHW heating a setting between 50 and 60°C is recommended.



Note: The times for DHW will be set in time programme 4/ TWW. **For reasons of comfort, the start of DHW heating should be approximately 1 hour before start of heating!**

6.5 Individual time programme

The gas condensing boiler can be commissioned having its standard values. For setting e.g. an individual time programme, please observe section *Programming (tab. 5)*.

6.6 Instruction for the customer

Instruction

The customer should be instructed in the operation of the boiler and the function of the safety devices. The following should be pointed out:

Commissioning

- the air inlet must not be restricted;
- flammable materials and liquids must not be stored in the vicinity of the gas boiler;
- the customer has to carry out the following control checks himself:
 - pressure check on the manometer;
 - check the discharge from the safety valve;
- only approved gas installers may carry out the inspection and maintenance.

Documents



- The documents, belonging to the boiler, have to be handed over with the instructions and they have to be kept in the installation room of the boiler.
- A copy of the commissioning sheet with confirmation and legally binding signature to the customer. All components have been installed according to the instruction of the manufacturer. The whole plant complies with the relevant British Standards and current Building Regulations.

Operation

7. Operation

7.1 Operating elements


Fig. 11: Operating elements














- | | |
|---|--|
| 1 Operating switch | 8 OK-button (acknowledgment) |
| 2 Reset button | 9 Information button |
| 3 Reset safety temperature limiter (STB) | 10 Rotating knob |
| 4 Blanking plate | 11 Chimney-sweep button |
| 5 Operator section (ISR) | 12 ESC-button |
| 6 Operating mode button heating operation | 13 Operation mode button DHW operation |
| 7 Display | |

7.2 Display

Fig. 12: Symbols on the display




sRE081B

| Meaning of the displayed symbols | | | |
|---|---|---|---|
|  | Heating to set comfort temperature |  | Cooling active (heat pump only) |
|  | Heating to set reduced temperature |  | Compressor in operation (heat pump only) |
|  | Heating to set frost protection temperature |  | Service message |
|  | Current process |  | Fault message |
|  | Holiday function active | INFO | Information level active |
|  | Reference to heating circuits | PROG | Setting level active |
|  | Burner in operation (boiler only) | ECO | Heating system shut down (automatic summer/winter changeover or automatic heating limit active) |



7.3 Setting up heating operation

Change-over between operating modes for heating operation will be carried out with the operating button "Heating operation". The selected setting will be marked with a bar underneath the operating mode symbol.



Operation

Automatic operation :

- Heating operation according to time programme
- Nominal temperature values  comfort or  reduced according to time programme
- Protection functions (plant frost protection, overheating protection) activated
- Automatic summer/winter switch-over (automatic switching over between heating and summer operation from a certain outside temperature)
- Automatic day heating limit (automatic change-over between heating and summer operation, if outside temperature exceeds the nominal room value)

Continuous Operation comfort or reduced :


- Heating operation without time programme
- Protection functions activated
- Automatic summer/winter switch-over is not activated
- Automatic day heating limit is not activated

Protection operation :

- No heating operation
- Temperature according to frost protection setpoint
- Protection functions activated
- Automatic summer/winter switch-over is not activated
- Automatic day heating limit is not activated
- DHW operation according to status

7.4 Stop drinking water operation

Stop drinking water operation



- *Switched on* Drinking water will be prepared according to the selected switching programme.
- *Switched off* Drinking water preparation has been de-activated.




Note: Legionella function

Each Sunday during the first charge of the DHW tank, the legionella function is activated; this means the DHW is being heated up to 65 °C once for eliminating the existing legionellas.


7.5 Setting room setpoint

Setting comfort setpoint:



1. Set comfort setpoint with the control knob
=> The value will automatically be take over


Setting reduced setpoint:



1. Press OK button
2. Select heating circuit.
3. Press OK button
4. Select parameter *Reduced setpoint*
5. Press OK button
6. Set reduced setpoint with the control knob
7. Press OK button
8. Leave programming level by pressing the operation mode button heating operation

7.6 Display information

Various temperatures and messages can be called up by pushing the information button.



Including:


- Room and outside temperature (if sensor fitted)
- Fault or service messages



Note: When no faults occur and no service messages exist, this information is not displayed.

7.7 Error message


If the fault sign  appears in the display, a fault exists in the heating system.




- Press information button (i)
- Further information can be called up (see *Fault code table*).

Operation

7.8 Servicing message

If the maintenance sign  appears in the display, a maintenance message exists or the heating system is in special operation.



- Press information button (i)
- Further information can be called up (see section *Maintenance code-table*).



Note: The maintenance message has not been activated by the setting in the factory.

7.9 Emergency mode (Manual control)

Activation of manual control. If the manual control function is activated the boiler will be controlled to the Setpoint manual control. All pumps will be activated. Additional request will be ignored!

1. Press OK button
2. Select menu point *Maintenance/service*
3. Press OK button
4. Select parameters *Manual control* (prog.-no. 7140)
5. Press OK button
6. Select parameter "On"
7. Press OK button
8. Leave programming level by pressing the operation mode button heating operation

7.10 Restoring factory setting

The factory settings will be restored as follows:

1. Press OK button
2. Select *Setting level Engineer* (see section *Programming at Programming procedure*)
3. Select menu point *Operator section*
4. Press OK button
5. Select parameters *Operator section activate basic settings* (prog.-no. 31)
6. Press OK button
7. Change setting to "Yes" and wait until setting returns to "No"
8. Press ESC button
9. Factory setting is restored




Note: You can find more information for adjusting parameters in the section *Programming*.

8. Programming

8.1 Programming procedure

The selection of the setting levels and menu points for end users and heating specialists is carried out by means of the following diagram:



Programming


8.2 Modification of parameters


Settings, which are not directly modified via the front panel, have to be carried out in the setting level.


The basic programming process is depicted in the following by the setting of time and date.


Basic display:


 Press





Select with  the menu point **time and date**.


Acknowledge selection with 





Select with  the menu point **hours/minutes**.

Acknowledge selection with 





Select with  set the hours (e.g. 15 hours).


Acknowledge selection with 




Programming



Select with  set the minutes (e.g. 30 minutes).



Acknowledge selection with 



Press heating circuit operation mode button to return to the basic display.



The previous menu point will be called-up by pressing the ESC-button without taking over previously modified values. If no settings are carried out for approximately 8 minutes, the basic display is called-up without taking over previously modified values.

Programming





8.3 Setting table




- Not all parameters displayed in the display are listed in the setting table.
- Depending on the plant configuration, not all parameters listed in the setting table are displayed in the display.
- In order to get to the setting levels: Enduser (Eu), Commissioning (C) and Engineer (E), press OK button; after this, press and hold the information (i) button for 3 seconds, select the required level with the rotating knob and acknowledge with the OK button.



Tab. 5: Setting the parameters

| Function | Prog. no. | Level ¹⁾ | Standard value |
|--|-----------|---------------------|--------------------|
| Time of day and date | | | |
| Hours/minutes | 1 | EU | 00:00 (h:min) |
| Day/month | 2 | EU | 01.01 (day. month) |
| Year | 3 | EU | 2004 (year) |
| Start of summertime | 5 | E | 25.03 (day.month) |
| End of summertime | 6 | E | 25.10 (day, month) |
| Operating unit | | | |
| This parameter is only visible in the room device! | | | |
| Language | 20 | Eu | English |
| Info Temporarily Permanently | 22 | E | Temporarily |
| Display of errors Code Code and text | 23 | E | Code and text |
| Contrast of display | 25 | Eu | 87 |
| Operation lock Off On | 26 | E | Off |
| Programming lock Off On | 27 | E | Off |
| Units °C, bar °F, PSI | 29 | Eu | °C, bar |
| Save basic settings No Yes | 30 | E | No |
| This parameter is only visible in the room device! | | | |
| Activate basic settings No Yes | 31 | E | No |
| This parameter is only visible if a suitable standard setting is available in the programming unit. | | | |
| Used as Room unit 1 Room unit 2 Room unit 3/P Operator unit 1 Operator unit 2 Operator unit 3 Service unit | 40 | C | Room unit 1 |
| This parameter is only visible in the room device! | | | |
| Assignment device 1 Heating circuit 1 Heating circuits 1 and 2 Heating circuits 1 and 3/P All heating circuits | 42 | C | Heating circuit 1 |
| This parameter is only visible in the room device, as the operating unit in the boiler is fixed programmed for the operating device! | | | |


| Function | Prog. no. | Level ¹⁾ | Standard value |
|--|-----------|---------------------|-----------------------------------|
| Operation HC2 Commonly with HC1 Independently | 44 | C | Commonly with HC1 |
| Operation HK3 Commonly with HC1 Independently | 46 | C | Commonly with HC1 |
| Room temperature unit 1 Only for Heating circuit 1 For all assigned heating circuits  This parameter is only visible in the room device! | 47 | C | For all assigned heating circuits |
| Occupancy button unit 1 None Only for Heating circuit 1 For all assigned heating circuits  This parameter is only visible in the room device! | 48 | C | For all assigned heating circuits |
| Readjustment room sensor  This parameter is only visible in the room device! | 54 | E | 0.0°C |
| Software version | 70 | E | |
| Radio  Parameter only visible, if wireless room device exists! | | | |
| Room unit 1 Missing Ready No reception Change battery Delete device | 130 | C | missing |
| Room device 2 Missing Ready No reception Change battery Delete device | 131 | C | missing |
| Room unit 3 Missing Ready No reception Change battery Delete device | 132 | C | missing |
| Outside sensor Missing Ready No reception Change battery Delete device | 133 | C | missing |
| Repeater Missing Ready No reception Change battery Delete device | 134 | C | missing |
| Operator unit 1 Missing Ready No reception Change battery Delete device | 135 | C | missing |
| Operator unit 2 Missing Ready No reception Change battery Delete device | 136 | C | missing |
| Operator unit 3 Missing Ready No reception Change battery Delete device | 137 | C | missing |
| Service unit Missing Ready No reception Change battery Delete device | 138 | C | missing |
| Delete all devices No Yes | 140 | C | No |
| Time prog heating circuit 1 | | | |
| Preselection Mo - Su Mo-Su Mo-Fr Sa-Su Mo Tu We Th Fr Sa Su | 500 | Eu | Mo |
| 1st phase on | 501 | Eu | 06:00 (h/min) |
| 1st phase off | 502 | Eu | 22:00 (h/min) |
| 2nd phase on | 503 | Eu | --:-- (h/min) |
| 2nd phase off | 504 | Eu | --:-- (h/min) |
| 3rd phase on | 505 | Eu | --:-- (h/min) |
| 3rd phase off | 506 | Eu | --:-- (h/min) |
| Copy? | 515 | Eu | |

Programming

| Function | Prog. no. | Level ¹⁾ | Standard value |
|--|-----------|---------------------|----------------|
| Default values No Yes | 516 | Eu | No |
| Time prog heating circuit 2 | | | |
|  Parameter only visible, if heating circuit 2 exists! | | | |
| Preselection Mo - Su Mo-Su Mo-Fr Sa-Su Mo Tu We Th Fr Sa Su | 520 | Eu | Mo |
| 1st phase on | 521 | Eu | 06:00 (h/min) |
| 1st phase off | 522 | Eu | 22:00 (h/min) |
| 2nd phase on | 523 | Eu | --:-- (h/min) |
| 2nd phase off | 524 | Eu | --:-- (h/min) |
| 3rd phase on | 525 | Eu | --:-- (h/min) |
| 3rd phase off | 526 | Eu | --:-- (h/min) |
| Copy? | 535 | Eu | |
| Default values No Yes | 536 | Eu | No |
| Time program 3 / HC3 | | | |
| Preselection Mo - Su Mo-Su Mo-Fr Sa-Su Mo Tu We Th Fr Sa Su | 540 | Eu | Mo |
| 1st phase on | 541 | Eu | 06:00 (h/min) |
| 1st phase off | 542 | Eu | 22:00 (h/min) |
| 2nd phase on | 543 | Eu | --:-- (h/min) |
| 2nd phase off | 544 | Eu | --:-- (h/min) |
| 3rd phase on | 545 | Eu | --:-- (h/min) |
| 3rd phase off | 546 | Eu | --:-- (h/min) |
| Copy? | 555 | Eu | |
| Default values No Yes | 556 | Eu | No |
| Time program 4 / DHW | | | |
| Preselection Mo - Su Mo-Su Mo-Fr Sa-Su Mo Tu We Th Fr Sa Su | 560 | Eu | Mo |
| 1st phase on | 561 | Eu | 05:00 (h/min) |
| 1st phase off | 562 | Eu | 22:00 (h/min) |
| 2nd phase on | 563 | Eu | --:-- (h/min) |
| 2nd phase off | 564 | Eu | --:-- (h/min) |
| 3rd phase on | 565 | Eu | --:-- (h/min) |
| 3rd phase off | 566 | Eu | --:-- (h/min) |
| Copy? | 575 | Eu | |
| Default values No Yes | 576 | Eu | No |
| Time program 5 | | | |
| Preselection Mo - Su Mo-Su Mo-Fr Sa-Su Mo Tu We Th Fr Sa Su | 600 | Eu | Mo |
| 1st phase on | 601 | Eu | 06:00 (h/min) |
| 1st phase off | 602 | Eu | 22:00 (h/min) |

| Function | Prog. no. | Level ¹⁾ | Standard value |
|--|-----------|---------------------|--------------------|
| 2nd phase on | 603 | Eu | --:-- (h/min) |
| 2nd phase off | 604 | Eu | --:-- (h/min) |
| 3rd phase on | 605 | Eu | --:-- (h/min) |
| 3rd phase off | 606 | Eu | --:-- (h/min) |
| Copy? | 615 | Eu | |
| Default values No Yes | 616 | Eu | No |
| Holidays heating circuit 1 | | | |
| Preselection Period 1 ... 8 | 641 | Eu | Period 1 |
| Start | 642 | Eu | --:-- (day. month) |
| End | 643 | Eu | --:-- (day. month) |
| Operating level Frost protection Reduced | 648 | Eu | Frost Protection |
| Holidays heating circuit 2 | | | |
|  Parameter only visible, if heating circuit 2 exists! | | | |
| Preselection Period 1 ... 8 | 651 | Eu | Period 1 |
| Start | 652 | Eu | --:-- (day. month) |
| End | 653 | Eu | --:-- (day. month) |
| Operating level Frost protection Reduced | 658 | Eu | Frost Protection |
| Holidays heating circuit 3 | | | |
|  Parameter only visible, if heating circuit 3 exists! | | | |
| Preselection Period 1 ... 8 | 661 | Eu | Period 1 |
| Start | 662 | Eu | --:-- (day. month) |
| End | 663 | Eu | --:-- (day. month) |
| Operating level Frost protection Reduced | 668 | Eu | Frost Protection |
| Heating circuit 1 | | | |
| Operating mode Heating circuit 1 Protection Automatic Reduced Comfort | 700 | Eu | Automatic |
| Comfort setpoint | 710 | Eu | 20.0°C |
| Reduced setpoint | 712 | Eu | 18.0°C |
| Frost protection setpoint | 714 | Eu | 10.0°C |
| Heating curve slope | 720 | Eu | 1.50 |
| Heating curve displacement | 721 | E | 0.0°C |
| Heating curve adaption Off On | 726 | E | Off |
| Summer/winter heating limit | 730 | Eu | 20°C |
| 24-hour heating limit | 732 | E | - 0°C |
| Flow temp setpoint min | 740 | E | 8°C |


Programming

| Function | Prog. no. | Level ¹⁾ | Standard value |
|--|-----------|---------------------|--------------------------|
| Flow temp setpoint max | 741 | E | 80°C |
| Flow temp setpoint room stat | 742 | E | ---°C |
| Delay heat request | 746 | E | 0s |
| Room influence | 750 | C | --- % |
| Room temp limitation | 760 | E | 0.5°C |
| Boost heating | 770 | E | ---°C |
| Quick setback Off Down to reduced setpoint Down to frost prot setpoint | 780 | E | Down to reduced setpoint |
| Optimum start control max | 790 | E | 0 min |
| Optimum stop control max | 791 | E | 0 min |
| Reduced setp increase start | 800 | E | ---°C |
| Reduced setp increase end | 801 | E | -15°C |
| Continuous pump operation No Yes | 809 | E | No |
| Overtemp prot pump circuit Off On | 820 | E | Off |
| Mixing valve boost | 830 | E | 5°C |
| Actuator running time | 834 | E | 120 s |
| Floor curing function Off Functional heating Curing heating Functional/curing heating Curing/Functional heating Manually | 850 | C | Off |
| Floor curing setp manually | 851 | E | 25°C |
| Floor curing setp current | 855 | E | ---°C |
| Floor curing day current | 856 | E | 0°C |
| Excess heat draw Off Heating mode Always | 861 | E | Heating mode |
| With buffer storage tank Off Heating mode Always | 870 | E | Yes |
| With prim contr/system pump No Yes | 872 | E | Yes |
| Pump speed reduction Operating level Characteristic | 880 | E | Characteristic |
| Pump speed min | 882 | C | 10 % |
| Pump speed max | 883 | C | 100 % |
| Curve readj at 50% speed | 888 | E | 10 % |
| Flow setp readj speed ctrl No Yes | 890 | E | Yes |
| Operating level changeover Frost protection Reduced Comfort | 898 | E | Reduced |
| Optg mode changeover None Protection Reduced Comfort Automatic | 900 | E | Protection |
| Heating circuit 2 | | | |
|  Parameter only visible, if heating circuit 2 exists! | | | |
| Operating mode Heating circuit 2 Protection Automatic Reduced Comfort | 1000 | Eu | Automatic |

Programming

| Function | Prog. no. | Level ¹⁾ | Standard value |
|--|-----------|---------------------|--------------------------|
| Comfort setpoint | 1010 | Eu | 20.0°C |
| Reduced setpoint | 1012 | Eu | 18.0°C |
| Frost protection setpoint | 1014 | Eu | 10.0°C |
| Heating curve slope | 1020 | Eu | 1.50 |
| Heating curve displacement | 1021 | E | 0.0°C |
| Heating curve adaption Off On | 1026 | E | Off |
| Summer/winter heating limit | 1030 | Eu | 20°C |
| 24-hour heating limit | 1032 | E | - 0°C |
| Flow temp setpoint min | 1040 | E | 8°C |
| Flow temp setpoint max | 1041 | E | 80°C |
| Flow temp setpoint room stat | 1042 | E | -- °C |
| Delay heat request | 1046 | E | 0s |
| Room influence | 1050 | C | -- % |
| Room temp limitation | 1060 | E | 0.5°C |
| Boost heating | 1070 | E | -- °C |
| Quick setback Off Down to reduced setpoint Down to frost prot setpoint | 1080 | E | Down to reduced setpoint |
| Optimum start control max | 1090 | E | 0 min |
| Optimum stop control max | 1091 | E | 0 min |
| Reduced setp increase start | 1100 | E | -- °C |
| Reduced setp increase end | 1101 | E | -15°C |
| Continuous pump operation No Yes | 1109 | E | No |
| Overtemp prot pump circuit Off On | 1120 | E | Off |
| Mixing valve boost | 1130 | E | 5°C |
| Actuator running time | 1134 | E | 120 s |
| Floor curing function Off Functional heating Curing heating Functional/curing heating Curing/Functional heating Manually | 1150 | E | Off |
| Floor curing setp manually | 1151 | E | 25°C |
| Floor curing setp current | 1155 | E | -- °C |
| Floor curing day current | 1156 | E | 0°C |
| Excess heat draw Off Heating mode Always | 1161 | E | Heating mode |
| With buffer storage tank No Yes | 1170 | E | Yes |
| With prim contr/system pump No Yes | 1172 | E | Yes |
| Pump speed reduction Operating level Characteristic | 1180 | E | Characteristic |
| Pump speed min | 1182 | C | 10 % |
| Pump speed max | 1183 | C | 100 % |
| Curve readj at 50% speed | 1188 | E | 10 % |

Programming

| Function | Prog. no. | Level ¹⁾ | Standard value |
|--|-----------|---------------------|--------------------------|
| Flow setp readj speed ctrl No Yes | 1190 | E | Yes |
| Operating level changeover Frost protection Reduced Comfort | 1198 | E | Reduced |
| Optg mode changeover None Protection Reduced Comfort Automatic | 1200 | E | Protection |
| Heating circuit 3 | | | |
|  Parameter only visible, if heating circuit 3 exists! | | | |
| Operating mode Heating circuit 3 Protection Automatic Reduced Comfort | 1300 | Eu | Automatic |
| Comfort setpoint | 1310 | Eu | 20.0°C |
| Reduced setpoint | 1312 | Eu | 18.0°C |
| Frost protection setpoint | 1314 | Eu | 10.0°C |
| Heating curve slope | 1320 | Eu | 1.50 |
| Heating curve displacement | 1321 | E | 0.0°C |
| Heating curve adaption Off On | 1326 | E | Off |
| Summer/winter heating limit | 1330 | Eu | 20°C |
| 24-hour heating limit | 1332 | E | - 0°C |
| Flow temp setpoint min | 1340 | E | 8°C |
| Flow temp setpoint max | 1341 | E | 80°C |
| Flow temp setpoint room stat | 1342 | E | ---°C |
| Delay heat request | 1346 | E | 0s |
| Room influence | 1350 | C | --- % |
| Room temp limitation | 1360 | E | 0.5°C |
| Boost heating | 1370 | E | ---°C |
| Quick setback Off Down to reduced setpoint Down to frost prot setpoint | 1380 | E | Down to reduced setpoint |
| Optimum start control max | 1390 | E | 0 min |
| Optimum stop control max | 1391 | E | 0 min |
| Reduced setp increase start | 1400 | E | ---°C |
| Reduced setp increase end | 1401 | E | -15°C |
| Continuous pump operation No Yes | 1409 | E | No |
| Overtemp prot pump circuit Off On | 1420 | E | Off |
| Mixing valve boost | 1430 | E | 5°C |
| Actuator running time | 1434 | E | 120 s |
| Floor curing function Off Functional heating Curing heating Functional/curing heating Curing/Functional heating Manually | 1450 | E | Off |
| Floor curing setp manually | 1451 | E | 25°C |
| Floor curing setp current | 1455 | E | ---°C |
| Floor curing day current | 1456 | E | 0°C |

Programming

| Function | Prog. no. | Level ¹⁾ | Standard value |
|--|-----------|---------------------|--------------------------|
| Excess heat draw Off Heating mode Always | 1461 | E | Heating mode |
| With buffer storage tank No Yes | 1470 | E | Yes |
| With prim contr/system pump No Yes | 1472 | E | Yes |
| Pump speed reduction Operating level Characteristic | 1480 | E | Characteristic |
| Pump speed min | 1482 | C | 10 % |
| Pump speed max | 1483 | C | 100 % |
| Curve readj at 50% speed | 1488 | E | 10 % |
| Flow setp readj speed ctrl No Yes | 1490 | E | Yes |
| Operating level changeover Frost protection Reduced Comfort | 1498 | E | Reduced |
| Optg mode changeover None Protection Reduced Comfort Automatic | 1500 | E | Protection |
| DHW | | | |
| Nominal setpoint | 1610 | Eu | 55°C |
| Reduced setpoint | 1612 | E | 45°C |
| Release 24h/day Time programmes HCs Time programme 4/DHW | 1620 | Eu | Time program 4/DHW |
| Charging priority Absolute Shifting None MC shifting, PC absolute | 1630 | E | MC shifting, PC absolute |
| Legionella function Off Periodically Fixed weekday | 1640 | E | Fixed weekday |
| Legionella funct periodically | 1641 | E | 3 |
| Legionella funct weekday Monday Tuesday Wednesday Thursday Friday Saturday Sunday | 1642 | E | Sunday |
| Legionella funct time | 1644 | E | --- |
| Legionella funct setpoint | 1645 | E | 65°C |
| Legionella funct duration | 1646 | E | --- min |
| Legionella function circ pump Off On | 1647 | E | On |
| Circulating pump release Time programme 3 / HCP DHW release Time programme 4/DHW Time program 5 | 1660 | C | DHW release |
| Circulating pump cycling Off On | 1661 | C | On |
| Circulation setpoint | 1663 | E | 55°C |
| Optg mode changeover None Off On | 1680 | E | Off |
| Consumer circuit 1 | | | |
| Flow temp setp cons request | 1859 | C | 70°C |
| DHW charging priority - No Yes | 1874 | E | Yes |

Programming

| Function | Prog. no. | Level ¹⁾ | Standard value |
|---|-----------|---------------------|----------------|
| Excess heat draw - Off On | 1875 | E | ON |
| With buffer storage tank - No Yes | 1878 | E | Yes |
| With prim contr/system pump - No Yes | 1880 | E | Yes |
| Consumer circuit 2 | | | |
| Flow temp setp cons request | 1909 | C | 70°C |
| DHW charging priority No Yes | 1924 | E | Yes |
| Excess heat draw Off On | 1925 | E | ON |
| With buffer storage tank No Yes | 1928 | E | Yes |
| With prim contr/system pump No Yes | 1930 | E | Yes |
| Swimming pool circuit | | | |
| Flow temp setp cons request | 1959 | C | 70°C |
| DHW charging priority No Yes | 1974 | E | Yes |
| Excess heat draw Off On | 1975 | E | ON |
| With buffer No Yes | 1978 | E | Yes |
| With prim contr/system pump No Yes | 1980 | E | Yes |
| Swimming pool | | | |
| Setpoint solar heating | 2055 | Eu | 26°C |
| Setpoint source heating | 2056 | Eu | 22°C |
| Charging priority solar Priority 1 Priority 2 Priority 3 | 2065 | E | Priority 3 |
| Swimming pool temp max | 2070 | E | 32°C |
| With solar integration No Yes | 2080 | E | Yes |
| Primary contr/system pump | | | |
| Flow temp setpoint min | 2110 | E | 8°C |
| Flow temp setpoint max | 2111 | E | 80°C |
| Syst pump on heat gen lock Off On | 2121 | E | Off |
| Mixing valve boost | 2130 | E | 0°C |
| Actuator running time | 2134 | E | 120 s |
| Primary contr/system pump Before buffer After buffer | 2150 | E | After buffer |
| Primary contr/system pump Before buffer After buffer | 2150 | E | After buffer |

Programming

| Function | Prog. no. | Level ¹⁾ | Standard value |
|--|-----------|---------------------|--|
| Primary contr/system pump Before buffer After buffer | 2150 | E | After buffer |
| Primary contr/system pump Before buffer After buffer | 2150 | E | After buffer |
| Boiler | | | |
| Release below outside temp | 2203 | E | --- °C |
| Full charging buffer Off On | 2208 | E | Off |
| Setpoint min | 2210 | E | 20°C |
| Setpoint max | 2212 | E | 80°C |
| Setpoint manual control | 2214 | Eu | 60°C |
| Burner running time min | 2241 | E | 1 min |
| Burner running time min | 2243 | E | 3 min |
| SD burner off time | 2245 | E | 20°C |
| Pump overrun time | 2250 | E | 5 min |
| Pump overr time after DHW | 2253 | E | 5 min |
| Boiler pump on heat gen lock Off On | 2301 | E | Off |
| Impact heat generation lock Heating mode only Heating and DHW mode | 2305 | E | Heating and DHW mode |
| Temp differential max | 2316 | C | 45°C |
| Temp differential nominal | 2317 | C | 15°C |
| Pump modulation None Demand Boiler setpoint Temp differential nominal Burner output | 2320 | E | Temp differential nominal |
| Pump speed min | 2322 | E | 10 % |
| Pump speed max | 2323 | E | 100 % |
| Output nominal | 2330 | E | EC three 125: 125 kW EC three 170: 170 kW EC three 215: 215 kW EC three 260: 260 kW EC three 300: 300 kW |
| Output basic stage | 2331 | E | EC three 125: 20 kW EC three 170: 28 kW EC three 215: 35 kW EC three 260: 42 kW EC three 300: 48 kW |
| Output at pump speed min | 2334 | E | 10 % |
| Output at pump speed max | 2335 | E | 90 % |
| Max fan output heating operation | 2441 | E | EC three 125: 125 kW EC three 170: 170 kW EC three 215: 215 kW EC three 260: 260 kW EC three 300: 300 kW |


Programming

| Function | Prog. no. | Level ¹⁾ | Standard value |
|--|-----------|---------------------|--|
| Max fan output heating full charging | 2442 | E | EC three 125: 125 kW EC three 170: 170 kW EC three 215: 215 kW EC three 260: 260 kW EC three 300: 300 kW |
| Fan output DHW max. | 2444 | E | EC three 125: 125 kW EC three 170: 170 kW EC three 215: 215 kW EC three 260: 260 kW EC three 300: 300 kW |
| Fan shutdown heating mode Off On | 2445 | E | Off |
| Fan shutdown delay | 2446 | E | 15 s |
| Controller delay Off Heating mode only DHW mode only Heating and DHW mode | 2450 | E | Heating and DHW mode |
| Fan output controller delay | 2452 | E | EC three 125: 20 kW EC three 170: 28 kW EC three 215: 35 kW EC three 260: 42 kW EC three 300:48 kW |
| Control delay duration | 2453 | E | 0 s |
| Switching diff on HCs | 2454 | E | 4°C |
| Switching diff off min HCs | 2455 | E | 3°C |
| Switching diff off max HCs | 2456 | E | 5°C |
| Switching diff on DHW | 2460 | E | 4°C |
| Switching diff off min DHW | 2461 | E | 5°C |
| Switching diff off max DHW | 2462 | E | 7°C |
| Delay heat req special op | 2470 | E | 0 s |
| Pressure switch shutdown Start prevention Lockout position | 2500 | E | Start prevention |
| Cascade | | | |
| Lead strategy Late on, early off Late on, late off Early on, late off | 3510 | E | Late on, late off |
| Release integral source seq | 3530 | E | 50°C*min |
| Reset integral source seq | 3531 | E | 20°C*min |
| Restart lock | 3532 | E | 300 s |
| Switch on delay | 3533 | E | 10 min |
| Auto source seq ch'over | 3540 | E | 100 h |
| Auto source seq exclusion None First Last First and last | 3541 | E | None |
| Leading source Source 1 Source 2 Source 3 Source 4 Source 5 Source 6 Source 7 Source 8 Source 9 Source 10 Source 11 Source 12 Source 13 Source 14 Source 15 Source 16 | 3544 | E | Source 1 |
| Return setpoint min | 3560 | E | 8°C |
| Temp differential min | 3590 | E | --°C |
| Solar | | | |

Programming

| Function | Prog. no. | Level ¹⁾ | Standard value |
|---|-----------|---------------------|-------------------|
| Temp diff on | 3810 | C | 8°C |
| Temp diff off | 3811 | C | 4°C |
| Charg temp min DHW st tank | 3812 | I | --- °C |
| Temp diff on buffer | 3813 | E | --- °C |
| Temp diff off buffer | 3814 | E | --- °C |
| Charging temp min buffer | 3815 | E | --- °C |
| Temp diff on swi pool | 3816 | E | --- °C |
| Temp diff off swi pool | 3817 | E | --- °C |
| Charging temp min swi pool | 3818 | E | --- °C |
| Charging prio storage tank None DHW storage tank Buffer storage tank | 3822 | E | DHW storage tank |
| Charging time relative prio | 3825 | E | --- min |
| Waiting time relative prio | 3826 | E | 5 min |
| Waiting time parallel op | 3827 | E | --- min |
| Delay secondary pump | 3828 | E | 60 s |
| Collector start function | 3830 | E | --- |
| Min run time collector pump | 3831 | E | 20 s |
| Collector start function On | 3832 | E | 07:00 (h:min) |
| Collector start function Off | 3833 | E | 19:00 (h:min) |
| Collector start funct grad | 3834 | E | --- min/°C |
| Collector frost protection | 3840 | E | --- °C |
| Collector overtemp prot | 3850 | E | --- °C |
| Evaporation heat carrier | 3860 | E | 130°C |
| Antifreeze None Ethylene glycol Propylene glycol Ethyl and propyl glycol | 3880 | E | Propylene glycol |
| Antifreeze concentration | 3881 | E | 50% |
| Pump capacity | 3884 | E | 200 l/h |
| Pulse valency | 3887 | E | 10 l |
| Solid fuel boiler | | | |
| Locks other heat sources Off On | 4102 | E | Off |
| Setpoint min | 4110 | E | 65°C |
| Temp diff on | 4130 | E | 8°C |
| Temp diff off | 4131 | E | 4°C |
| Comparative temp DHW sensor B3 DHW sensor B31 Buffer sensor B4 Buffer sensor B41 Flow temp setpoint Setpoint min | 4133 | E | Buffer sensor B41 |
| Pump overrun time | 4140 | E | 20 min |
| Buffer storage tank | | | |
| Auto heat gen lock None With B4 With B4 and B42/B41 | 4720 | E | With B4 |
| Auto heat gen lock SD | 4721 | E | 5°C |
| Temp diff buffer/HC | 4722 | E | -3°C |
| Min st tank temp heat mode | 4724 | E | --- °C |

Programming

| Function | Prog. no. | Level ¹⁾ | Standard value |
|---|-----------|---------------------|----------------|
| Charging temp max | 4750 | E | 80°C |
| Recooling temperature | 4755 | E | 60°C |
| Recooling DHW/HCs Off On | 4756 | E | Off |
| Recooling collector Off Summer Always | 4757 | E | Off |
| With solar integration No Yes | 4783 | E | Yes |
| Temp diff on return div | 4790 | E | 8°C |
| Temp diff off return div | 4791 | E | 4°C |
| Compar temp return div With B4 With B41 With B42 | 4795 | E | With B4 |
| Optg action return diversion Temp decrease Temp increase | 4796 | E | Temp increase |
| Full charging Off Heating mode Always | 4810 | E | Off |
| Full charging temp min | 4811 | E | 8°C |
| Full charging sensor With B4 with B42/41 | 4813 | E | With B42/41 |
| DHW-storage | | | |
|  Parameter depends on hydraulic system! | | | |
| Charge push forward time | 5011 | E | 01:00 min |
| Flow setpoint boost | 5020 | E | 18°C |
| Transfer boost | 5021 | E | 10°C |
| Type of charging Recharging Full charging Full charging legio Full charg 1st. time day Full charg 1st time legio. Charging | 5022 | E | Full charging |
| Switching diff | 5024 | E | 4°C |
| Charging time limitation | 5030 | E | 120 min |
| Discharging protection Off Always Automatically | 5040 | E | Automatic |
| Charging temp max | 5050 | E | 65°C |
| Re-cooling temperature | 5055 | E | 80°C |
| Recooling collector Off Summer Always | 5057 | E | Off |
| El imm heater optg mode Substitute Summer Always | 5060 | E | Substitute |
| El immersion heater release 24h/day DHW release Time program 4/DHW | 5061 | E | DHW release |
| El immersion heater control External thermostat DHW sensor | 5062 | E | DHW sensor |
| Automatic-Push: Off On | 5070 | E | On |
| Excess heat draw Off On | 5085 | E | On |

| Function | Prog. no. | Level ¹⁾ | Standard value |
|---|-----------|---------------------|-----------------|
| With buffer storage tank No Yes | 5090 | E | Yes |
| With prim contr/system pump No Yes | 5092 | E | Yes |
| With solar integration No Yes | 5093 | E | Yes |
| Pump speed min | 5101 | E | 0% |
| Pump speed max | 5102 | E | 100% |
| Speed Xp | 5103 | E | 35°C |
| Speed Tn | 5104 | E | 120 s |
| Speed Tv | 5105 | E | 45 s |
| Transfer strategy Always DHW release | 5130 | E | Always |
| Interm circ boost recharging | 5139 | E | 5°C |
| Intermediate circuit boost | 5140 | E | 3°C |
| Excess interm circ temp max | 5141 | E | 2°C |
| Flow setp compensation delay | 5142 | E | 30 s |
| Flow setp compensation Xp | 5143 | E | 60°C |
| Flow setp compensation Tn | 5144 | E | 30 s |
| Flow setp compensation Tv | 5145 | E | 30 s |
| Full charging with B36 No Yes | 5146 | E | Yes |
| Min start temp diff Q33 | 5148 | E | -3°C |
| Excess interm circ temp del | 5151 | E | 30 s |
| Configuration | | | |
| Heating circuit 1 Off On | 5710 | C | On |
| Heating circuit 2 Off On | 5715 | C | Off |
| Heating circuit 3 Off On | 5721 | C | Off |
| DHW sensor DHW sensor B3 Thermostat | 5730 | E | DHW sensor B3 |
| DHW controlling element Q3 No charging request Charging pump Diverting valve | 5731 | E | Charging pump |
| Basic pos DHW div valve Last request Heating circuit DHW | 5734 | E | Heating circuit |
| DHW separate circuit Off On | 5736 | E | Off |
| Optg action DHW div valve Position on DHW Position on heating circuit | 5737 | E | Position on DHW |
| Ctrl boiler pump/DHW valve All requests Request HC1/DHW only | 5774 | E | All requests |
| Solar controlling element Charging pump Diverting valve | 5840 | E | Diverting valve |

Programming

| Function | Prog. no. | Level ¹⁾ | Standard value |
|--|-----------|---------------------|----------------------------|
| External solar exchanger Jointly DHW storage tank Buffer storage tank | 5841 | E | Jointly |
| Combi storage tank No Yes | 5870 | E | No |
| Relay output QX1 None Circulating pump Q4 El imm heater DHW K6 Collector pump Q5 Cons circuit pump VK1 Q15 Boiler pump Q1 Alarm output K10 Heat circuit pump HC3 Q20 Cons circuit pump VK2 Q18 System pump Q14 Heat gen shutoff valve Y4 Solid fuel boiler pump Q10 Time program 5 K13 Buffer return valve Y15 Solar pump ext exch K9 Solar ctrl elem buffer K8 Solar ctrl elem swi pool K18 Cons circuit pump VK3 Q19 Cascade pump Q25 St tank transfer pump Q11 DHW mixing pump Q35 DHW interm circ pump Q33 Heat request K27 Heat circuit pump HC1 Q2 Heat circuit pump HC2 Q6 DHW ctrl elem Q3 Status output K35 Status information K36 Flue gas damper K37 Flue gas damper K37 | 5890 | C | Alarm output K10 |
| Relay output QX2 Parameters see Relay output QX1 (prog.-no. 5890)! | 5891 | C | Heat circuit pump HC1 Q2 |
| Relay output QX3 Parameters see Relay output QX1 (prog.-no. 5890)! | 5892 | C | DHW controlling element Q3 |
| Sensor input BX1 None DHW sensor B31 Collector sensor B6 DHW circulation sensor B39 Buffer sensor B4 Buffer sensor B41 Common flow sensor B10 Solid fuel boiler sensor B22 DHW charging sensor B36 Buffer sensor B42 Common return sensor B73 Cascade return sensor B70 Swimming pool sensor B13 Solar flow sensor B63 Solar return sensor B64 | 5930 | C | Collector sensor B6 |
| Sensor input BX2 Parameters see Sensor input BX1 (prog.-no. 5930)! | 5931 | C | DHW sensor B31 |
| Sensor input BX3 Parameters see Sensor input BX1 (prog.-no. 5930)! | 5932 | C | Buffer sensor B4 |
| Function input H1 None Optg mode change HCs+DHW Optg mode changeover DHW Optg mode changeover HCs Optg mode changeover HC1 Optg mode changeover HC2 Optg mode changeover HC3 Heat generation lock Error/alarm message Consumer request VK1 Consumer request VK2 Consumer request VK3 Excess heat discharge Release swi pool solar Operating level DHW Operating level HC1 Operating level HC2 Operating level HC3 Room thermostat HC1 Room thermostat HC2 Room thermostat HC3 DHW thermostat Pulse count Checkb sign flue gas damper Start prevention Consumer request VK1 10V Consumer request VK2 10V Consumer request VK3 10V Preselected output 10V | 5950 | C | None |
| Contact type H1 NC NO | 5951 | C | NO |
| Voltage value 1 H1 | 5953 | E | 0 V |
| Function value 1 H1 | 5954 | E | 0 |
| Voltage value 2 H1 | 5955 | E | 10 V |
| Function value 2 H1 | 5956 | E | 100 |

| Function | Prog. no. | Level ¹⁾ | Standard value |
|--|-----------|---------------------|-------------------|
| Function input H4 None Optg mode change HCs+DHW Optg mode changeover DHW Optg mode changeover HCs Optg mode changeover HC1 Optg mode changeover HC2 Optg mode changeover HC3 Heat generation lock Error/alarm message Consumer request VK1 Consumer request VK2 Consumer request VK3 Excess heat discharge Release swi pool solar Operating level DHW Operating level HC1 Operating level HC2 Operating level HC3 Room thermostat HC1 Room thermostat HC2 Room thermostat HC3 DHW thermostat Pulse count Checkb sign flue gas damper Start prevention Flow measurement Hz | 5970 | C | None |
| Contact type H4 NC NO | 5971 | C | NO |
| Frequency value 1 H4 | 5973 | E | 0 |
| Function value 1 H4 | 5974 | E | 0 |
| Frequency value 2 H4 | 5975 | E | 0 |
| Function value 2 H4 | 5976 | E | 0 |
| Function input H5 None Optg mode change HCs+DHW Optg mode changeover DHW Optg mode changeover HCs Optg mode changeover HC1 Optg mode changeover HC2 Optg mode changeover HC3 Heat generation lock Error/alarm message Consumer request VK1 Consumer request VK2 Consumer request VK3 Excess heat discharge Release swi pool solar Operating level DHW Operating level HC1 Operating level HC2 Operating level HC3 Room thermostat HC1 Room thermostat HC2 Room thermostat HC3 DHW thermostat Pulse count Checkb sign flue gas damper Start prevention | 5977 | C | None |
| Contact type H5 NC NO | 5978 | C | NO |
| Function extension module 1 None Multifunctional Heating circuit 1 Heating circuit 2 Heating circuit 3 Solar DHW Primary contr/system pump | 6020 | C | Heating circuit 2 |
| Function extension module 2 Parameters see extension module 1 (prog.-no. 6020)! | 6021 | C | Heating circuit 3 |
| Function extension module 3 Parameters see extension module 1 (prog.-no. 6020)! | 6022 | C | None |
| Relay output QX21 module 1 Parameters see Relay output QX1 (prog.-no. 5890)! | 6030 | C | None |
| Relay output QX22 module 1 Parameters see Relay output QX1 (prog.-no. 5890)! | 6031 | C | None |
| Relay output QX23 module 1 Parameters see Relay output QX1 (prog.-no. 5890)! | 6032 | C | None |
| Relay output QX21 module 2 Parameters see Relay output QX1 (prog.-no. 5890)! | 6033 | C | None |
| Relay output QX22 module 2 Parameters see Relay output QX1 (prog.-no. 5890)! | 6034 | C | None |
| Relay output QX23 module 2 Parameters see Relay output QX1 (prog.-no. 5890)! | 6035 | C | None |
| Relay output QX21 module 3 Parameters see Relay output QX1 (prog.-no. 5890)! | 6036 | C | None |

Programming

| Function | Prog. no. | Level ¹⁾ | Standard value |
|--|-----------|---------------------|----------------|
| Relay output QX22 module 3 Parameters see Relay output QX1 (prog.-no. 5890)! | 6037 | C | None |
| Relay output QX23 module 3 Parameters see Relay output QX1 (prog.-no. 5890)! | 6038 | C | None |
| Sensor input BX21 module 1 Parameters see Sensor input BX1 (prog.-no. 5930)! | 6040 | C | None |
| Sensor input BX22 module 1 Parameters see Sensor input BX1 (prog.-no. 5930)! | 6041 | C | None |
| Sensor input BX21 module 2 Parameters see Sensor input BX1 (prog.-no. 5930)! | 6042 | C | None |
| Sensor input BX22 module 2 Parameters see Sensor input BX1 (prog.-no. 5930)! | 6043 | C | None |
| Sensor input BX21 module 3 Parameters see Sensor input BX1 (prog.-no. 5930)! | 6044 | C | None |
| Sensor input BX22 module 3 Parameters see Sensor input BX1 (prog.-no. 5930)! | 6045 | C | None |
| Function input H2 module 1 None Optg mode change HCs+DHW Optg mode changeover DHW Optg mode changeover HCs Optg mode changeover HC1 Optg mode changeover HC2 Optg mode changeover HC3 Heat generation lock Error/alarm message Consumer request VK1 Consumer request VK2 Consumer request VK3 Excess heat discharge Release swi pool solar Operating level DHW Operating level HC1 Operating level HC2 Operating level HC3 Room thermostat HC1 Room thermostat HC2 Room thermostat HC3 Limit thermostat HC Start prevention Consumer request VK1 10V Consumer request VK2 10V Consumer request VK3 10V Preselected output 10V | 6046 | C | None |
| Contact type H2 module 1 NC NO | 6047 | C | NO |
| Voltage value 1 H2 module 1 | 6049 | E | 0 Volt |
| Funct value 1 H2 module 1 | 6050 | E | 0 |
| Voltage value 2 H2 module 1 | 6051 | E | 10 Volt |
| Funct value 2 H2 module 1 | 6052 | E | 100 |
| Function input H2 module 2 Parameters see Function input H2 module 1 (prog.-no. 6046)! | 6054 | C | None |
| Contact type H2 module 2 NC NO | 6055 | C | NO |
| Voltage value 1 H2 module 2 | 6057 | E | 0 Volt |
| Funct value 1 H2 module 2 | 6058 | E | 0 |
| Voltage value 2 H2 module 2 | 6059 | E | 10 Volt |
| Funct value 2 H2 module 2 | 6060 | E | 100 |
| Function input H2 module 3 Parameters see Function input H2 module 1 (prog.-no. 6046)! | 6062 | C | None |
| Contact type H2 module 3 NC NO | 6063 | E | NO |
| Voltage value 1 H2 module 3 | 6065 | E | 0 Volt |
| Funct value 1 H2 module 3 | 6066 | E | 0 |
| Voltage value 2 H2 module 3 | 6067 | E | 10 Volt |








| Function | Prog. no. | Level ¹⁾ | Standard value |
|--|-----------|---------------------|---------------------------|
| Funct value 2 H2 module 3 | 6068 | E | 100 |
| PWM-output P1 None Boiler pump Q1 DHW pump Q3 DHW interm circ pump Q33 Heat circuit pump HC1 Q2 Heat circuit pump HC2 Q6 Heat circuit pump HC3 Q20 Collector pump Q5 Solar pump ext exch K9 Solar pump buffer K8 Solar pump swi pool K18 | 6085 | E | Boiler pump Q1 |
| Sensor type collector NTC PT 1000 | 6097 | E | NTC |
| Readjustm collector sensor | 6098 | E | 0°C |
| Readjustm outside sensor | 6100 | E | 0°C |
| Time constant building | 6110 | C | 10 h |
| Central setp compensation | 6117 | E | 20°C |
| Frost protection plant Off On | 6120 | E | On |
| Saving sensors No Yes | 6200 | C | No |
| Check no heat source 1 | 6212 | E | - |
| Check no heat source 2 | 6213 | E | - |
| Check no storage tank | 6215 | E | - |
| Check no. heating circuits | 6217 | E | - |
| Software version | 6220 | E | |
| LPB-system | | | |
| Device address | 6600 | C | 1 |
| Bus power supply function Off Automatic | 6604 | E | Automatic |
| Bus power supply state Off On | 6605 | E | |
| Display system messages No Yes | 6610 | E | Yes |
| Alarm delay | 6612 | E | --- min |
| Action changeover functions Segment System | 6620 | E | System |
| Summer changeover Locally Centrally | 6621 | E | Locally |
| Optg mode changeover Locally Centrally | 6623 | E | Centrally |
| Manual source lock Locally Segment | 6624 | E | Locally |
| DHW assignment Local HCs All HCs in segment All HCs in system | 6625 | E | All HCs in system |
| Note OT limit ext source No Yes | 6632 | E | No |
| Clock mode Autonomously Slave without remote setting Slave with remote set- ting Master | 6640 | C | Slave with remote setting |
| Outside temp source | 6650 | E | |










Programming

| Function | Prog. no. | Level ¹⁾ | Standard value |
|--|-----------|---------------------|----------------|
| Fault | | | |
| Fault message | 6700 | Eu | |
| SW diagnostic code | 6705 | Eu | |
| Burn ctrl phase lockout pos | 6706 | Eu | |
| Reset alarm relay No Yes | 6710 | C | No |
| Flow temp 1 alarm | 6740 | E | --- min |
| Flow temp 2 alarm | 6741 | E | --- min |
| Flow temp 3 alarm | 6742 | E | --- min |
| Boiler temp alarm | 6743 | E | --- min |
| DHW charging alarm | 6745 | E | --- h |
| History 1 - Date / Time - Error code 1 | 6800 | E | |
| SW diagnostic code 1 - Burner control phase 1 | 6805 | E | |
| History 2 - Date / Time - Error code 2 | 6810 | E | |
| SW diagnostic code 2 - Burner control phase 2 | 6815 | E | |
| History 3 - Date / Time - Error code | 6820 | E | |
| SW diagnostic code 3 - Burner control phase 3 | 6825 | E | |
| . | . | . | . |
| . | . | . | . |
| . | . | . | . |
| . | . | . | . |
| History 20 - Date / Time - Error code 20 | 6990 | E | |
| SW diagnostic code 20 - Burner control phase 20 | 6995 | E | |
| Service / special operation | | | |
| Burner hours interval | 7040 | E | --- h |
| Burn hrs since maintenance | 7041 | E | 0 h |
| Burner start interval | 7042 | E | --- |
| Burn starts since maint | 7043 | E | 0 |
| Maintenance interval | 7044 | E | --- months |
| Time since maintenance | 7045 | E | 0 months |
| Fan speed ionization current | 7050 | E | 0 rpm |
| Message ionization current No Yes | 7051 | E | No |

| Function | Prog. no. | Level ¹⁾ | Standard value |
|--|-----------|---------------------|----------------|
| Chimney-sweep function Off On | 7130 | Eu | Off |
| Manual control Off On | 7140 | Eu | Off |
| Controller stop function Off On | 7143 | E | Off |
| Controller stop setpoint | 7145 | E | |
| Telephone customer service | 7170 | C | --- |
| PStick storage pos | 7250 | E | 0 |
| PStick Reg data set | 7251 | E | |
| PStick command No operation Reading from stick Writing on stick | 7252 | E | No operation |
| PStick progress | 7253 | E | 0 % |
| State PStick No stick Stick ready Writing on stick Reading from stick EMC test active Writing error Reading error Incompatible data set Wrong stick type Stick format error Check data set Data set disabled Reading disabled | 7254 | E | |
| Input/output test | | | |
| Relay test No test Everything off Relay output QX1 Relay output QX2 Relay output QX3 Relay output QX21 module 1 Relay output QX22 module 1 Relay output QX23 module 1 Relay output QX21 module 2 Relay output QX22 module 2 Relay output QX23 module 2 Relay output QX21 module 3 Relay output QX22 module 3 Relay output QX23 module 3 | 7700 | C | No test |
| Output test P1 | 7713 | C | |
| PWM-output P1 | 7714 | C | |
| Outside temp B9 | 7730 | C | |
| DHW temp B3/B38 | 7750 | C | |
| Boiler temp B2 | 7760 | C | |
| Sensor temp BX1 | 7820 | C | |
| Sensor temp BX2 | 7821 | C | |
| Sensor temp BX3 | 7822 | C | |
| Sensor temp BX21 module 1 | 7830 | C | |
| Sensor temp BX22 module 1 | 7831 | C | |
| Sensor temp BX21 module 2 | 7832 | C | |
| Sensor temp BX22 module 2 | 7833 | C | |
| Sensor temp BX21 module 3 | 7834 | C | |
| Sensor temp BX22 module 3 | 7835 | C | |
| Voltage signal H1 | 7840 | C | |
| Contact state H1 Open Closed | 7841 | C | |
| Voltage signal H2 module 1 | 7845 | C | |
| Contact state H2 module 1 Open Closed | 7846 | C | |

Programming

| Function | Prog. no. | Level ¹⁾ | Standard value |
|--|-----------|---------------------|----------------|
| Voltage signal H2 module 2 | 7848 | C | |
| Contact state H2 module 2 Open Closed | 7849 | C | |
| Voltage signal H2 module 3 | 7851 | C | |
| Contact state H2 module 3 Open Closed | 7852 | C | |
| Contact state H4 Open Closed | 7860 | C | |
| Frequency H4 | 7862 | C | |
| Contact state H5 Open Closed | 7865 | C | |
| Contact state H6 Open Closed | 7872 | C | |
| State | | | |
| State heating circuit 1 | 8000 | C | |
| State heating circuit 2 | 8001 | C | |
| State heating circuit 3 | 8002 | C | |
| State DHW | 8003 | C | |
| State boiler | 8005 | C | |
| State solar | 8007 | C | |
| State solid fuel boiler | 8008 | C | |
| State burner | 8009 | C | |
| State buffer storage tank | 8010 | C | |
| State swimming pool | 8011 | C | |
| Diagnostics cascade | | | |
|  Parameter not intended for operation with WGS ! | | | |
| Priority/state source 1 Missing Faulty Manual control active Heat generation lock active Chimney sweep funct active Temporarily unavailable Outside temp limit active Not released Released | 8100 | C | |
| Priority/state source 2  Parameters see Priority/state source 1 (prog.no. 8100)! | 8102 | C | |
| Priority/state source 3  Parameters see Priority/state source 1 (prog.no. 8100)! | 8104 | C | |
| Priority/state source 4  Parameters see Priority/state source 1 (prog.no. 8100)! | 8106 | C | |
| Priority/state source 5  Parameters see Priority/state source 1 (prog.no. 8100)! | 8108 | C | |
| Priority/state source 6  Parameters see Priority/state source 1 (prog.no. 8100)! | 8110 | C | |
| Priority/state source 7  Parameters see Priority/state source 1 (prog.no. 8100)! | 8112 | C | |

| Function | Prog. no. | Level ¹⁾ | Standard value |
|---|-----------|---------------------|----------------|
| Priority/state source 8  Parameters see Priority/state source 1 (prog.no. 8100)! | 8114 | C | |
| Priority/state source 9  Parameters see Priority/state source 1 (prog.no. 8100)! | 8116 | C | |
| Priority/state source 10  Parameters see Priority/state source 1 (prog.no. 8100)! | 8118 | C | |
| Priority/state source 11  Parameters see Priority/state source 1 (prog.no. 8100)! | 8120 | C | |
| Priority/state source 12  Parameters see Priority/state source 1 (prog.no. 8100)! | 8122 | C | |
| Priority/state source 13  Parameters see Priority/state source 1 (prog.no. 8100)! | 8124 | C | |
| Priority/state source 14  Parameters see Priority/state source 1 (prog.no. 8100)! | 8126 | C | |
| Priority/state source 15  Parameters see Priority/state source 1 (prog.no. 8100)! | 8128 | C | |
| Priority/state source 16  Parameters see Priority/state source 1 (prog.no. 8100)! | 8130 | C | |
| Cascade flow temp | 8138 | C | |
| Cascade flow temp setp | 8139 | C | |
| Cascade return temp | 8140 | C | |
| Cascade return temp setp | 8141 | C | |
| Source seq ch'over current | 8150 | C | |
| Diagnostics heat generation | | | |
| Boiler pump Q1 | 8304 | E | |
| Boiler pump speed | 8308 | E | |
| Boiler temp | 8310 | C | |
| Boiler temperature setpoint | 8311 | C | |
| Boiler switching point | 8312 | C | |
| Control sensor None Boiler sensor B2 Return sensor B7 DHW charging sensor B36 DHW outlet sensor B38 DHW circulation sensor B39 Cascade sensor B10/B70 | 8313 | E | |
| Boiler return temp | 8314 | C | |
| Fan speed | 8323 | C | |
| Set point fan | 8324 | C | |
| Current fan control | 8325 | C | |
| Burner modulation | 8326 | C | |
| Ionization current | 8329 | C | |
| Hours run 1st stage | 8330 | Eu | |
| Start counter 1st stage | 8331 | C | |

Programming


| Function | Prog. no. | Level ¹⁾ | Standard value |
|---|-----------|---------------------|----------------|
| Hours run heating mode | 8338 | Eu | |
| Hours run DHW | 8339 | Eu | |
| Current phase number | 8390 | E | |
| Collector pump 1 | 8499 | C | |
| Solar ctrl elem buffer | 8501 | E | |
| Solar ctrl elem swi pool | 8502 | E | |
| Collector temp 1 | 8510 | C | |
| Collector temp 1 max | 8511 | C | |
| Collector temp 1 min | 8512 | C | |
| dt collector 1/DHW | 8513 | C | |
| dt collector 1/buffer | 8514 | C | |
| dt collector 1/swimming pool | 8515 | C | |
| Solar flow temp | 8519 | E | |
| Solar return temp | 8520 | E | |
| 24-hour yield solar energy | 8526 | Eu | |
| Total yield solar energy | 8527 | Eu | |
| Hours run solar yield | 8530 | Eu | |
| Hours run collect overtemp | 8531 | E | |
| Hours run Collector pump | 8532 | Eu | |
| Solid fuel boiler temp | 8560 | C | |
| Hours run solid fuel boiler | 8570 | C | |
| Diagnostics consumers | | | |
| Outside temperature | 8700 | Eu | |
| Outside temperature minimum | 8701 | Eu | |
| Outside temperature maximum | 8702 | Eu | |
| Outside temp attenuated | 8703 | E | |
| Outside temp composite | 8704 | E | |
| Heating circuit pump 1 Off On | 8730 | C | |
| Heat circ mix valve 1 open Off On | 8731 | C | |
| Heat circ mix valve 1 close Off On | 8732 | C | |
| Speed heating circuit pump 1 | 8735 | C | |
| Room temp 1 | 8740 | C | |
| Room setpoint 1 | | C | |
| Flow temp 1 | 8743 | C | |
| Flow temp setpoint 1 | 8 | | |
| Room thermostat 1 No demand Demand | 8749 | C | |
| Heating circuit pump 2 Off On | 8760 | C | |
| Heat circ mix valve 2 open Off On | 8761 | C | |

Programming

| Function | Prog. no. | Level ¹⁾ | Standard value |
|---|-----------|---------------------|----------------|
| Heat circ mix valve 2 close Off On | 8762 | C | |
| Speed heating circuit pump 2 | 8765 | C | |
| Room temp 2 | 8770 | C | |
| Room setpoint 2 | | | |
| Flow temp 2 | 8773 | C | |
| Flow temp setpoint 2 | | | |
| Room thermostat 2 No demand Demand | 8779 | C | |
| Heating circuit pump 3 Off On | 8790 | C | |
| Heat circ mix valve 3 open Off On | 8791 | C | |
| Heat circ mix valve 3 close Off On | 8792 | C | |
| Speed heating circuit pump 3 | 8795 | C | |
| Room temp 3 | 8800 | C | |
| Room setpoint 3 | | | |
| Flow temp 3 | 8804 | C | |
| Flow temp setpoint 3 | | | |
| Room thermostat 3 No demand Demand | 8809 | C | |
| DHW pump Off On | 8820 | C | |
| Speed DHW pump | 8825 | E | |
| Speed DHW interm circ pump | 8826 | E | |
| DHW temp 1 | 8830 | C | |
| DHW temp setpoint | | C | |
| DHW temp-actual value bottom (B31) | 8832 | C | |
| DHW circulation temp | 8835 | E | |
| DHW charging temp | 8836 | E | |
| Flow temp setpnt consumer circuit 1 | 8875 | C | |
| Flow temp setpnt consumer circuit 2 | 8885 | C | |
| Flow temp setpnt swimming pool | 8895 | C | |
| Swimming pool temp | 8900 | C | |
| Swimming pool setpoint | 8901 | C | |
| Primary controller temp | 8930 | E | |
| Primary controller setpoint | 8931 | E | |
| Common flow temperature | 8950 | E | |
| Common flow temp setpoint | 8951 | E | |
| Common return temp | 8952 | E | |
| Common output setpoint | 8962 | E | |
| Buffer temp 1 | 8980 | C | |
| Buffer setpoint | 8981 | C | |

Programming

| Function | Prog. no. | Level ¹⁾ | Standard value |
|--|-----------|---------------------|--|
| Buffer temp 2 | 8982 | C | |
| Buffer temp 3 | 8983 | C | |
| Relay output QX1 Off On | 9031 | C | |
| Relay output QX2 Off On | 9032 | C | |
| Relay output QX3 Off On | 9033 | C | |
| Relay output QX21 module 1 Off On | 9050 | C | |
| Relay output QX22 module 1 Off On | 9051 | C | |
| Relay output QX23 module 1 Off On | 9052 | C | |
| Relay output QX21 module 2 Off On | 9053 | C | |
| Relay output QX22 module 2 Off On | 9054 | C | |
| Relay output QX23 module 2 Off On | 9055 | C | |
| Relay output QX21 module 3 Off On | 9056 | C | |
| Relay output QX22 module 3 Off On | 9057 | C | |
| Relay output QX23 module 3 Off On | 9058 | C | |
| Burner control | | | |
| Prepurge time | 9500 | F | 20 s |
| Nominal output prepurging | 9504 | F | EC three 125: 59,3 kW EC three 170: 75,5 kW EC three 215: 77,1 kW EC three 260: 97,7 kW EC three 300: 103,9 kW |
| Nominal output ignition load | 9512 | F | EC three 125: 59,3 kW EC three 170: 75,5 kW EC three 215: 77,1 kW EC three 260: 97,7 kW EC three 300: 103,9 kW |
| Nominal output Partial load | 9524 | F | EC three 125: 20 kW EC three 170: 28 kW EC three 215: 35 kW EC three 260: 42 kW EC three 300: 48 kW |
| Nominal output full load | 9529 | F | EC three 125: 125 kW EC three 170: 170 kW EC three 215: 215 kW EC three 260: 260 kW EC three 300: 300 kW |
| Postpurge time | 9540 | F | 20 s |

| Function | Prog. no. | Level ¹⁾ | Standard value |
|---|-----------|---------------------|---|
| Fan output/speed slope | 9626 | F | EC three 125: 37,1 EC three 170: 27,6 EC three 215: 26,4 EC three 260: 20,1 EC three 300: 19,9 |
| Fan output/speed Y-section | 9627 | F | EC three 125: 501,1 EC three 170: 517,2 EC three 215: 464,4 EC three 260: 488,0 EC three 300: 431,7 |
| Info Option | | | |
|  The display of the information values depends on the operation status! | | | |
| Fault message Servicing message Setpoint manual control Floor curing setp current Floor curing day current Room temperature Room temperature min Room temperature max Cascade flow temp Controller stop setpoint Boiler temp Outside temp Outside temp min Outside temp max DHW temp 1 DHW consumption temp Collector temp 1 24-hour yield solar energy Solid fuel boiler temp Buffer temp 1 Swimming pool temp State heating circuit 1 State heating circuit 2 State heating circuit 3 State DHW State boiler State solar State solid fuel boiler State buffer storage tank State swimming pool Year Date | | | |

Programming

| Function | Prog. no. | Level ¹⁾ | Standard value |
|--|-----------|---------------------|----------------|
| Time Telephone customer service | | | |
| ¹⁾ Eu = End user; C = Commissioning; E = Engineer | | | |



Note: Parameters with the program numbers 1- 54 are individual parameters of the operating unit and the room unit and may, therefore, be set differently on both devices. All parameters from programme number 500 onwards are stored on the controller and, therefore, identical. The value changed last is the valid value.

8.4 Explanations for setting table

8.4.1 Time and date

Time of day and date
(1 - 3)

The control has a year clock with setting possibilities for time, day, month and year. Time and date must be correctly set, so that the heating programs can operate to previously carried out programming.

Summertime
(5 - 6)

The start of the summertime can be set under prog. no. 5; the end of summertime will be set under prog. no. 6. The time changing will be carried out on the Sunday following the set date.

8.4.2 Operator section

Language
(20)

The language of the menu guidance can be modified under prog. no. 20.

Info
(22)

Temporarily: The information display returns to the basic display after 8 minutes.
Permanently: The information display remains permanently displayed after call-up with the information button.

Contrast of display
(25)

Under prog. no. 25 the contrast of the display can be adjusted.

Operation lock
(26)

If this function is activated the following operating elements are locked:

- Operating mode buttons for heating and DHW mode
- Control knob (comfort-setpoint room temperature)
- Presence button (only room device)

Programming lock
(27)

In case of switched on lock, the parameters can be displayed, but not changed.

- Temporary unlocking:
Press the OK- and the ESC-button simultaneously for at least 3 sec. The lock will be re-activated after leaving the setting level.
- Permanent unlocking:
At first temporary unlocking, then prog. no. 27 to "Off".

Units
(29)

Prog. no. 29 enables you to select SI units (°C, bar) or US units (°F, PSI).

Operator section save basic settings
(30)



The data of the control will be written into the room unit (only available for room unit).

Caution! The data of the room unit will be overwritten! With this, the individual programming of the control in the room unit can be ensured.

Operator section activate basic settings
(31)



The data of the operating unit or room unit will be written into the control.

Caution: The data of the control will be overwritten! The factory settings are stored in the operating unit.

- Activation of the prog. no. 31 at the *operating unit*:
The control will be reset to the **factory settings**.
- Activation of the prog. no. 31 at the *room unit*:
The individual programming of the room unit will be written into the control.



This parameter is only visible if a suitable standard setting is available in the programming unit.

Use as
(40)

- *room device 1/2*: this setting establishes which heating circuit the room unit on which this setting is made should be used. When selecting **room unit 1** the room device can be assigned to more heating circuits using prog. no. 42, while with the selection of **room unit 2** only heating circuit 2 can be controlled.
- *Operator unit*: this setting is provided for the pure operation without room functions and is not needed in connection with this controller.
- *service unit*: this setting is used, for example, to secure or save control settings.

Room controller 1 assignment
(42)

If setting **Room controller 1** (prog. no. 40) was selected at the room controller, determine the heating circuits to which room controller 1 is assigned under prog. no. 42.

Operation HC2/HC3/P
(44, 46)

When selecting **room unit 1** or **operator unit** (prog.no. 40), it must be set under prog. no. 44 or 46, if the heating circuits HC2 and HC3/P have to be operated together with heating circuit 1 or independent from heating circuit 1 by the operator unit.

Room temperature Unit 1
(47)

Under prog. no. 47 you can select the assignment of room controller 1 to the heating circuits.

Heating circuit 1 only: The room temperature is sent exclusively to heating circuit 1.

For all assigned heating circuits: The room temperature is sent to the heating circuits assigned under prog. no. 42.

Occupancy button device 1
(48)

You can select the assignment of the occupancy button under prog. no. 48.

None: Pressing the presence key has no effect on the heating circuits.

Heating circuit 1 only: The presence key only affects heating circuit 1.

For all assigned HCs: The presence key affects the heating circuits assigned under prog. no. 42.

Programming

Readjustment room sensor
(54)

The temperature display of the value, transmitted by the room sensor, can be corrected under programme no. 54.

Software version
(70)

Display of the current software version.

8.4.3 Radio



Detailed descriptions are in the assembly and setting manual of the room device RGTF.

Device lists
(130 to 138)

The state of the respective device will be displayed under programme numbers 130 to 138.

Delete all devices
(140)

The radio connections to all devices will be cancelled under programme number 140.

8.4.4 Time programs



Note: The time programme 1 and 2 are always assigned to the respective heating circuits (1 - 3) and only displayed if these heating circuits are present and also turned on in the menu **Configuration** (prog.-no. 5710 and 5715).

Time program 3 can be used for the Heating circuit 3, for the DHW and for the circulation pump, depending on the setting, and is always displayed.

Time program 4 can be used for the DHW and for the circulation pump, depending on the setting, and is always displayed.

Time program 5 is not assigned a function and can be freely used for any application using an output QX.

Preselection
(500, 520, 540, 560, 600)

Selection of weekday or day blocks. The day blocks (Mo-Su, Mo-Fr and Sa-Su) assist the adjustment. The set times are only copied to the individual weekdays and can be changed in the individual day settings, as required. The times of the individual weekdays always determine the heating program.



Note: If a time in a group of days is changed, all 3 start/stop phases will be copied to the day group automatically.

To call up groups of days (Mo-Su, Mo-Fr or Sa-Su), turn the rotary selector anti-clockwise; to call up individual days (Mo, Tu, We, Th, Fr, Sa, Su), turn the rotary selector clockwise.

Heating phases
(501 to 506, 521 to 526, 541 to 546, 561 to 566, 601 to 606)

Up to three heating phases may be set per heating circuit, which will be activated on the days, set under the **preselection**(prog.-no. 500, 520, 540, 560, 600). In the heating phases, it will be heated at the set comfort setpoint. Outside the heating phases, it will be heated at the reduced setpoint.



Note: The time programmes are only activated in the operation mode "Automatic".

Copy
(515, 535, 555, 575, 615)



The time switching program for one day can be copied and assigned to another or several other days.

Note: Day blocks cannot be copied.

Default values
(516, 536, 556, 576, 616)

Setting of the default values given in the setting table

8.4.5 Holiday programs

The heating circuits may be set to a selectable operation level with the holiday program during a certain holiday period.

Preselection
(641, 651, 661)

8 vacation periods can be selected with this preselection.

Start of holiday
(642, 652, 662)

Entering the holiday start

End of holiday
(643, 653, 663)

Input of holiday end

Operatin level
(648, 658, 668)

Selection of the operation level (reduced setpoint or frost protection) for the holiday program.



Note: A holiday period ends each time on the last day at 12:00 AM (00:00). The holiday programs are only activated in the operation mode **Automatic**.

8.4.6 Heating circuits

Comfort setpoint
(710, 1010, 1310)

Setting the maximum comfort setpoint in the heating phases. Without room sensor or with the room influence (prog.no. 750, 1050, 1350), this value is used for calculation of the flow temperature, to theoretically reach the set room temperature.

Reduced setpoint
(712, 1012, 1312)

Setting of the desired room temperature during the reduced heating phase. Without room sensor or with the room influence (prog.no. 750, 1050, 1350), this value is used for calculation of the flow temperature, to theoretically reach the set room temperature.

Frost protection setpoint
(714, 1014, 1314)

Setting of the desired room temperature during the frost protection operation. Without room sensor or with the room influence (prog.no. 750, 1050, 1350), this value is used for calculation of the flow temperature, to theoretically reach the set room temperature. The heating circuit remains turned off until the flow temperature drops so far that the room temperature falls below the frost protection temperature.


Heating curve slope
(720, 1020, 1320)

Using the heating curve, the flow temperature setpoint is formed, which is used for control of the heating circuit, based on the outside temperature. The slope of the curve indicates by how much the flow temperature changes with changing outside temperature.

Programming

Determination of the heating curve slope

Enter lowest calculated outside temperature according to climate zone (e.g. -1°C in London) into the diagram (see Fig. 14) (e.g. vertical line at -1°C). Enter the maximum flow temperature of the heating circuit, which is reached by calculating with -1°C outside temperature at 20°C room temperature e.g., horizontal line at 82°C). The intersecting point gives the value for the heating curve slope.



Heating curve displacement
(721, 1021, 1321)

Correction of the heating curve by parallel shifting in case of generally too high or too low room temperature.

Heating curve adaption
(726, 1026, 1326)

Automatic adaptation of the heating nominal line to the actual circumstances, due to which a correction of the heating nominal line gradient becomes obsolete.




For automatic adaptation of the heating curve a room sensor must be connected. The value for room influence (see prog. no. 750, 1050, 1350) must be set between 1% and 99%. Should there be radiator valves in the leading room (assembly location of the room sensor), these have to be fully opened.

Summer/winter heating limit
(730, 1030, 1330)

As soon as the average of the outside temperatures of the last 24 hours rises 1°C over the value set here, the heating circuit switches into summer mode. As soon as the average of the outside temperatures of the last 24 hours drops 1°C below the value set here, the heating circuit switches back into winter mode.

Fig. 15: Summer/winter heating limit



SWHL Summer/winter heating limit
 T Temperature
 t Time

24-hour heating limit
 (732, 1032, 1332)



The 24-hour heating limit shuts off the heating circuit if the current outside temperature increases up to the difference set here of the current operating level (reduced or comfort set point). The heating cuts on again if the current outside temperature again falls under the set difference minus 1°C.

This function is not active in the operating modes **Continuous Comfort** and **Continuously Reduced**.

Flow temp setpoint limitations
 Minimum
 (740, 1040, 1340)
 Maximum
 (741, 1041, 1341)

With this function, a range can be defined for the flow setpoint. When the required flow temperature setpoint of the heating circuit reaches the respective limit value, this remains constantly on maximum or minimum value during continuously increasing or decreasing heat requirement.

Flow temp setpoint room stat
 (742, 1042, 1342)

For room thermostat mode the flow setpoint set here applies. Setting -- °C gives the flow temperature setpoint from the outside temperature and the heating curve.

Delay heat request
 (746, 1046, 1346)

The boiler heat request is forwarded to the burner delayed by the time set here. In this way a slowly opening mixer can already start up before the burner goes into operation.



Note: If, under Prog. no. 1630 the option *Absolute* is selected, the value "0" must be set under Prog.no. 746, 1046 and 1346. For special functions (e.g. chimney-sweep function) the delay does not have an effect (see Prog. no. 2470).

Programming

Room influence
(750, 1050, 1350)



The flow temperature is calculated using the heating curve as a factor of the outside temperature. This type of control assumes that the heating curve is set correctly, since the control does not take any room temperature into consideration in this setting.

Note: However, if there is a RGTf or RGB room unit is connected and the setting "room influence" is set between 1 and 99%, the deviation of the room temperature compared to the set point is recorded and taken into consideration in the temperature control. In this way existing external heat can be considered and a constant room temperature is possible. The influence of the deviation can be set in percentage. The better the leading room is (correct room temperature, correct installation location, etc.), the higher the value can be set and the room temperature is taken into consideration even more.



Caution! Open radiator valves!

Should there be radiator valves in the leading room (assembly location of the room sensor), these have to be fully opened.

- Setting for weather compensation with room influence: 1% - 99%
- Setting for pure weather compensation: - - - %
- Setting for pure room compensation: 100%


Room temp limitation
(760, 1060, 1360)



The heating circuit pump will be switched on or off, depending on the room temperature due to the switching difference set here. The switch-off point of the pump is set as difference to the set room set point. The switching-on time of the pump is in the set room setpoint. This function is only possible with the RGT/ RGTf or RGB room unit and active room influence.

A room sensor must be connected.

Fig. 16: Room temp limitation




| | |
|-----|-------------------------------|
| TRx | Room temperature actual value |
| TRw | Room temperature setpoint |
| SDR | Room switching difference |
| P | Pump |
| t | Time |

Boost heating (770, 1070, 1370)

The boost heating is active if the room set point is switched from protection mode or reduced mode to comfort mode. During the boost heating the the room set point is increased to the value set here. This causes the actual room temperature to increase to the new set point within a short period of time. The boost heating is ended if the room temperature measured with a RGT/RGTF or RGB (accessories) room unit increases to 0.25 °C below the comfort set point.

Without room sensor or without room influence the boost heating is carried out based on an internal calculation. Due to the room set point acting as a basis, the effect of the duration of the boost heating and that of the flow temperature works differently for each outside temperature.



Quick setback (780, 1080, 1380)

The quick setback is active if the room setpoint is switched from comfort level to another operating level (selected between reduced mode or protection mode). During the quick setback the heating circuit pump is turned off and the mixing valve is also closed during mixing circuits. During the quick setback no heat requirement is sent to the heat generator.

The quick setback is possible with or without room sensor: with room sensor the heating circle function is switched off as long as the room temperature has dropped to the reduced setpoint or frost protection setpoint. If the room temperature has dropped to the reduced setpoint or the frost protection setpoint, the heating circuit pump is switched on again and the mixing valve is released. Without the room sensor the quick setback switched the heater off depending on the outside temperature and the building time constant (prog.no. 6110) as long as the temperature has theoretically dropped to the reduced target value or the frost protection value.

Duration of the quick setback for setback by 2°C in h:
(e.g. comfort setpoint = 20°C, reduced setpoint = 18°C)

| Outside temperature composite: | Building time constant (configuration, programme number 6110) | | | | | | |
|--------------------------------|---|-------|-------|--------|------|------|--------|
| | 0 hrs | 2 hrs | 5 hrs | 10 hrs | 15 h | 20 h | 50 hrs |
| 15°C | 0 | 3.1 | 7,7 | 15.3 | 23 | | |
| 10°C | 0 | 1,3 | 3,3 | 6,7 | 10 | 13,4 | |
| 5°C | 0 | 0.9 | 2,1 | 4.3 | 6.4 | 8,6 | 21,5 |
| 0°C | 0 | 0,6 | 1,6 | 3,2 | 4.7 | 6,3 | 15.8 |
| -5°C | 0 | 0,5 | 1,3 | 2,5 | 3,8 | 5 | 12,5 |


Programming

| | | | | | | | |
|--|--|-------|-------|--------|------|------|--------|
| -10°C | 0 | 0,4 | 1 | 2,1 | 3,1 | 4,1 | 10,3 |
| -15°C | 0 | 0,4 | 0,9 | 1,8 | 2,6 | 3,5 | 8,8 |
| -20°C | 0 | 0,3 | 0,8 | 1,5 | 2,3 | 3,1 | 7,7 |
| Duration of the quick setback for setback by 4°C in h: | | | | | | | |
| Outside temperature composite: | Building time constant (configuration, programme number 6110) | | | | | | |
| | 0 hrs | 2 hrs | 5 hrs | 10 hrs | 15 h | 20 h | 50 hrs |
| 15°C | 0 | 9,7 | 24,1 | | | | |
| 10°C | 0 | 3,1 | 7,7 | 15,3 | 23 | | |
| 5°C | 0 | 1,9 | 4,7 | 9,3 | 14 | 18,6 | |
| 0°C | 0 | 1,3 | 3,3 | 6,7 | 10 | 13,4 | |
| -5°C | 0 | 1 | 2,6 | 5,2 | 7,8 | 10,5 | 26,2 |
| -10°C | 0 | 0,9 | 2,1 | 4,3 | 6,4 | 8,6 | 21,5 |
| -15°C | 0 | 0,7 | 1,8 | 3,6 | 5,5 | 7,3 | 18,2 |
| -20°C | 0 | 0,6 | 1,6 | 3,2 | 4,7 | 6,3 | 15,8 |

Optimum start control max
(790, 1090, 1390)
Optimum stop control max
(791, 1091, 1391)


The optimization of the on/off switching time is a function of time and possible with or without the room unit. With a room unit the conversion of the operating level compared to the programmed time point is moved forward so that the building dynamics (heat up and cool down time) is considered. In this way the desired temperature level is reached exactly at the programmed time point. If this is not the case (too early or too late) a new switching time point is calculated which is used the next time.

Without room sensor an advance time is calculated based on the outside temperature and the building time constant (prog. no. 6110). The optimization time (advance) is limited here to a maximum value. By setting the optimization time = 0, the function is switched off.



Reduced setp increase start
(800, 1100, 1400)
Red setp increase end
(801, 1101, 1401)

For a relatively small required heating output, the reduced room setpoint can be raised for cold outside temperatures. The increase is dependent upon the outside temperature. The lower the outside temperature is, the higher the reduced setpoint for the room temperature is raised. The start of the increase and the end point can be set. Between these two points there is a linear increase of the "reduced setpoint" up to the "comfort setpoint".



Continuous pump operation
(809, 1109, 1409)

Using the *continuous pump operation* function switching off the pump can be suppressed by the quick setback and when reaching the room set point (room thermostat, room sensor or room model)

- No: the heating circuit pump /boiler pump can be switched off by quick setback or reaching the room set point
- Yes: the heating circuit pump/boiler pump remains switched on even during the quick setback and after reaching the room set point

Overtemp prot pump circuit
(820, 1120, 1420)

This function prevents overheating of the pumped heating circuit by switching-on and switching-off the pump, if the flow temperature is higher than the flow temperature required according to the heating curve (e.g. in case of higher demands of other consumers).

Mixing valve boost
(830, 1130, 1430)

The heat demand of the mixer heating circuit to the generator is superelevated above the set value here. This boost should be achieved so that the temperature fluctuations can be corrected with the mixer valve.

Actuator running time
(834, 941, 1134)

For mixing circuits, a kick-start of the mixer drive is carried out after a pump kick-start (Pump is OFF). In this case, the mixer will be controlled in direction OPEN and CLOSED.

The time of activation in direction OPEN corresponds to the drive running time.


Programming

Floor curing function
(850, 1150, 1450)

The floor curing function serves controlled drying out of screed floors

- *Off*: the function is switched off.
- *Functional heating (Fh)*: Part 1 of the temperature profile will be run through automatically.
- *Curing heating (Ch)*: Part 2 of the temperature profile will be run through automatically.
- *Functional heating and curing heating*: The whole temperature profile will be run through automatically.
- *Manually*: Control to the floor curing setpoint manually.

Fig. 20: Temperature profile of the floor -curing function



- X Starting day
- Fh Functional heating
- Ch Curing heating



Important! The respective regulations and standards of the screed manufacturer have to be observed.

A correct function is only possible with a correctly installed plant (hydraulic, electrical systems and settings).

Deviations can only lead to damage of the screed.

The floor curing function can be stopped prematurely by setting **0=OFF**.

Floor curing setp manually
(851, 1151, 1451)

Setting of temperature, up to which manual control is carried out at activated floor curing function (see prog. no. 850).

Floor curing setp current
(855, 1155, 1455)

Display of the current floor curing setpoint.

Screed day actual
(856, 1156, 1456)

Display of the current day of the floor curing function.

| | |
|--|---|
| Excess heat draw (861, 1161, 1461) | <p>If the excess temperature draw is activated via input H1 to H5 or a maximum temperature is exceeded in the system, this excess heat energy can be released by a heat draw of the room heating.</p> <ul style="list-style-type: none">- <i>Off</i>: the function is switched off.- <i>Heating mode</i>: the function is limited to only a draw during the heating time.- <i>Always</i>: the function is generally released. |
| With buffer (870, 1170, 1470) | <p>This parameter establishes whether the heating circuit can be supplied by a buffer or only from a heat generator. The function has the effect of whether with a heat demand the system pump goes into operation.</p> <ul style="list-style-type: none">- <i>No</i>: the heating circuit is supplied from the boiler.- <i>Yes</i>: the heating circuit can be supplied from the buffer. |
| With primary controller/system pump (872, 1172, 1472, 5092) | <p>This parameter establishes whether a zone system pump goes into operation with a heat demand of the heating circuit. This system pump is based on the segment, in which this controller is located (LPB bus system) and which is controlled with a primary control.</p> <ul style="list-style-type: none">- <i>No</i>: the heating circuit will be fed without primary control unit/feed pump.- <i>Yes</i>: the heating circuit is supplied after the primary control with the system pump. |
| Pump speed reduction (880, 1180, 1480) | <p>Speed reduction of the heating circuit pump can be done acc. to operating level or acc. to pump characteristic curve.</p> <p><i>Operating level</i>: With this option the speed of the heating circuit pump is calculated acc. to the operating level. The pump is controlled in operating level comfort (incl. optimization) or during active floor curing function with parameterized maximum speed. With reduced operating level the pump is controlled with the parameterized minimum speed.</p> <p><i>Characteristic</i>: The pump speed of the heating circuit pump is calculated based on the actually held flow temperature and the current flow set point. The common flow temp setpoint is used for the actual value. If no common flow temperature sensor is available the boiler flow actual value is used. The temperature actual value is attenuated with a filter (time constant capable of parameterization)</p> |
| Pump speed min (882, 1182, 1482) | <p>Using this function the minimum speed for the heating circuit pump can be specified.</p> |
| Pump speed max (883, 1183, 1483) | <p>Using this function the maximum speed for the heating circuit pump can be specified.</p> |
| Curve readj at 50% speed (888, 1188, 1488) | <p>Correction of the flow setpoint with reduction of the pump speed by 50%. The correction is calculated from the difference from the flow setpoint according to the heating curve and current room setpoint.</p> |
| Flow setp readj speed ctrl (890, 1190, 1490) | <p>Here it can be specified whether the calculated flow setpoint correction is included in the temperature request or not.</p> <ul style="list-style-type: none">- <i>No</i>: the temperature request remains unchanged. The calculated correction value is not added.- <i>Yes</i>: the temperature request includes the flow setpoint correction. |

Programming

Operating level changeover
(898, 1198, 1498)

Using an external timer above the entrances *Hx* it can be selected in which operating level the heating circuit is switched into.

- *Frost Protection:*
- *Reduced:*
- *Comfort:*

Optg mode changeover
(900, 1200, 1500)

In case of external changeover of the operating mode per *Hx* it can be selected, if in automatic mode changeover will be carried out from nominal comfort value to the frost protection value or the reduced nominal value.

8.4.7 DHW

Nominal setpoint
(1610)

Setting the DHW nominal setpoint.


Reduced setpoint
(1612)

The DHW reduced setpoint is set under prog. no. 1612.

Release
(1620)


- *24h/day:* The DHW temperature will be continuously controlled to the nominal drinking water temperature value independent from the time switching programmes.
- *Time programs HCs:* The DHW temperature will be switched over between the nominal DHW temperature value and the reduced nominal DHW temperature value depending on the time switching programs. Every time, the switching-on time will be moved forward.
- In case of several releases per day, it is moved forward by 1 hour (see Fig. 21).

Fig. 21: Release depending on the time switching programmes of the heating circuits (example#)



- *Time program 4* The DHW temperature will be switched over between the nominal setpoint and the reduced setpoint independent from the time switching programs of the heating circuits. In this case, the time switching programme 4 will be used (see Fig. 22).

Fig. 22: Release according to time switching programme 4 (example)



Charging priority (1630)

This function ensures that the boiler capacity is primarily made available for DHW in case of simultaneous capacity demand by room heating and DHW.

- *Absolute priority*: Mixer and pumped heating circuits are blocked until the DHW has been heated up.
- *Shifting priority*: Should the boiler capacity not be sufficient to heat up DHW, mixer and pumped heating circuits will be restricted.
- *None priority*: Charging DHW is carried out in parallel with heating operation.
- *MC shifting, PC absolute*: Pumped heating circuits are blocked until the DHW has been heated up. Should the boiler capacity not be sufficient, also the mixer circuit will be restricted.

Legionella function (1640)

Function to kill legionella germs by heating up to the set legionella function setpoint (see programme number 1645).

- *Off*: Legionella function is switched off.
- *Periodically*: Legionella function is repeated periodically, depending on the set value (prog. no. 1641).
- *Fixed weekday*: Legionella function will be activated on a certain weekday (prog. no. 1642).

Legionella funct periodically (1641)

Setting the interval for the **legionella function periodically** (recommended setting in case of additional drinking water heating by solar plant in connection with a st tankmixing pump).

Legionella funct weekday (1642)

Selection of the weekday for the legionella function **fixed weekday** (factory setting).

Legionella funct time (1644)

Setting the start time for the legionella function. The legionella function will be carried out at the first release of the DHW preparation with the setting "---".

Legionella funct setpoint (1645)

Setting the temperature setpoint for killing the germs.

Legionella funct duration (1646)

With this function, the time will be set, during which the legionella function setpoint is activated to kill germs.



If the colder storage temperature rises above the **legionella function setpoint** by -1 K, the **legionella function setpoint** is assumed as met and the timer starts running. If the storage temperature drops by more than the switching difference +2 K below the required **legionella function setpoint**, the duration has to be met again. If no duration has been set, the legionella function has been met immediately on reaching the **legionella function setpoint**.

Programming

Legionella function circ pump
(1647)



- *On*: The circulation pump will be switched on in case of active legionella function.

Caution! There exists a hazard of scalding at the tapping locations in case of activated legionella function.

Circulating pump release
(1660)

- *Time program 3* The DHW circulating pump is enabled subject to time program 3 (see prog. no. 540 to 556).

- *DHW release*: The DHW circulating pump will be enabled when DHW heating has been enabled.

- *Time program 4* The DHW circulating pump will be enabled subject to time program 4.

Circulating pump cycling
(1661)

The circulating pump will be switched on for 10 minutes and off for 20 minutes within the release time.

Circulation setpoint
(1663)

In case of undercutting the circulation setpoint (Standard value: 45°C), the circulation pump will be switched on for 10 minutes within the release time. When reaching the circulation setpoint, but at the earliest 10 minutes later, the pump is switched off. For this function, the connection of a sensor in the circulation return is necessary (inputs BX, program no. 5930-5933).

Optg mode changeover
(1680)

Using external switching above the entrances H1-H5 it can be selected into which operating mode is switched into.

- *None*: the function is switched off.

8.4.8 Consumer circuit and swimming pool circuit

Flow temp setp cons request
(1859, 1909, 1959)

Setting of the flow setpoint is done with this function, which is effective during active request of the consumer circuit.

DHW charging priority
(1874, 1924, 1974)

Setting, if the connected consumerscircuit pump should be used with priority for domestic hot water charging.

Excess heat draw
(1875, 1925, 1975)

If an excess temperature discharge is activated, the excess energy can be discharged through a consumerscircuit of the room heating. This can be separately set for each consumerscircuit.

With buffer storage tank
(1878, 1928, 1978)

- *No*: the consumer circuit is fed directly from the boiler.

- *Yes*: the consumer circuit is fed directly from the charging buffer.

With prim contr/system
pump
(1880, 1930, 1980)

- *No*: the consumer circuit will be fed without primary control unit/feed pump

- *Yes*: the consumer circuit will be charged from the primary controller on/with the system pump.

8.4.9 Swimming pool

Setpoint solar heating
(2055)

When using solar energy, the swimming pool is heated to the setpoint set here.

Setpoint source heating
(2056)

When using the generator heating, the swimming pool is heated to the setpoint set here.

Charging priority solar (2065) Setting of which priority the swimming pool will be solar heated. The priority for the DHW and charging buffer is set under Prog. no. 3822.

- *Priority 1*: the swimming pool is heated, **before** the buffer is charged.
- *Priority 2*: the swimming pool is heated, **while** the buffer is charged.
- *Priority 3*: the swimming pool is heated, **after** the buffer is charged.

Swimming pool temp Maximum (2070) This parameter sets whether the swimming pool heating by solar charging has priority or not. If the swimming pool temp reaches the heating limit set here, the collector pump is switched off. It is again released if the swimming pool temp has dropped by 1 °C below the maximum heating limit temperature.

With solar integration (2080) Setting of whether the swimming pool heating can be done by solar energy or not.

8.4.10 Primary contr/system pump

Flow temp setpoint min (2110)
Flow temp setpoint max (2111) With these boundaries a range for the flow setpoint can be defined.

Syst pump on heat gen lock (2121) This parameter can set whether during active heat generation lock the system pump will also be locked or not.

- *Off*: The system pump will not be locked.
- *On*: During active heat generation lock the system pump will also be locked.

Mixing valve boost (2130) For the admixture the boiler flow temperature actual value must be higher as the requested setpoint of the mixer flow temperature, since these cannot otherwise be corrected. The controller from the boiler temperature setpoint from the boost set here and the current flow temperature setpoint.

Actuator running time (2134) Setting the actuator running time of the used mixing valve.

Prim contr/system pump (2150) - *Before buffer storage tank*: the primary controller/feed pump is arranged with existing buffer storage tank hydraulically before the buffer storage tank
- *After buffer storage tank*: the primary controller/feed pump is arranged with existing buffer storage tank hydraulically after the buffer storage tank

8.4.11 Boiler

Release below outside temp (2203) The boiler is only put into operation if the mixed outside temperature is below the threshold set here. The switching difference is 0.5°C.

Full charging buffer (2208) Under Prog. no. 4810 (full charge charging buffer) is selected, whether and when the charging buffer is fully charged despite automatic heat generation lock. Under Prog.no. 2203 it is set, whether the boiler takes part in the full charge or not.



- *Off*: the boiler does **not** take part in the full charging of the charging buffer.
- *On*: the boiler takes part in the full charging of the charging buffer.

Setpoint min (2210)
Setpoint max (2212) As a protection function the boiler temperature setpoint can be limited below by the minimum setpoint (prog.no. 2210) and above by the maximum setpoint (prog.no. 2212).

Programming

| | |
|---|--|
| Setpoint manual control (2214) | The Temperature to which the boiler will be controlled in manual control mode (also see prog. no. 7140). |
| Burner running time min (2241) | Here the time span after start up of the burner is set in which the switch off difference is increased by 50 %. However, this setting does not guarantee that the burner always remains in operation for the set time span. |
| Burner off time min (2243) | The boiler minimum pause time only takes effect between heating requirements coming following in sequence. The boiler minimum pause time blocks the boiler for a set time. |
| SD burner off time (2245) | When exceeding this switching difference, the <i>burner pausing time minimum</i> (prog.-no. 2243) will be interrupted. The boiler starts despite pausing time. |
| Pump overrun time (2250) Pump overr time after DHW (2253) | The delay times of the pumps are controlled according to heating mode or DHW mode. |
| Boiler pump at heat generation lock (2301) | Stop of boiler pump in case of activated manual heat generation lock (e.g. via H1). <ul style="list-style-type: none">- <i>Off</i>: Switching off not activated- <i>On</i>: Switching off activated |
| Impact heat generation lock (2305) | With these parameter it can be set whether the heat generation lock should be effective only for heating requests or also for DHW requests. <ul style="list-style-type: none">- <i>Heating mode only</i>: Only the heating request is locked. DHW requests will continue to be operated.- <i>Heating and DHW mode</i>: All heating and DHW requests will be locked. |
| Temp differential max (2316) | The limit of the boiler stroke is only possible if a valid value of the boiler return temperature is available. Caution! The limit of the boiler stroke is only performed if a modulating heat circuit pump is configured, i.e. if Prog. no. 6085 (PWM-output P1) is assigned to a heating circuit pump. |
| Temp differential nominal (2317) | The expansion between boiler flow temperature and boiler return temperature is called the temperature rise. For operation with a modulating pump, the temperature rise is limited with this parameter. |



| | |
|---|---|
| <p>Pump modulation (2320)</p> | <ul style="list-style-type: none"> - <i>None</i>: the function is switched off. - <i>Demand</i>: Actuation of the boiler pump occurs with the speed calculated for the DHW pump during DHW mode or with the highest calculated speed for the max. 3 heating circuit pumps during pure heating mode. The calculated pump speed for heating circuit 2 and 3 is only evaluated if these heating circuits are also dependent on the setting of the diverting valve (Parameter <i>boiler pump/DHW diverting valve control</i>). - <i>Boiler setpoint</i>: The boiler pump modulates its speed so that the current setpoint (DHW or buffer storage tank) is achieved on boiler flow. The speed of the boiler pump must be raised within the specified limits until the burner has reached its upper output limit. - <i>Temp differential nominal</i>: The boiler output is controlled to the boiler setpoint. The control of the pump speed controls the speed of the boiler pump so that the nominal rise between the boiler return and boiler flow is held. If the actual rise is larger than the nominal rise, the pump speed is increased, otherwise the pump speed is reduced. - <i>Burner output</i>: If the burner is operated with low output then the boiler pump should also run on low speed. During high boiler output the boiler pump should run on high speed. |
| <p>Pump speed min (2322)</p> | <p>For the modulating pump the working range can be defined in percent of output. The control translates the percent data internally into speeds. The value "0%" corresponds to the minimum pump speed.</p> |
| <p>Pump speed max (2323)</p> | <p>The pump speed and with it, the power consumption can be limited via the maximum value.</p> |
| <p>Output nominal (2330) Output basic stage (2331)</p> | <p>The settings under prog.no. 2330 and prog.no. 2331 are necessary when setting up boiler cascades with boilers of different power. The values are requested from the cascade controller.</p> |
| <p>Output at pump speed min (2334) Output at pump speed max (2335)</p> | <p>If under the prog. no. 2320 option burner load is selected, the boiler pump is operated up to the set burner load under prog. no line 2334 to minimum pump speed. from the set burner output set under prog. no. 2335 the boiler pump is operated on maximum pump speed. If the burner output lies between these two values, the pump speed for the boiler pump is given by linear conversion.</p> |
| <p>Max fan output heating operation (2441)</p> | <p>With this parameter the maximum boiler capacity can be limited in heating mode.</p> |
|  | <p>Note: These are calculated values. The actual output must be calculated using a gas meter, for example.</p> |
| <p>Max fan output heating full charging (2442)</p> | <p>With this parameter the maximum boiler capacity can be limited in full charging mode at layer storage.</p> |
|  | <p>Note: These are calculated values. The actual output must be calculated using a gas meter, for example.</p> |

Programming

Fan output DHW max.
(2444)

With this parameter the maximum boiler capacity for the DHW mode can be restricted.



Note: These are calculated values. The actual output must be calculated using a gas meter, for example.

Fan shutdown heating mode
(2445)

This function is used for switching off the supply voltage for the fan. The supply voltage for the fan is released as soon as the fan PWM actuation is active or a DHW request exists. The switch off is done delayed to switch off of the PWM actuation or to discontinuation of the DHW request. The duration of the switch off delay can be set with the fan switch off delay function (prog.no. 2446). During a DHW request the voltage supply for the fan also remains then released if the PWM actuation is not active.

Fan shutdown delay
(2446)

If no heating requirement exists the voltage supply of the fan is switched off. The time is set here in which the fan gets voltage anyway.

Controller delay
(2450)

The controller delay is used for a stabilisation of the combustion conditions, especially after a cold start. After release of the firing automation by the controller this remains on the set output for a specified time. Only after this time has elapsed is the modulation released.

Prog. no. 2450 is used to set at which operating mode the controller delay is active.

Controller delay fan output
(2452)

Boiler capacity which is used during the duration of the control delay.




Note: The calculated value see prog-no. 2444.

Controller delay duration
(2453)

Duration of the control delay. The time duration starts as soon as after ignition a positive flame detection is done.

- Switching diff on HCs (2454)
- Switching diff off min HCs (2455)
- Switching diff off max HCs (2456)
- Switching diff on DHW (2460)
- Switching diff off min DHW (2461)
- Switching diff off max DHW (2462)

To avoid unnecessary switch off during transient effects the switch off difference adapts dynamically depending on the temperature profile (see Fig. 23).



- Delay heat request special op (2470)

The heat request during special operation (chimney-sweep function, controller stop, manual operation) is sent to the burner delayed by the time set here. In this way slowly opening mixers can already start up before the burner goes into operation. Thus a boiler temperature that is too high can be prevented.

- Pressure switch shutdown (2500)

This function checks the static water pressure with the aid of the connected water pressure switch. Depending on the set option (*start prevention* or *lockout position*) with shutdown either a start prevention or lockout position occurs with the corresponding diagnostics.

A closed water pressure switch releases the commissioning on the burner control and the actuation of the pumps. With open pressure switch is a start prevention or lockout position triggered.

The pump actuation is also locked for protection against dry running. If the water pressure increases again and the switch closes again, with a start prevention these are automatically again cancelled and the pump actuation is again released.

8.4.12 Cascade

- Lead strategy (3510)


Considering the specified output range the heat generation is switched on and off acc. to the set lead strategy. To switch off the effect of the die output range, the limits must be set to 0% and 100% and the lead strategy to late on, late off.

- *Late on, early off*: additional boiler is switched on as late as possible (output range max) and back off as early as possible (output range max). I.e. boiler in operation as little as possible, or short running times for additional boiler.
- *Late on, late off*: additional boiler is switched on as late as possible (output range max) and back off as late as possible (output range min). I.e. as few as possible on and off processes as possible for the boiler.
- *Early on, late off*: additional boiler is switched on as early as possible (output range min) and back off as late as possible (output range min). I.e. boiler in operation as much as possible, or as long as possible running times for additional boiler.

Programming

| | |
|---|--|
| Release integral source seq (3530) | A value generated from temperature and time. The following boiler will be switched on in case of exceeding the set limit. . |
| Reset integral source seq (3531) | The following boiler will be switched off in case of exceeding the setpoint |
| Restart lock (3532) | The restart lock prevents switching back on of a switched off boiler. Only after the set time period has elapsed is it again released. This prevents too frequent switching on and off of the boiler and achieves a stable operating condition of the system. |
| Switch-on delay (3533) | Too frequent forward and back switching (cycles) of the boiler are avoided by the switch-on delay and therefore a stable operating state is ensured. |
| Auto source seq ch'over (3540) | The sequence of lead boiler and following boiler is defined by the source sequence changeover and in this way, the utilisation of the boilers in a cascade is influenced. After the set time has elapsed, the boiler sequence will be changed. The boiler with next higher device address operates as lead boiler. |
| Auto source seq exclusion (3541) | <ul style="list-style-type: none">- <i>None</i>: After the set time has elapsed, the boiler sequence will be changed.- <i>First</i>: the first boiler in the addressing works as the lead boiler; for all other boilers, the boiler sequence is changed after the time set in prog.no. 3540 has elapsed.- <i>Last</i>: the last boiler in the addressing always remains as the last boiler; for all other boilers, the boiler sequence is changed after the time set in prog.no. 3540 has elapsed. |
| Leading source (3544) | The setting of the leading source is only used in combination with the fixed sequence of the source sequence (prog. no. 3540). The generator defined as the leading generator is always put into operation first, and switched off last. The other generators are switched on and off in the sequence of the device address. |
| Return setpoint min (3560) | If the return temperature drops below the return setpoint set here, the return maintenance is active. The return maintenance enables influences on the consumers or use of a return controller. |
| Temp differential min (3590) | This function prevents too high cascade return temperatures and improves the switch off behaviour of the cascade. If the temperature difference between the flow and return sensor is smaller than the minimal temperature spread set here, a source is switched off as early as possible independently of the set lead strategy. If the temperature difference is again sufficient, the set lead strategy is again switched to. |
| Temp diff on (3810) Temp diff off (3811) | 8.4.13 Solar The switching-on and switching-off point of the collector pump is set with these functions. Basis is the temperature difference between collector temperature and storage temperature. |

Fig. 24: charging control /schematically)




| | |
|-------------------|--|
| ON / OFF | Collector pump |
| T _{col} | Collector temp |
| T _{Lmin} | Charging temp min buffer / swimming pool |
| T _{Sp} | Storage temperature |

Charg temp min DHW st tank (3812)

In addition to the temperature difference, reaching a certain collector temperature is necessary for the storage charging process.

Fig. 25: Charging controller (dT)



| | |
|-------------------|-----------------------|
| T _{col} | Collector temperature |
| On/Off | Charging ON / OFF |
| S _{dON} | Temp diff ON |
| S _{dOFF} | Temp diff OFF |

Temp diff ON buffer (3813)
 Temp diff OFF buffer (3814)
 Charging temp min buffer (3815)

The switching-on and switching-off point of the collector pump is set with these functions. Basis is the temperature difference between collector temperature and storage temperature of the buffer.
 In addition to the temperature difference, reaching a certain minimum collector temperature is necessary for the buffer storage charging process.

Temp diff ON swi pool (3816)
 Temp diff OFF swi pool (3817)

For exceeding or not reaching the difference between solar collector temperature and swimming pool temperature, the solar pump is switched on and off.

Programming

Charging temp min swi pool (3818)

Temperatures that the collector must have at the least in order to begin charging a swimming pool.

Charging prio storage tank (3822)

For several combined exchangers in the system, the loading sequence for the combined storage tank can be defined by setting the loading priority.

None: each storage tank is loaded alternately for a temperature increase of 5°C, until each setpoint has reached level A, B or C (see *Tab. 6 (Page 100)*). If all setpoints are reached, the setpoint of the next level is approached.

DHW storage tank: The DHW storage tank is preferred during solar charging. It is charged in each level A, B or C (see below) with priority. Only afterward is the following consumer in the same level charged. As soon as all setpoints in one level are reached, the ones in the next level are approached, whereby the DHW storage tank again has priority.

Buffer storage tank: The buffer storage tank is preferred during solar charging. It is charged in each level A, B or C (see *Tab. 6 (Page 100)*) with priority. Only afterward is the consumer next to it in the same level charged. As soon as all setpoints in one level are reached, the ones in the next level are approached, whereby the buffer storage tank again has priority.

Tab. 6: Storage tank setpoints

| Level | DHW storage tank | Buffer storage tank |
|-------|--|---|
| A | 1610 Nominal setpoint | Buffer setpoint (drag-pointer) |
| B | 5050 DHW Charging temp max | 4750 Buffer storage tank charging temp max |
| C | DHW storage tank temp max (set by factory: 90°C) | Buffer storage temperature max (set by factory: 90°C) |

Charging time relative prio (3825)

If the preferred storage tank corresponding to the charging control not be charged, during the time set here the priority goes to the next storage tank or the swimming pool.

Waiting time relative prio (3826)

The transfer of the priority of the time set here is delayed.

Waiting time parallel op (3827)

With sufficient solar capacity, with use of solar charging pumps a parallel operation is possible. During this the next storage tank in the priority sequence can be loaded parallel to the current loaded storage tank. The storage tank switching on for parallel operation can be delayed and staged by the value set here.

Delay secondary pump (3828)

So that possible existing cold water can be first rinsed through the pump in the primary circuit, the operation of the secondary pump of the heat exchanger can be delayed.

Collector start function (3830)

If the temperature at the collector with the pump turned off is not be measured correctly (e.g. with vacuum tubes), then a periodic switching on of the pump is possible.

The temperature on a certain collector cannot be measured correctly, if the pump is switched-off. For this reason, the pump must be activated from time to time.




| | |
|---|--|
| Min run time collector pump (3831) | The collector pump is periodically switched on for the running time set here. |
| Collector start function ON (3832) Collector start function OFF (3833) | The time that the collector start function starts or stops is set here. |
| Collector start funct grad (3834) | As soon as there is a temperature increase on the collector sensor, the collector pump switches on. The higher the value here is set, the larger the temperature increase must be. |
| Collector frost protection (3840) | In order to prevent freezing of the collector, the collector pump will be activated in case of frost danger. |
| Collector overtemp prot (3850) | In case of overheating danger, charging of the storage will be continued to remove heat. When reaching the storage safety temperature charging of the storage will be interrupted. |
| Evaporation heat carrier (3860) | Pump protecting function, to prevent overheating of the collector pump in case of evaporating danger of the heat carrying medium due to high collector temperature. |
| Antifreeze (3880) | Information of the antifreeze used. |
| Antifreeze concentration (3881) | Input of antifreeze concentration for usage measurement of solar energy. |
| Pump capacity (3884) | Input of the flow of the installed pump for calculation of the brought in volume for usage measurement. |
| Pulse valency (3887) | Defines the flow per pulse for the Hx inlet. The Hx inlet must be configured to pulse count for this. |
| | 8.4.14 Solid fuel boiler |
| Locks other heat sources (4102) | If the solid fuel boilers are activated, other heat generators, e.g. oil./gas boilers, are blocked, as soon as an increase in the boiler temperature is discovered that points to the exceeding of the comparative temperature (prog. no. 4133). |
| Setpoint min (4110) | The boiler pump is only put into operation if the boiler temperature has reached the minimum setpoint set here in addition to the necessary temperature difference. |

Programming

Temp diff ON/OFF
(4130, 4131)
Comparative temp
(44133)

A sufficiently large temperature difference is necessary between the boiler temperature and the comparative temperature for start-up of the pump.



To maintain the comparative temperature, the following settings are available under prog. no. 4133:

DHW sensor B3/B31: The comparative temperature is supplied by the DHW sensor B3/B31

Buffer sensor B4/B41: The comparative temperature is supplied by the buffer storage tank sensor B3/B31

Flow temp setpoint: The flow temperature setpoint is used as comparative temperature.

Setpoint min The value set in prog.no. 4110 is used as comparative temperature.

Pump after-run time
(4140)

Setting pump after-run time.

8.4.15 Buffer storage

The hydraulic separation of heat source and buffer storage tanks achieved by the automatic heat generation lock. The heating source will only be started if the buffer storage tank cannot cover the actual heat request. The following settings are possible:

- *None:* the automatic heat generation lock is de-activated.
- *With B4:* the automatic heat generation lock will be triggered by the buffer storage tank B4
- *With B4 and B42/B41:* the automatic heat generation lock will be triggered by the buffer storage tanks B4 and B41/B42.

Auto heat gen lock SD
(4721)

The heat source will be locked if the temperature in the buffer storage tank is higher than the boiler setpoint+ auto heat generation lock SD.

Temp diff buffer/HC
(4722)

If the temperature difference between buffer storage and heating circuit temperature request is sufficiently large, the heat required by the heating circuit will be taken from the buffer storage. The heat generator is locked.

Min st tank temp heat mode (4724) If the storage tank temperature of the buffer storage tank drops below this value, the heating circuit is switched of if no generator is available.

Charging temp max (4750) The buffer storage tank is charged from solar energy up to the set charging temperature maximum.



The collector overheating protection function can put the collector pump back in operation until the maximum storage tank temperature is reached.

Recooling temp (4755) The collector overheating protection function can put the collector pump back in operation until the maximum storage tank temperature is reached.

Recooling DHW/HCs (4756) For the recooling of the buffer storage tank to the recooling temperature there are two functions available. The energy can be discharged via a heat draw of the room heating or the DHW storage tank. This can be separately set for each heating circuit.

Recooling collector (4757) Recooling with a too high buffer storage tank temperature by transmission of energy to the environment via the collector area.
 - *Off*: recooling is switched off.
 - *Summer*: the recooling is only active in the summer.
 - *Always*: recooling is always active.

With solar integration (4783) Setting of whether the buffer storage tank can be charged by solar energy.

Return diversion (4790 - 4795) At the appropriate temperature difference between the return sensor B73 and the selectable comparative temperature the return is re-routed to the lower buffer storage tank part. The function can either be used as return temperature increase or as return temperature decrease. The way this works is defined in prog. no. 4796.

Using the definition of the temperature differences in prog. no. 4790 and 4791 the switch on and switch off point of the return redirection is established.

In prog. no. 4795 the buffer storage tank sensor is selected that delivers the value for the comparison with the return temperature, to switch on the return redirection with the aid of the set temperature differences.



Note: To activate the return redirection the relay outlet QX1, QX2, QX3 (prog. no. 5890-5892) for the buffer deflector valve and the sensor inlet BX1, BX2, BX3 (prog. no. 5930-5932) for the rail return sensor B73 must also be configured.

Optg action return diversion (4796) The function can either be used as return temperature increase or as return temperature decrease.

Temp decrease: If the return temperature of the consumer is higher than the temperature on the selected sensor (prog. no. 4795), the lower part of the storage tank can be preheated with the return. The return temperature drops even lower with this, which, for example with a condensing boiler leads to a higher efficiency.

Temp increase: If the return temperature of the consumer is lower than the temperature on the selected sensor (prog. no. 4795), the return can be preheated by redirecting over the lower part of the storage tank. In this way, for example, a return reheating can be implemented.

Programming

Full charging
(4810)

The function *full charging* makes it possible that the released heat source is first switched off, despite automatic heat source block if the buffer storage tank is fully charged. During active function the heat source parameterized for the fully charging function is first switched off, if the fully charging setpoint is reached or the boiler must be switched off because of burner control.

Off: the Full charging function is switched off.

Heating Mode: The full charging is active if the automatic heat source block blocks the heat source during valid heat request based on the buffer temperature. If the buffer storage tank reaches the requested temperature on the sensor parameterized for the full charging function, the function is ended.

Always: The full charging is active if the automatic heat source block blocks the heat source during valid heat request based on the buffer temperature or the heat request is invalid. If the buffer storage tank reaches the requested temperature on the sensor parameterized for the full charging function, the function is ended.

Full charging temp min
(4811)

The buffer storage tank is charged minimally to the set value.

Full charging sensor
(4813)


With B4 For the full charging function the buffer storage tank sensor B4 is considered.

With B42/B41: For the full charging function the buffer storage tank sensor B42, if not available buffer storage tank sensor B41, is considered.

8.4.16 DHW-storage

Charge push forward time
(5011)

The DHW release is pushed forward by the set charge push forward time compared to each heating circuit allocation and kept during the heating circuit allocation.



Flow setpoint boost
(5020)

The boiler temperature setpoint for charging the DHW storage tank consists of the DHW temperature setpoint and the flow setpoint boost.

Transfer boost
(5021)

Through the transfer, energy can be moved from the buffer storage tank into the DHW storage tank. For this the current buffer storage tank temperature must be higher than the current temperature in the DHW storage tank. This temperature difference is set here.

Type of charging
(5022)

Charging a layer storage (if exists):

- *Recharging*: The cylinder is only reheated at every DHW demand.
- *Full charging*: The cylinder is fully heated at every DHW demand.
- *Full charging legio*: The cylinder is fully heated if the pasteurisation function is enabled; otherwise it is only reheated.
- *Full charg 1st time day*: During the first charging of the day, the cylinder is fully heated; after this, it is reheated.
- *Full charg 1st time legio*: The cylinder is fully heated during the first charging of the day and if the pasteurisation function is enabled; otherwise, it is reheated

Explanations:

- Full charging: The stratification cylinder is fully heated. The heat demand is triggered by the top cylinder sensor TWF (B3), and ended by sensors TWF and TLF (B36) or TWF2 (B31). If only one B3 is installed, reheating takes place automatically.
- Recharging: The stratification cylinder is reheated; i.e. only the area up to the cylinder sensor TWF (B3) is heated. The heat demand is triggered and ended by the top cylinder sensor TWF (B3).

Switching diff
(5024)

If the DHW temperature is lower than the current setpoint minus the switching difference set here, the DHW charging is started. The DHW charging is ended if the temperature of the current setpoint is reached.



At the first DHW release of the day, a forced charging is performed. The DHW charging is also started if the DHW temperature is within the switching difference - as long as it is not less than 1 K under the setpoint.

Charging time limitation
(5030)

During the DHW charging, the room heater - depending on the selected charging priority (prog.no. 1630) and the hydraulic switch – has too little or no power. Often it is therefore practical to restrict the time of DHW charging.

Discharging protection
(5040)

The function ensures that the DHW pump (Q3) first switches on if the temperature in the heat generator is sufficiently high.

Application with sensor

The charging pump is first switched on if the heat source temperature is above the DHW temperature plus the half of the charging increase. If the boiler temperature drops again below the DHW temperature plus 1/8 of the charging excess during the charging, the charging pump is again switched off. If two DHW sensors for the DHW charging are parameterized, the lower temperature is considered for the discharge safety function (normally the DHW sensor B31).

Application with thermostat

The charging pump is first switched on if the boiler temperature is above the DHW nominal setpoint. If the boiler temperature drops below the DHW nominal setpoint minus the DHW switching difference, charging pump is again switched off.

Off: the function is switched off.

Always: the function always affects.

Automatically: the function only takes effect if the heat generator cannot deliver heat or is not available (malfunction, heat source block).


Charging temp max
(5050)

With this setting, the maximum charging temperature for the connected storage of the solar system will be limited. If the DHW-charging value is exceeded, the collector pump switches off.



The collector pump can be re-activated by the collector overheating protecting function see prog.no. 3850) until the storage safety temperature has been reached.

Programming

| | |
|---|---|
| Recooling temp (5055) | Setting the temperature for recooling the DHW-storage. |
| Recooling collector (5057) | Recooling of the overheated collector through giving off of the energie to the surrounding of the collector. |
| El imm heater optg mode (5060) | <ul style="list-style-type: none">- <i>Replacement</i>: the DHW is only heated by electrical immersion heater if the boiler signals a malfunction or a boiler lock exists.- <i>Summer</i>: the DHW is heated by an electrical immersion heater if all connecting heating circuits have switched to summer mode. As soon at least one heating circuit is switched to heating mode, the DHW preparation is again taken over by the boiler. The conditions listed for the electrical immersion heater under Replacement operating mode is also activated in the Summer operating mode.- <i>Always</i>: the DHW preparation is only performed by the electrical immersion heater. |
| El immersion heater release (5061) | <ul style="list-style-type: none">- <i>24h/day</i>: Permanent release of the electric insert- <i>DHW release</i>: Release of the electric insert depending on DHW-release (see prog.no. 1620).- <i>Time program 4/DHW</i>: Release of the electric insert via the time switching programme 4 of the local controller. |
| El inmmersion heater control (5062) | <ul style="list-style-type: none">- <i>External thermostat</i>: The storage temperature will be achieved with an external thermostat <u>without</u> setpoint control of the controller.- <i>DHW sensor</i>: The storage temperature will be achieved with an external thermostat <u>with</u> setpoint control of the controller. |
| Automatic-Push (5070) | <p>The DHW-Push can activated by hand or automatically. It causes a one-time DHW charging to the nominal setpoint.</p> <ul style="list-style-type: none">- <i>Off</i>: The DHW-Push can only activated by hand.- <i>On</i>: If the DHW temperature drops by more than two switching differences (prog. no. 5024) below the reduced setpoint (prog. no. 1612), one -time it will be recharged to the DHW nominal setpoint (prog.no.1610). <p>The automatic push only works for set DHW operating mode.</p> |
| |  |
| Excess heat draw (5085) | An excess heat draw can be actuated through the following functions: storage tank temperature maximum, automatic push, charging priority time push, excess heat draw, active inputs H1, H2, H3 or EX2, storage tank recooling, solid boiler excess heat draw. If an excess temperature discharge is activated, the excess energy can be discharged through a heat draw of the room heating. This can be separately set for each heating circuit. |
| With buffer storage tank (5090) | <ul style="list-style-type: none">- <i>No</i>: The domestic hot water storage tank will be directly charged from the boiler.- <i>Yes</i>: The domestic hot water storage tank will be charged from the buffer storage tank. |
| With primary control/system pump (5092) | <ul style="list-style-type: none">- <i>No</i>: the domestic hot water storage tank will be charged without primary controller/system pump.- <i>Yes</i>: the domestic hot water storage tank will be charged from the primary controller on/with the system pump. |

Programming

| | |
|-------------------------------------|--|
| With solar integration (5093) | This function sets whether the DHW storage tank should be filled. |
| Pump speed limitations (5101, 5102) | Setting of the minimum and maximum speed of the storage tank charging pump in percent. |
| Speed Xp (5103) | The P-band Xp defines the amplification of the controller. A smaller Xp value leads to a higher actuation of the charging pump with equal control difference. |
| Speed Tn (5104) | The reset time Tn determines the reaction speed of the controller when compensating for remaining controller differences. A shorter reset time Tn leads to faster compensating. |
| Speed Tv (5105) | The preholding time Tv determines how long a spontaneous change of the control difference continues to have an effect. A short time only influences the control variable only for a short time. |
| Transfer strategy (5130) | The transfer is always allowed or to the set DHW release times. |
| Interm circ boost recharging (5139) | Setpoint boost for charging setpoint on charging sensor B36 with recharging. |
| Intermediate circuit boost (5140) | Setpoint boost for charging setpoint on charging sensor B36 with full charging. |
| Excess interm circ temp max (5141) | With this parameter the end criterion of a full charging during control is specified on the charging sensor B36. If the contents of the layer storage is charge to the bottom, the temperature increases on the charging sensor. |
| Flow setp compensation delay (5142) | The filter time for the setpoint lead is set here. |
| Flow setp compensation Xp (5143) | The P-band Xp defines the amplification of the controller. A smaller Xp value leads to higher actuation of the charging pump with equal control difference. |
| Flow setp compensation Tn (5144) | The reset time Tn determines the reaction speed of the controller when compensating for remaining controller differences. A shorter reset time Tn leads to faster compensating. |
| Flow setp compensation Tv (5145) | The preholding time Tv determines how long a spontaneous change of the control difference continues to have an effect. A short time only influences the control variable only for a short time. |
| Full charging with B36 (5146) | Here it can be set whether the end of the full charging is detected via the temperature on the charging sensor B36. <ul style="list-style-type: none">- No: the end of the full charging is detected via the temperature on the upper and lower storage sensor B3 and B31.- Yes: the end of the full charging is detected via the temperature on the upper storage sensor B3. |

Programming

Min start temp diff Q33
(5148)

This parameter determines switch on delay of the intermediate circuit pump depending on the boiler temperature. The intermediate circuit pump is switched on as soon as the boiler temperature has reached the boiler setpoint plus the value set here. The setting -5 °C has the effect that the intermediate circuit pump will be switched on as soon as the boiler temperature has reached the boiler setpoint up to 5 °C.

Excess interm circ temp del
(5151)

Control of the burner output on the charging temperature is activated if the time set here has elapsed since switching on the intermediate circuit pump.

Heating circuit 1,2
(5710, 5715)

8.4.17 Configuration

The heating circuits can be switched on or off by this setting. The parameters for the heating circuits are hidden in the switched off state.



This adjustment directly affects the heating circuits and has no influence on the operating unit!

DHW sensor
(5730)

- *None*: No DHW sensor available.
- *Sensor B3*: It exists a DHW storage tank sensor. The controller calculates the switching points with the corresponding switching difference from the DHW setpoint and the measured DHW storage tank temperature.
- *Thermostat*: Control of domestic hot water temperature as a function of the switching status of a thermostat connected to DHW sensor B3.



Note: When using a DHW thermostat no reduced mode is possible. This means if reduced mode is active, the DHW preparation is blocked with the thermostat.



Caution! No frost protection for DHW !

The domestic water frost protection cannot be guaranteed.

- *Sensor B38*: An instantaneous heater discharge sensor is present. The controller calculates the switching points with corresponding switching difference from the instantaneous heater setpoint and the measured DHW discharge temperature.

DHW control element Q3
(5731)

- *None*: DHW-charge de-activated via Q3.
- *Charge pump*: DHW-charging via the connection of a charge pump to Q3/Y3.
- *Deflecting valve*: DHW-charging via connection of a deflecting valve at Q3/Y3.

Basic pos DHW div valve
(5734)

The base position of the diverting valve is the position in which the diverting valve (DV) is in if no request is active.

- *Last request*: The diverting valve (DV) remains after the last request has ended in this last position.
- *Heating circuit*: The diverting valve (DV) goes into the heating circuit position after the last request has ended.
- *DHW*: The diverting valve (DV) goes into the DHW position after the last request has ended.

Separate circuit
(5736)



The DHW separate circuit can only be used in a boiler cascade.

- *Off*: The DHW separate circuit is switched off. Each available boiler can feed the DHW storage tank.
- *On*: The DHW separate circuit is switched on. The DHW charging is only done from the boiler defined for this.

For a DHW separate circuit, under prog. no. 5731, the DHW control element Q3 is set on "diverting valve".

Optg action DHW div valve
(5737)

Using this parameter the diverting valve position is set, which applies during active output.

- *Position on DHW*: during active output the diverting valve is in the DHW position.
- *Position on heating circuit*: during active output the diverting valve is in the heating circuit position.

Ctrl boiler pump/DHW valve
(5774)

With this parameter it can be defined for special hydraulic systems that the boiler pump Q1 and the diverting valve Q3 only are responsible for DHW and heating circuit 1, however not for heating circuits 2 and 3 or for the external consumer circuit.

- *All requests*: the diverting valve is connected hydraulically for all requests and switches between DHW mode and the remaining requests. The boiler pump runs for all requests.
- *Request HC1/DHW only*: The diverting valve is connected hydraulically only for heating circuit 1 and DHW and switches between DHW mode and heat circuit 1 mode. All other requests are not connected hydraulically via the diverting valve (DV) and the boiler pump, but rather directly connected to the boiler.

Solar controlling element
(5840)

The solar heating system can also be operated with charging pumps instead of with a collector pump and diverting valves for the storage tank connection.

- *Charge pump*: When using with the charging pump all exchangers can be flowed through simultaneously. The parallel or alternative mode is possible.
- *Deflecting valve*: When using with a diverting valve always only one exchanger can be flowed through. Only the alternative mode is possible.

External solar exchanger
(5841)

For solar schemes with two storage connections it must be set whether the external heat exchanger is present and is used *together* for DHW and buffer storage or *only for one of the two*.

Combined storage
(5870)

Combined storage-specific functions will be activated with this setting. For instance, the buffer storage electric heater insert can be used for heating as well as for DHW.

- *No*: No combined storage exists.
- *Yes*: A combined storage exists.

Relay outputs QX1 - QX3 (5890 bis 5892)

Relay outputs QX1/QX2/QX3
(5890 bis 5892)

- *None*: Relay outputs deactivated.
- *Circulation pump Q4*: The connected pump serves as domestic hot water circulation pump (see prog. no. 1660).

Programming

- *El imm heater DHW K6*: With the connected electrical immersion heater, the DHW can be charged according to the operating side DHW storage operating lines electrical immersion heater.

Note: The Operating mode is set under programme number 5060.



- *Collector pump Q5*: Connection of a circulating pump in case of solar collector use.
- *Cons circuit pump VK1/2*: Connection of a pump at the input Q15/18 for an additional consumer, which is requested via an Hx-input.
- *Boiler pump Q1*: the connected pump is used for recirculation of the boiler water.
- *Alarm output K10*: An occurring fault will be signalled with the alarm relay. The contact is closed with the delay time selected under prog. no. 6612. If no fault message exists, the contact opens without delay.

Note: The alarm relay can be reset without removing the fault (see prog. no. 6710). The alarm relay can also be closed temporarily by a message which, for example, leads to restart.



- *Heating circuit pump HC3 / Q20*: Activating the pump heating circuit HC3.
- *System pump Q14*: Connection of a system pump.
- *Heat gen shut-off valve Y4*: Connection of a changeover valve for hydraulic decoupling the heat generator from the rest of the heating system.
- *Solid fuel boiler pump Q10*: Connection of a circulating pump for the boiler circuit for connection to a solid fuel boiler.
- *Time program 5 K13*: The relay will be controlled by the time program 5 according to the settings.
- *Buffer return valve Y15*: This valve must be configured for return temperature increase/decrease or the buffer storage tank partial charging.
- *Solar pump ext exch K9*: here, the solar pump external exchanger K9 must have been set for the external heat exchange.
- *Solar ctrl elem buffer K8*: if several exchangers are connected, the buffer storage must be set at the respective relay output and the type of solar regulating unit must be defined under prog.no. 5840.
- *Solar ctrl elem buffer K8*: if several exchangers are connected, the swimming pool must be set at the respective relay output and the type of the solar regulating unit must be defined in prog.no. 5840.
- *Swimming pool pump Q19*: Connection of a swimming pool pump at the input Q19 .
- *Cascade pump Q25*: Boiler pump in common for all boilers in a cascade.
- *St tank transfer pump Q11*: The drinking water storage can be charged from the buffer storage, if is sufficiently hot. This transfer is carried out with the transfer pump Q11.
- *DHW mixing pump Q35*: Separate pump for storage circulation during active legionella function.
- *DHW interm circ pump Q33*: Charge pump for domestic hot water storage with external heat exchanger.
- *Heat request K27*: As soon as a heat demand exists in the system, the output K27 will be activated.
- *Heating circuit pump HC1 /HC2*: The relay is used for actuating the heating circuit pump Q2/Q6.
- *DHW controlling element Q3*: Depending on the hydraulics a connected DHW charging pump or diverting valve.
- *Status output K35*: The status output will be operated when a command exists from the controller to the firing automation. If there is a disturbance, which prevents the firing automation to operate, the status output will be switched off.

- *Status information K36*: The output is set, when the burner operates.
- *Flue gas damper K37*: This function activates the flue gas damper control. If the flue gas damper control is activated the burner will only start operating, when the flue gas damper is open.
- *Fan shutdown K38*: This output serves to stop the fan. The output is activated, when the fan is needed; otherwise it is not activated. The fan should be switched off as often as possible, to minimize the total energy consumption of the system.

Sensor inputs BX1/BX2/BX3 (5930 bis 5932)

Functions in addition to the basic functions will be possible by configuring the sensor inputs.

- *None*: Sensor inputs deactivated.
- *DHW sensor B31*: second DHW sensor, which is used for through loading of the legionella function.
- *Collector sensor B6*: first solar collector sensor in a collector field.
- *DHW circulation sensor B39*: Sensor for return line of DHW circulation.
- *Buffer st tank sensor B4*: lower buffer storage tank sensor.
- *Buffer st tank sensor B41*: centre buffer sensor.
- *Common flow sensor B10*: common flow sensor for boiler cascades.
- *Solid fuel boiler sensor B22*: Sensor for the acquisition of the temperature of a solid fuel boiler.
- *DHW charging sensor B36*: DHW sensor for DHW charging system.
- *Buffer st tank sensor*: upper buffer storage tank sensor.
- *Common return sensor B73*: Return sensor for the function return diversion.
- *Cascade return sensor B70*: common return sensor for boiler cascades.
- *Swimming pool sensor B13*: Sensor for measurement of swimming pool temp.
- *Solar flow sensor B63*: this sensor is required for the solar usage measurement.
- *Solar return sensor B64*: this sensor is required for the solar usage measurement.

Function inputs H1/H4/H5 (5950, 5970, 5977)

- *None*: No function.
- *Optg mode change HCs+DHW*: Changeover of the operating modes of the heating circuits to reduced operation or protecting operation (program numbers 900, 1200, 1500) and locking of domestic hot water charging in case of closed contact at H1/H4/H5/H2.
- *Optg mode changeover HC1 to HC3*: Changeover of operating modes of the heating circuits to protective operation or reduced operation.



Locking of domestic hot water charging is only possible under the setting **Optg mode change HCs+DHW**.

- *Heat generation lock*: locking of the boiler in case of closed contact at H1/H4/H5/H2.
- *Error/alarm message*: Closing the inputs H1/H2 gives a control unit-internal fault message, which will also be signalled via a relay output, programmed as an alarm output or in the remote management system.
- *Consumer request VK1/VK2*: The set flow temperature setpoint is activated via the connecting terminals (e.g. a ventilation heater function for door curtain units).



Note: The setpoint is set under programme number 1859/1909.

Programming

- *Excess heat discharge*: an active excess heat discharge enables, for example, an external source to force the consumer (heating circuit, DHW storage tank, pump Hx) to take up the excess heat. For each consumer it can be set by the parameter excess temperature discharge whether the forced signal is paid attention to and therefore should take part in the heat discharge or not.
- *Release swi pool solar*: This function enables the solar swimming pool heater to be released externally (e.g. via a manual switch or the solar charging priority to be specified as compared to the storage).
- *Operating level DHW/HC's*: The operating level can be set via the contact instead of via the internal time switching program (external time switching program)
- *Room thermostat HC's*: With the input a room thermostat request can be generated for the set heating circuit.



Note: The quick decrease should be switched off for the corresponding heating circuits.

- *DHW thermostat*: Connection of the DHW thermostat.
- *Pulse count*: By querying the input the low frequency pulse, e.g. for flow measurement is recorded.
- *Feedback flue gas damper*: Feedback via input H1 in case of activated flue gas damper control.
- *Start prevention*: With this input a burner start can be prevented.
- *Consumer request VKx 10V*: The application nodes external load x receives a voltage signal (DC 0-10 V) as heat request. The linear curve is defined via two fix points (voltage value 1/function value 1 and voltage value 2/function value 2 (only applies to H1).
- *Preselected output*: The source receives a voltage signal (DC 0 - 10 V) as output request. The linear curve is defined via two fix points (voltage value 1/function value 1 and voltage value 2 / function value 2 (only applies to H1).
- *Flow measurement*: Here a flow sensor can be connected which indicates the flow volume via a frequency (only applies to H4).

Contact type H1/H4/H5/H2
(5951, 5971, 5978)

With this function, the contacts can be set as resting contact (contact closed, must be opened for activating the function) or as working contact (contact opened, must be closed for activating the function).


Voltage value 1/2 H1
(5953, 5955)
Function value 1/2 H1
(5954, 5956)

The linear sensor curve is defined over two fixed points. The setting is made with two parameter pairs for *Function value* and *Voltage value* (F1 / U1 and F2 / U2). The function value is specified to a factor of 10, i.e. if you require 100 °C, you should select "1000".

Frequency values 1/2 H4
Function values 1/2 H4
(5973-5976)

The linear sensor curve is defined over two fixed points. The setting is done with two parameter pairs for *function value* and *frequency value* (F1 / U1 and F2 / U2).

Fig. 28: Example for two different sensor curves



Function extension module
1/2/3
(6020 - 6022)

Specification of functions that are controlled by the extension modules 1 2 and 3.
Multifunctional: For possible functions that can be assigned to the multifunctional inputs/outputs, see prog. no. 6030 to 6055.

Heating circuit 1: For this use, the respective settings can be adjusted in the menu point Heating circuit 1.

Heating circuit 2: For this use, the respective settings can be adjusted in the menu point Heating circuit 2.

Heating circuit 3: For this use, the respective settings can be adjusted in the menu point Heating circuit 3.

Solar DHW: For this use, the respective settings can be adjusted in the menu point Solar.

Primary controller/feed pump: For this use, the respective settings can be adjusted in the menu point Primary controller/feed pump.

Relay output QX21-QX23
(6030 - 6038)

Relay outputs for the moduls 1, 2 and 3.
Explanations see prog.-no. 5890.

Sensor input BX21/BX22
(6040 - 6045)

Sensor input for the moduls 1, 2 and 3.
Functions in addition to the basic functions will be possible by configuring the sensor inputs BX21 and BX22.
Explanations see prog.-no. 5930).

Function input H2 EM 1/2/3
(6046, 6054, 6062)

Explanations see prog.-no. 5950.

Contact type H2 EM 1/2/3
(6047, 6055, 6063)


Explanations see prog.-no. 5951.

Voltage values 1/2 H2 module 1-3
(6049, 6051, 6057, 6059, 6065, 6067)
Function values 1/2 H2 module 1-3
(6050, 6052, 6058, 6060, 6066, 6068)

The linear sensor curve is defined over two fixed points. The setting is made with two parameter pairs for *Function value* and *Voltage value* (F1 / U1 and F2 / U2).

Programming

Fig. 29: Example for heat demand 10 V and cooling demand 10 V



PWM-output P1
(6085)

With this parameter the function for the modulating pumps is specified.

- *None*: No output P1 exists.
- *Boiler pump Q1*: the connected pump is used for recirculation of the boiler water.
- *DHW pump Q3*: Control element for drinking water storage.
- *DHW interm circ pump Q33*: Charge pump for domestic hot water storage with external heat exchanger.
- *Heat circuit pump HC1 Q2*: the heat circuit pump HC1 will be activated.
- *Heating circuit pump HC2 Q6*: the heat circuit pump HC2 will be activated.
- *Heating circuit pump HC3 Q20*: the heat circuit pump HC3 will be activated.
- *Collector pump Q5*: a circulation pump for the collector circuit is required for connection of a solar collector.
- *Solar pump ext exch K9*: if several exchangers are connected, the buffer storage must be set at the respective relay output. and the type of the solar regulating unit must be defined in prog.no. 5840.
- *Solar pump swi pool K18*: if several exchangers are connected, the the swimming pool must be set at the respective relay output. and the type of the solar regulating unit must be defined in prog.no. 5840.

Sensor type collector
(6097)

Selection of used sensor types for measurement of the collector temperature.

Readjustm coll sensor 1
(6098)

Setting a correction value for collector sensor 1.

Readjustm outside sensor
(6100)

Setting a correction value for outside sensor.

Time constant building
(6110)

The value set here influences the reaction speed of the nominal flow value in case of fluctuating outside temperatures as a function of the building design.

possible values (see also *Quick setback* prog.-no. 780, ...):

- 40 for buildings with thick walls or outer insulation.
- 20 For buildings of normal building design.
- 10 For buildings of light building design.

Programming

- Central setp compensation (6117) The central setpoint lead monitors the heat generator setpoint to the required central flow temperature. With the setting the maximum corrector is restricted, even if a large adaptation is required.
- Frost protection plant (6120) The heating circuit pump will be activated by the outside temperature without heat request If the outside temperature reaches the lower setpoint of -4°C, the heating circuit pump will be activated. If the outside temperature is between -5°C and +1.5°C, the pump will be activated every 6 hours for 10 minutes. When reaching the upper limit of 1.5°C, the pump will be switched off.
- Saving sensors (6200) Sensor statuses can be stored under programme number 6200. This happens automatically; however, after changing the plant (removal of a sensor) the state at the sensor terminals must be stored new.
- Control numbers generator 1/storage/heating circuit (6212, 6213, 6215, 6217) The basic device generates a control number for identification of the plant scheme, which is composed of the numbers listed in *Tab. 7 (Page 115)*

Tab. 7: Check no. heat source 1 (prog.-no. 6212)

| Solar | | | | | |
|--|---|--|---|---|--|
| A collector field with sensor B6 and collector pump Q5 | Tank charging pump for buffer storage tank K8 | Solar diverting valve for buffer storage tank K8 | Solar charging pump for swimming pool K18 | Solar diverting valve for swimming pool K18 | External solar exchanger, Solar pump K9 DHW=DHW storage tank B=Buffer storage tank |
| 0 | No solar | | | | |
| 1 | | | | | * |
| 3 | | | | | DHW/B |
| 5 | X | | | | |
| 6 | | X | | | |
| 8 | X | | | | DHW+B |
| 9 | | X | | | DHW/B |
| 10 | X | | | | DHW |
| 11 | | X | | | DHW |
| 12 | X | | | | B |
| 13 | | X | | | B |
| 14 | | | X | | |
| 15 | | | | X | |
| 17 | | | X | | DHW/B |
| 18 | | | | X | DHW/B |

Programming

| Solar | | | | | |
|-------|---|---|---|---|-------|
| 19 | X | | X | | |
| 20 | | X | | X | |
| 22 | X | | | | DHW+B |
| 23 | | X | | X | DHW/B |
| 24 | X | | X | | DHW |
| 25 | | X | | X | DHW |
| 26 | X | | X | | B |
| 27 | | X | | X | B |

Tab. 8: Check no. storage tank (prog.-no. 6215)

| Buffer storage | | DHW storage tank | |
|----------------|--|------------------|--|
| 0 | No buffer | 00 | No DHW storage tank |
| 1 | Buffer storage | 01 | Electric immersion heater |
| 2 | Buffer, solar connection | 02 | Solar connection |
| 4 | Buffer, heat generation shutoff valve | 04 | Charging pump |
| 5 | Buffer, solar connection | 05 | Charging pump, solar connection |
| | Heat gen shutoff valve | 13 | Diverting valve |
| | | 14 | Diverting valve, solar connection |
| | | 16 | Primary control, without exchanger |
| | | 17 | Primary control, 1 exchanger |
| | | 19 | Intermediate circuit, without exchanger |
| | | 20 | Intermediate circuit, 1 exchanger |
| | | 22 | Charging pump/intermediate circuit, without exchanger |
| | | 23 | Charging pump, intermediate circuit, 1 exchanger |
| | | 25 | Diverting valve, intermediate circuit, without exchanger |
| | | 26 | Diverting valve, intermediate circuit, 1 exchanger |
| | | 28 | Primary control, intermediate circuit, without exchanger |
| 29 | Primary control, intermediate circuit, 1 exchanger | | |

Tab. 9: Check no. heating circuit (prog.-no. 6217)

| Heating circuit 3 | | Heating circuit 2 | | Heating circuit 1 | |
|-------------------|------------------------------------|-------------------|------------------------------------|-------------------|------------------------------------|
| 0 | No heating circuit | 00 | No heating circuit | 00 | No heating circuit |
| 1 | Circulation via boiler pump | 01 | Circulation via boiler pump | 01 | Circulation via boiler pump |
| 2 | Heating circuit pump | 02 | Heating circuit pump | 02 | Heating circuit pump |
| 3 | Heating circuit pump, mixing valve | 03 | Heating circuit pump, mixing valve | 03 | Heating circuit pump, mixing valve |

Software version
(6220)

Display of the actual software version.

8.4.18 LPB-system

| | |
|---|---|
| Device address/Segment address (6600/6601) | The two-part LPB address of the controller consists of the 2-digit segment number and the 2-digit device number. |
| Bus power supply function (6604) | <ul style="list-style-type: none"> - <i>Off</i>: the power supply of the bus system does not take place through the controller. - <i>Automatically</i>: the power supply of the bus system is switched on and off by the controller depending on the power requirement of the bus system.. |
| Bus power supply state (6605) | <ul style="list-style-type: none"> - <i>Off</i>: the power supply of the bus system through the controller is currently inactive. - <i>On</i>: the power supply of the bus system through the controller is currently active. |
| Display systemmessages (6610) | This setting allows system messages which are transmitted via LPB to be suppressed on connected operating elements. |
| Alarm delay (6612) | Settling out of the alarm on the BM module can be delayed in the base device by an adjustable time. This allows the prevention of unnecessary messages to a service location from briefly occurring malfunctions (e.g. temperature monitor queried, communication errors). However, it must be realised that briefly occurring malfunctions which continue and quickly occur again, are also filtered out with this. |
| Display systemmessages (6610) | <p>If the setting Central is activated under progr. no. 6221 and 6223, the action for this setting can be set. The following settings are possible:</p> <ul style="list-style-type: none"> - <i>Segment</i>: the changeover is done for all controllers in the same segment. - <i>System</i>: the changeover is done for all controllers in the entire system (that is in all segments). The controller must be located in segment 0! |
| Summer changeover (6621) | <ul style="list-style-type: none"> - <i>Locally</i>: the local heating circuit is switched on and off depending on prog. no. 730, 1030 or 1330. - <i>Centrally</i>: depending on the settings made in prog no. 6620 either the heating circuit in the segment or in the entire system is switched on and off. |
| Optg mode changeover (6623) | <ul style="list-style-type: none"> - <i>Locally</i>: the local heating circuit is switched on and off. - <i>Centrally</i>: depending on the settings made in prog no. 6620 either the heating circuit in the segment or in the entire system is switched on and off. |
| Manual source lock (6624) | <ul style="list-style-type: none"> - <i>Locally</i>: The local heating source is locked. - <i>Segment</i>: All heating sources of the cascade are locked. |

Programming

DHW assignment
(6625)

This setting is only necessary if the control of the DHW charging is done by a heating circuit time program (see prog. no. 1620 and 5061)

- *Local HCs*: the DHW charging is done only for the local heating circuit.
- *All HCs in segment*: the DHW charging is done for all heating circuits in the segment.
- *All HCs in system*: the DHW charging is done for all heating circuits in the system.



For all settings the controller is also considered for the DHW charging, which are in vacation status.

Clock mode
(6640)

With this setting the action of the system time is established on the time setting of the controller. The following settings are possible:

- *Autonomously*: the time of day can be modified at the control. The time of the controller is not adapted to the system time.
- *Slave without remote setting*: the time of day can not be modified at the control. The time of the controller is continually, automatically adapted to the system time.
- *Slave with remote setting*: The time of day can be modified at the control. Simultaneously the system time is adapted, since the change is done by the master. The time of the controller is then continually adapted to the system time.
- *Master*: The time of day can be modified at the control. The time of the controller is the default for the system. The system time is adapted.

Outside temp source
(6650)

In the LPB system only one single outside temperature sensor is necessary. This delivers the signal via the LPB to the controller without sensor. In the display the segment number appears as first number and the device number is the second number.

8.4.19 Fault

Fault message
(6700)

A current existing error in the system is displayed here in the form of an error code.

SW diagnostic code
(6705)

In case of a fault, the display fault is on permanently. In addition, the diagnosis code is displayed on the display.

Fault phase
(6706)

Phase, in which the fault has occurred, which led to the failure.

Reset alarm relay
(6710)

An output relay QX, programmed as an alarm relay can be reset via this setting.


Temperature-Alarms
(6740-6745)

Setting the time, after which a error message will be triggered in case of persisting deviation from temperature nominal and actual values.

Error history/error codes
(6800 - 6995)

The last 20 error messages with error code and time of error occurrence will be stored in the error storage.

8.4.20 Service / special operation

| | |
|--|--|
| Burner hours interval (7040) | Setting of the interval for maintenance of the burner. |
| Burn hrs since maintenance (7041) | Burner hours since the last maintenance. <i>Note:</i> The burner hours are only counted, when the maintenance message has been activated. |
| Burner start interval (7042) | Setting of the interval for burner starts for maintenance. |
| Burn starts since maint (7043) | Burner starts since the last maintenance. <i>Note:</i> The burner starts are only counted, when the maintenance message has been activated. |
| Maintenance interval (7044) | Setting of maintenance interval in months. |
| Time since maintenance (7045) | Passed time since the last maintenance interval. <i>Note:</i> The time is only counted, when the maintenance message has been activated. |
| Fan speed ionization current (7050) | Speed limit from which the ionisation current service alarm should be set (prog. no. 7051), if the ionisation current monitoring and therefore a speed increase based on too low ionisation current active is. |
| Message ionization current (7051) | Function for display and reset of the burner ionisation current service alarm. The service alarm can only be reset if the reason for service is taken care of. |
| Chimney-sweep function (7130) | The chimney sweep function is switched on or off under this prog no. |
| |  <p>Note: The function is switched off by the setting "Off" or automatically if the maximum boiler temperature is reached. It can also be directly activated via the chimney sweep button.</p> |
| Manual control (7140) | Activation of manual control. If the manual control function is activated the boiler will be controlled to the Setpoint manual control. All pumps will be activated. Additional request will be ignored! |
| Controller stop function (7143) | If the controller stop function is activated, the burner output set in the setpoint controller stop is immediately requested by the device. |
| Controller stop setpoint (7145) | With activated controller stop function the output set here is requested by the device. |
| Telephone customer service (7170) | Here the desired telephone number of customer service can be entered. |
| PStick storage pos (7250) | Via the parameter <i>PStick Storage Pos</i> the data set (data set number on the stick) can be selected which should be written or read. |

Programming

PStick command
(7252)

- *No operation*: this is the base condition. As long as no operation is active on the stick, this command is displayed.
- *Reading from stick*: starts reading the data from the stick. This operation is only possible with READ sticks. The data of the set data set is copied in the LMS control. Beforehand is checked whether the data set may be brought in. If the data set is incompatible, it may not be brought in. The display resets to no operation, displays an error message. The text Read from stick remains until the operation is completed or an error occurs. As soon as the data transmission begins, the LMS control goes in a parameterization position. As soon as the parameter is transferred, the LMS control must be unlocked after ending the transmission. Error 183 parameterization is displayed.
- *Writing on stick*: Starts writing the data from the LMS control to the stick. This operation is only possible with WRITE sticks. The data is written in the previously set data set. Before writing of the data begins, it is checked whether the data fits on the stick and the respective customer number is correct. The text Writing to stick remains until the operation is completed or an error occurs.

PStick progress
(7253)

The read or write progress is displayed as a percentage. If no operation is active or an error shows up, 0% is displayed.

8.4.21 Input/output test

Input/output tests
(7700 - 7872)

Tests for checking the connected components for function.

8.4.22 State

State
(8000 bis 8011)

With this function the state of the selected system can be requested.

Programming

The following messages are possible under **Heating circuit**:

| End user (E) | Commissioning, Technician (menu <i>state</i>) |
|------------------------------|---|
| Monitor has tripped | Monitor has tripped |
| Manual control active | Manual control active |
| Floor curing function active | Floor curing function active |
| Heating mode restricted | Overtemp prot active Restricted, boiler protection Restricted, DHW priority Restricted, buffer |
| Forced draw | Forced draw DHW Forced draw source Overrun active |
| Comfort heating mode | Opt start ctrl+boost heating Optimum start control Boost heating Comfort heating mode |
| Reduced heating mode | Optimum stop control Reduced heating mode |
| Frost protection active | Frost prot room active Frost protection flow active Frost prot plant active |
| Summer operation | Summer operation |
| Off | 24-hour Eco active Setback reduced Setback frost protection Room temp limitation Off |

Programming

The following messages are possible under **DHW**:

| End user (E) | Commissioning, Technician (menu state) |
|-------------------------|--|
| Monitor has tripped | Monitor has tripped |
| Manual control active | Manual control active |
| Consumption | Consumption |
| Holding mode On | Holding mode Active Holding mode On |
| Recooling active | Recooling via collector Recooling via heat gen Recooling via HCs |
| Charging lock active | Discharging prot active Charg time limitation active Charging locked |
| Forced charging active | Forced, max stor tank temp Forced, max charging temp Forced, legionella setp Forced, nominal setp |
| Charg el imm heater | El charging, legionella setp El charging, nominal setp El charging, reduced setp El charging, frost prot setp El imm heater released |
| Push active | Push, legionella setp Push, nominal setp |
| Charging active | Charging, legionella setp Charging, nominal setp Charging, reduced setp |
| Frost protection active | Frost protection active Frost protection Instantaneous water heater |
| Overrun active | Overrun active |
| Standby charging | Standby charging |
| Charged | Charged, max st tank temp |
| | Charged, max charging temp |
| | Charged, legionella temp |
| | Charged, nominal temp |
| | Charged, reduced temp |
| Off | Off |
| Ready | Ready |

The following messages are possible under **boiler**:

| End user (Eu) | Commissioning, Engineer (menu state) |
|-----------------------------|--|
| SLT has tripped | SLT has tripped |
| Fault | Fault |
| Flue gas temp too high | Flue gas temp, shutdown Flue gas temp, powerlimitation |
| Limiter has tripped | Limiter has tripped |
| Manual control active | Manual control active |
| Chimney sweep funct active | Chimney-sweep function, nominal load Chimney-sweep function, part load |
| Locked | Locked, manual Locked, solid fuel boiler Locked, automatic Locked, outside temp Locked, economy mode |
| Min limitation active | Min limitation Min limitation, part load Min limitation active |
| In operation | Protective start Protective start, part load Return limitation Return limitation, part load |
| Charging buffer | Charging buffer |
| In op for HC, DHW | In op for HC, DHW |
| In part load op for HC, DHW | In part load op for HC, DHW |
| Released for HC, DHW | Released for HC, DHW |
| In operation for DHW | In operation for DHW |
| In part load op for DHW | In part load op for DHW |
| Released for DHW | Released for DHW |
| In operation for HC | In operation for HC |
| In part load op for HC | In part load op for HC |
| Released for HC | Released for HC |
| Overrun active | Overrun active |
| Released | Released |
| Frost protection active | Frost prot plant active |
| Off | Off |

Programming

The following messages are possible under **Solar**:

| End user (E) | Commissioning, Technician (menu <i>state</i>) |
|------------------------------|--|
| Manual control active | Manual control active |
| Fault | Fault |
| Frost prot collector active | Frost prot collector active |
| Recooling active | Recooling active |
| Max st tank temp reached | Max st tank temp reached |
| Evaporation prot active | Evaporation prot active |
| Overtemp prot active | Overtemp prot active |
| Max charging temp reached | Max charging temp reached |
| Charging DHW+buffer+swi pool | Charging DHW+buffer+swi pool |
| Charging DHW+buffer | Charging DHW+buffer |
| Charging DHW+swi pool | Charging DHW+swi pool |
| Charging buffer+swi pool | Charging buffer+swi pool |
| Charging DHW | Charging DHW |
| Charging buffer | Charging buffer |
| Charging swimming pool | Charging swimming pool |
| Radiation insufficient | Min charg temp not reached Temp diff insufficient Radiation insufficient |

Programming

The following messages are possible under **solid fuel boiler**:

| End user (Eu) | Commissioning, Engineer (menu state) |
|-----------------------------|--|
| Manual control active | Manual control active |
| Fault | Fault |
| Overtemp prot active | Overtemp prot active |
| Released | Locked, manual Locked, automatic |
| Min limitation active | Min limitation Min limitation, part load Min limitation active |
| In operation for HC | Protective start Protective start, part load Return limitation Return limitation, part load 14 In operation for HC |
| In part load op for HC | In part load op for HC |
| In operation for DHW | In operation for DHW |
| In part load op for DHW | In part load op for DHW |
| In op for HC, DHW | In op for HC, DHW |
| In part load op for HC, DHW | In part load op for HC, DHW |
| Overrun active | Overrun active |
| In operation | In operation |
| Assisted firing active | Assisted firing active |
| Released | Released |
| Frost protection active | Frost prot plant active Boiler frost prot active |
| Off | Off |

The following messages are possible under **burners**:

| End user (Eu) | Commissioning, Engineer (menu state) |
|----------------------|---|
| Fault position | Fault position |
| Start prevention | Start prevention |
| In operation | In operation |
| Commissioning | Safety time Purge Commissioning |
| | Postpurge Shutdown Home mode |
| Standby | Standby |

Programming

The following messages are possible under **Buffer**:

| End user (Eu) | Commissioning, Engineer (menu state) |
|-------------------------|--|
| Warm | Warm |
| Frost protection active | Frost protection active |
| Charg el imm heater | El charge, emergency mode El charge, source protection Electric charging defrost Electric charging, forced Electric charging, substitute |
| Charging restricted | Charging locked Restricted, DHW priority |
| Charging active | Forced charging active Partial charging active |
| Recooling active | Recooling via collector Recooling DHW / HCs |
| Charged | Charged, max st tank temp Charged, min charging temp Charged, forced temp Charged, required temp Part charged, required temp Charged, min charging temp |
| Cold | Cold |
| No request | No request |

The following messages are possible under **swimming pool**:

| End user (E) | Commissioning, Technician (menu State) |
|--------------------------------|---|
| Manual control active | Manual control active |
| Fault | Fault |
| Heating mode restricted | Heating mode source |
| Heated, max Swimming pool temp | Heated, max Swimming pool temp |
| Heated | Heated, Setpoint solar Heated, Setpoint source |
| Heating mode | Heating mode solar off Heating mode source off |
| Cold | Cold |

8.4.23 Diagnostics cascade/heat generation/consumers

Parameter not intended for operation with WGS !



Diagnostics cascade/heat generation/consumers (8100 - 9058)

Displays of different nominal and actual values, relay switching statuses and counter statuses for diagnosis purposes.

Prepurge time
(9500)



8.4.24 Burner control

Pre-venting time.

Note: This parameter must only be changed by a heating specialist!

Nominal output prepurging
(9504)

Nominal output fan speed during preventing.

Nominal output ignition load
(9512)

Nominal output fan speed during ignition.

Nominal output Partial load
(9524)

Nominal output fan speed under boiler in LF.



Note: If you change this value, please note that prog. no. 2452 is always set higher!

Nominal output Full load
(9529)

Nominal output fan speed under boiler in HF

Postpurge time
(9540)



After-venting time.

Note: This parameter must only be changed by a heating specialist!

Fan output/speed slope
(9626)
Fan output/speed Y-section
(9627)

With this parameter the rotational speed of the fan can be adjusted (e.g. for complex exhaust systems or the conversion of gas condensing boilers for operating with liquid gas.

- Prog. no. 9626 equates to the incline of the fan characteristic curve
- Prog. no. 9627 equates to the shift of the fan characteristic curve in Y-direction

8.4.25 Info Option

Display of different information values which depend on the current operation state. Furthermore, informations about the different states are displayed (see section *State*).

Maintenance

9. Maintenance

9.1 Inspection and need dependent service



Note:

It is recommended to carry out maintenance of the EuroCondense three annually. Should during inspection the need for maintenance work be found, these should be carried out according to need.

Maintenance work includes among others:

- Clean EuroCondense three outside.
- The burner has to be checked for contamination and, possibly, to be cleaned and serviced.
- Clean burner areas and heating surfaces
- Replace wear parts (see *Spare parts list*)



Caution! Only original spare parts must be used.

- Check connection and seal locations of water filled parts.
- Check safety valves for correct function.
- Check operating pressure and, possibly, fill in water.
- De-aerate heating plant
- De-aerate heating plant and return gravity lock into operating position.
- End control and documentation of performed service work




Tip: Conclude a maintenance contract!

In order to guarantee an optimum operation, recommend to have a service contract.


9.2 Boiler view

Fig. 30: Boiler view Eurocondense three 125-170



Maintenance

Fig. 31: Boiler view Eurocondense three 215-300



9.3 Disassembling and installing burner




Risk of electric shock! Before performing service work, power to the boiler must be shut off and it must be secured from accidentally being switched back on!

Disassembling burner

1. Close gas shut off device
2. Remove front panel of the SGB E gas condensing boiler
3. Release ignition cable, ionisation line and earthing cable.


4. Disconnect connection lines from fan and gas valve

Fig. 32: Loosen screws on the exhaust silencer



5. Remove screws on the flange of the venturi tube (2) and loosen the venturi tube with seal (in the flange) from the exhaust silencer (1).


Fig. 33: Release gas connection hose on the gas valve




6. Release gas connection hose (3) on the gas valve (4)

Fig. 34: Remove burner

Eurocondense three
125 - 170



Eurocondense three
215 - 300 E



7. Remove nuts and washers and pull out the entire burner (5) with burner seal (6) forwards

Installing burner

The installation of the burner is done in the opposite sequence

Note: Use new seals when installing the burner.


9.4 Check combustion room insulation



Attention! Check combustion room insulation after removing the burner!

After removing the burner the combustion room insulation must be checked for the correct position (Fig. 35) and increased wear. No plate should have slipped and caused large gaps. If in doubt replace the insulation!

Fig. 35: Position of the combustion room insulation.



1. Check the combustion room insulation (1) for the correct position.
2. If the insulation is torn, tipped forward or has large gaps, the insulation must be replaced!

Observe the spare part instructions.



Note: After installation of the burner the burner pipe lies on the rear combustion room insulation.

9.5 Installing the combustion room insulation.

The burner must be removed to install or replace the combustion room insulation.

1. Remove the existing combustion room insulation (1) from the rear wall of the heat exchanger (see Fig. 35).
2. Remove the residue of the insulation from the heat exchanger with the vacuum cleaner.
3. Follow the sequence (1. to 4.) when installing the insulation!
 1. Slide the insulation (1.) upwards
 2. Slide insulations (2. and 3.) to the left or right
 3. Wedge insulation (4.) in the remaining space

Maintenance

9.6 Check and replacing Ignition electrode



Note: To avoid an influence of the ionisation current by the ignition, the ignition electrode must only immerse into the edge of the flame.




Change ignition electrodes


Danger of electric shock! Before performing service work, power to the boiler must be shut off and it must be secured from accidentally being switched back on!

Fig. 36: Remove ignition electrode block

Eurocondense three
125 - 170



Eurocondense three
215 - 300



C0004597

1. Loosen ignition cable
2. Remove nuts and pull out the ignition electrode block (1) with the seal (2)
3. Insert the new ignition electrode block with seal and fasten with nuts



Note: Installation position and electrode clearance has to be maintained according to Fig. 38 .

4. Reconnect the ignition cable

9.7 Check and replacing ionisation electrode

The ionisation electrode must always be in contact with the flame. During burner operation, the measured ionisation flow must following data display:

- At minimum power > 5 μA DC (switching threshold at 0.7 μA DC)
- At maximum power > 10 μA DC

Measurement ionization current

For measurement of the ionisation current, pull plug from the gas-firing automaton and connect amperemeter between plug and electrode.

Danger of electric shock! Do not touch plug contacts during the ignition process!




Changing the ionisation electrode

Danger of electric shock! Before performing service work, power to the boiler must be shut off and it must be secured from accidentally being switched back on!



Fig. 37: Removing ionisation electrode



1. Release ionisation line
2. Remove nuts and pull out the ionisation electrode (1) with the seal (2)
3. Insert the new ionisation electrode with seal and fasten with nuts

Note: Installation position and electrode clearance has to be maintained according to Fig. 38




4. Reconnect the ionisation line

Maintenance

9.8 Electrode spacing and installation locations

Fig. 38: Electrode spacing and installation locations




- 1 Ionisation electrode
- 2 Ignition electrode block

9.9 Clean burner pipe

1. Removing burner (see section *Installing and removing burner*)

Fig. 39: Dismantle burner pipe



2. Remove screws and remove burner pipe (1) with the burner pipe seal (2)
 3. Clean the burner pipe with compressed air
 4. Reinstall burner pipe with burner pipe seal
- Note: Use a new burner pipe seal when installing the burner pipe.




5. Reinstall burner (see section *Installing and removing burner*)

9.10 Clean heat exchanger


1. Remove burner (see section *Installing and removing burner*)

Fig. 40: Remove the cover of the exhaust collection pan



2. Remove screws and remove cover (1) of the exhaust collection pan with seal (2)


Fig. 41: Heat exchanger



3. Clean heat exchanger (3) with a brush or rinse with water
4. Remove deposits from the exhaust collection pan

Maintenance

Fig. 42: Siphon



5. Remove siphon (4) and clean
 6. Clean siphon
 7. Reinstall siphon
 8. Replace the cover of the exhaust collection pan
- Note: Use a new seal when installing the cover.




9. Reinstall burner (see section *Installing and removing burner*)

9.11 Clean fan

Dismounting the burner

1. Remove burner (see section *Installing and removing burner*)

Fig. 43: Remove fan



2. Remove nuts with washers and release the fan (3) with seal (2) from burner cover (1)
3. Remove screws and release venturi pipe, incl. gas valve (5) with seal (4) from fan
4. Clean fan with compressed air
5. Reassemble burner in the opposite sequence

Note: Use new seals when reassembling the burner.



6. Reinstall burner (see section *Installing and removing burner*)

Maintenance

9.12 Fault switch-off

Safety switch-off in case of flame failure during the operation.

After every safety switch-off a new ignition attempt is carried out as per program. If this does not result in flame formation a fault switch-off occurs.

In case of fault switch-off, the reset button on the control panel should be pressed. In case of operation disturbances (bell symbol in the display), the digit in the display on the operating panel points out the cause of the disturbance (see fault code table).

Burner does not start:

- No voltage at the control and regulating centre
- no "burner ON" signal from the heating circuit control (see *fault code table*)

Burner goes into disturbance status:

Without flame formation:

- No ignition
- ionisation electrode has ground connection
- no gas

In spite of flame formation the burner goes on fault after expiration of the safety time:

- Ionisation electrode defective or soiled.
- Ionisation electrode does not penetrate the flame

9.13 Fault code table

The following is the fault code table. In case of further displayed fault codes, please inform the heating specialist.

| Fault code | Fault description | Explanations/causes |
|------------|---|--|
| 0 | No error | |
| 10 | Outside temp sensor fault | Connection or AT-sensor, emergency operation |
| 20 | Boiler temperature 1 Sensor fault | Check connection, inform heating specialist ¹⁾ |
| 25 | Boiler temperature solid fuel sensor fault | |
| 26 | Boiler temperature solid fuel sensor fault | |
| 28 | Boiler temperature solid fuel sensor fault | |
| 30 | Flow temperature 1 Sensor fault | |
| 32 | Flow temperature 2 Sensor fault | Check connection, inform heating specialist ¹⁾ |
| 38 | Boiler temperature solid fuel sensor fault | |
| 40 | Return temperature 1 Sensor fault | Check connection, inform heating specialist ¹⁾ |
| 46 | Boiler temperature solid fuel sensor fault | |
| 47 | Common return temp sensor fault | |
| 50 | DHW temperature 1 sensor fault | Check connection, inform heating specialist, emergency operation ¹⁾ |
| 52 | DHW temperature 2 sensor fault | Check connection, inform heating specialist ¹⁾ |
| 54 | Flow temperature DHW sensor fault | |
| 57 | Drinking water circulation temperature sensor fault | |
| 60 | Room temperature 1 sensor fault | |
| 65 | Room temperature 2 sensor fault | |
| 68 | Room temperature 3 sensor fault | |
| 70 | Storage tank temp 1 (top) sensor fault | |
| 71 | Storage tank temp 2 (bottom) sensor fault | |
| 72 | Storage tank temp 3 (middle) sensor fault | |
| 73 | Collector temperature 1 sensor fault | |
| 81 | LPB short-circuit or no bus power supply | |
| 82 | LPB Address collision | Check addresses of connected control modules |
| 83 | BSB-wire short/circuit | Check connection of the room units |
| 84 | BSB Address collision | 2 room devices have the same allocation (Prog.-Nr. 42) |
| 85 | BSB-radio communication fault | |
| 91 | EEPROM fault: information of locking mechanism | Internal fault LMS, process sensor, replace LMS, heating specialist |
| 98 | Expansion module 1 fault (collective fault) | |
| 99 | Expansion module 2 fault (collective fault) | |
| 100 | Two time masters (LPB) | Check time master |
| 102 | Clock time master without backup | |
| 105 | Servicing message | See maintenance code (press information button once) for detailed information |
| 109 | Boiler temperature monitoring | |

Maintenance

| Fault code | Fault description | Explanations/causes |
|------------|--|---|
| 110 | Safety temperature limiter lockout | No heat removal, STB/interruption, possibly short in gas valve ²⁾ , internal fuse defective; let device cool down and reset; if this fault occurs several times, inform heating specialist ³⁾ |
| 111 | Temperature monitor switching off | No heat removal; pump defect, radiator valves closed ¹⁾ |
| 119 | Fault pressure switch | Check or refill water pressure ¹⁾ |
| 121 | Flow temperature 1 (Heating circuit 1) monitoring | |
| 122 | Flow temperature 2 (Heating circuit 2) monitoring | |
| 126 | DHW charging monitoring | |
| 127 | Legionnaire's setpoint temperature not reached | |
| 128 | Flame failure during operation | |
| 130 | | |
| 132 | Gas pressure monitor- or air pressure switch fault | Lack of gas, contact GW opened, external temperature monitor |
| 133 | No flame during the safety time | Reset, if the fault re-occurs several times, contact heating specialist, lack of gas, polarity of mains connection, safety period, check ignition electrode and ionisation current ^{1) 3)} |
| 146 | Configuration fault Common message | |
| 151 | Internal fault | Check parameter (see Adjustment Table Heating Expert and/or Call-up Values), reset LMS, change LMS, heating expert ^{1) 3)} |
| 152 | Parameterization fault | |
| 160 | Fan fault | Fan possible defective, speed threshold set wrongly ³⁾ |
| 162 | Air pressure monitor doesn't close. | |
| 171 | Alarm contact H1 or H4 activated. | |
| 172 | Alarm contact H2 (EM1, EM2 or EM3) or H5 activated | |
| 178 | Temperature monitor heating circuit 1 | |
| 179 | Temperature monitor heating circuit 2 | |
| 183 | The device is in Parameter setting mode | |
| 217 | Sensor fault | |
| 218 | Pressure supervision | |
| 241 | Flow sensor solar sensor fault | |
| 242 | Return sensor solar sensor fault | |
| 243 | Swimming pool sensor fault | |
| 260 | Flow temperature 3 Sensor fault | |
| 270 | Monitoring function | |
| 317 | Ned frequency outside of valid range | |
| 320 | DHW Charging temp sensor fault | |
| 321 | | |
| 324 | BX same sensors | |

| Fault code | Fault description | Explanations/causes |
|---|---|---------------------|
| 325 | BX/e'module same sens | |
| 326 | BX/m'grp same sens | |
| 327 | E'module same funct | |
| 328 | Mix group same funct | |
| 329 | E'mod/m'grp same funct | |
| 330 | Sensor BX1 no function | |
| 331 | Sensor BX2 no function | |
| 332 | Sensor BX3 no function | |
| 335 | Sensor BX21 no function (EM1, EM2 or EM3) | |
| 336 | Sensor BX22 no function (EM1, EM2 or EM3) | |
| 339 | Coll pump Q5 missing | |
| 341 | Coll sensor B6 missing | |
| 342 | Solar DHW sensor B31 missing | |
| 343 | Solar integration missing | |
| 344 | Solar ctrl elem buffer K8 missing | |
| 345 | Sol ctrl elem swi pool K18 missing | |
| 346 | Solid fuel boiler pump Q10 missing | |
| 347 | Solid fuel boil comp sens missing | |
| 348 | Solid fuel boil addr err | |
| 349 | Buff valve Y15 missing | |
| 350 | Buffer address error | |
| 351 | Prim/sys pump addr err | |
| 352 | Pr'less header addr err | |
| 353 | Common flow sensor B10 missing | |
| 371 | Flow temperature 3 (Heating circuit 3) monitoring | |
| 372 | Limit thermostat HC3 | |
| 373 | Expansion module 3 fault (collective fault) | |
| 378 | Repetition counter internal fault expired | |
| 382 | Repetition counter fan fault expired | |
| 384 | Extran light | |
| 385 | Ned undervoltage | |
| 386 | Fan: revolutions per minute has left valid range | |
| 387 | Air pressure switch fault | |
| 426 | Checkb sign flue gas damper: | |
| 427 | Configuration flue gas damper | |
| 432 | Functional earth X17 not connected | |
| <p>1) Switching off, start prevention, re-start after removal of fault</p> <p>2) Check parameter according to table Setting Table Heating Specialist and program basic settings or call-up internal LMS SW-diagnosis code and correct respective parameter fault according to fault information!</p> <p>3) Switching off and interlock; can only be unlocked by reset</p> | | |

Maintenance

9.14 Maintenance code table

| Maintenance codes | Maintenance description |
|-------------------|---------------------------------|
| 1 | Burner operating hours exceeded |
| 2 | Burner starts exceeded |
| 3 | Maintenance interval exceeded |

9.15 Operating phases of the Control Centre LMS

Press the information key to display the operating phases.

| Phase no. | | |
|-----------|--|--|
| Display | Operating state | Description of function |
| STY | Standby (no heat demands) | Burner on stand-by |
| THL1 | Fan start-up | Self-test for burner start and fan start-up |
| THL1A | | |
| TV | Pre-purging time | Pre-purging, fan deceleration time to starting load speed |
| TBRE | Waiting time | Internal safety tests |
| TW1 | | |
| TW2 | | |
| VDE | Ignition phase | Ignition and start of safety time for flame formation, ionisation current build-up |
| tsa1 | Safety time constant | Flame monitoring with ignition |
| tsa2 | Safety time variable | Flame monitoring without ignition |
| it | Interval time | Flame stabilisation |
| MOD | Modulating mode | Burner in operation |
| THL2 | Subsequent ventilation with last operating fan speed | Fan continues to run |
| THL2A | Subsequent ventilation with pre-purging fan speed | Fan continues to run |
| TNB | Burner shut-off delay | Permitted burner run-on time |
| TNN | Overrun time | Permitted fan run-on time |
| STV | Start prevention | No internal or external release exists (e.g. no water pressure, lack of gas) |
| SAF | Safety switch-off | |
| STOE | Fault position | The actual fault code is displayed, see <i>fault code table</i> |

Index

2

24-hour heating limit 83

A

Air inlet 43

Application example 24

Automatic day heating limit 46

Automatic operation 46

Automatic summer/winter switch-over 46

B

Boiler view

-Eurocondense three 125-170 129

-Eurocondense three 215-300 130

Boost heating 85

C

Cable lengths 39

Check tightness 35

CO₂ -Content 36

-Check and setting 38

Combustion air

-Corrosion protection 18

Combustion supply air 21

Comfort setpoint 46

Commissioning 19, 36, 41

Commissioning sheet 43

Condensate 34

Conformity declaration 9

Connect components 40

Connections 10

Construction work 41

Content of this manual 5

Continuous operation 46

Controller stop function 38, 38, 119

Controller stop mode 37

Convert type of gas 36

Customer service; Telephone 119

D

DHW operation 46

DHW temperature 42

Diagnostics consumers 126

Dimensions 10

Disassembling

-Burner 130

Discharge from safety valve 43

E

ECO 45

Emergency operation 48

Error message 47

F

Factory setting 79

Factory settings 35

Fault 140

Fault code table 141

Fault message 45

Floor curing function 88

Flue lengths 34

Flue system 34

Frost protection plant 115, 115

Frost protection setpoint 46, 81

Fuses 40

G

Gas connection 35

Gas filter 35

Gravity lock 128

H

Heating curve

-Adaptation 82

-Diagram 82

-Displacement 82

-Slope 81

Heating isolator switch 42

Heating mode 45

I

INFO 45

Information 47

Input/output tests 120

Installation room 21

Installing

-Burner 132

Ionization current 135

L

Language 41

Legionella function 46

Liquid gas under ground 8

Lock

-Operation 78

-Programming 78

M

Mains isolator 39

Maintenance Contract 128

Maintenance message 48

Manual adjustment of burner load 37, 119, 119

Manual control 48, 119

Measure ionization current 135

Menu-Commissioning 41

O

Operating phases 144

Operator section

-Activate 79

Optimum start and stop control 86
Original spare parts 128
Outside temperature sensor 40

P

Protection 46
Protection against contact 40
Purging the gas line 35

Q

Quick setback 85

R

Reduced setpoint 47
Reduced setpoint increase 87
Regulations 8
Replacing cables 40
Requirements for heating circuit water 18
Resistance values 15
Restoring factory setting 48
Room influence 84
Room temperature 42
-Comfort setpoint 46
-Reduced setpoint 47

S

Safety valve 34, 128
Service message 45
Set frost protection temperature 45
Shut-off valve 35
Software version 80, 116
Spare parts 128
Standards 8
State 120
Strain reliefs 39
Summer/winter heating limit 82

T

Technical Data 11
Time program 42
Topping up water 128

U

Used symbols 6
Usa appropriato 7

W

Water pressure 41
Wiring Diagram 14

Space for notes

A large, empty rectangular box with a thin black border, occupying most of the page. It is intended for the user to write notes.



RS 33961

Baxi Commercial
Wood Lane, Erdington
Birmingham B24 9QP

Sales: **0845 070 1056** Technical: **0845 070 1057**

Email: potterton.commercial@baxicommercialdivision.com
www.pottertoncommercial.co.uk

POTTERTON
COMMERCIAL

heating specialists

